Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TCT TCT-DL1320M

TCT 1320 Magenta Toner Cartridge User Manual

Model: TCT-DL1320M

1. Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your TCT 1320 Magenta Toner Cartridge. This cartridge is designed as a compatible replacement for Dell 310-9064 (1320M, Ku055) magenta toner cartridges, ensuring reliable performance with compatible Dell printers.

2. Printer Compatibility

This TCT toner cartridge is compatible with the following Dell printer models:

- Dell 1320
- Dell 1320C
- Dell 1320CN
- Dell 1320DN



Image: Visual representation of compatible Dell 1320 series laser printers.

3. Package Contents

Each package contains:

- 1 x TCT Compatible Replacement Magenta Toner Cartridge (for Dell 310-9064 - 1320 Series)



Image: The TCT 1320 Magenta Toner Cartridge shown with its retail packaging.

4. Installation Instructions

Follow these steps to install your new toner cartridge:

1. **Unpack the Cartridge:** Carefully remove the new toner cartridge from its protective packaging. Avoid touching the drum or electrical contacts.
2. **Shake the Cartridge:** Gently shake the cartridge horizontally 5-6 times to evenly distribute the toner inside.
3. **Remove Protective Cover:** Remove any orange protective covers, seals, or tapes from the cartridge as indicated.
4. **Open Printer Access:** Open the front cover or access panel of your Dell printer to expose the toner cartridge slots.
5. **Remove Old Cartridge:** Carefully pull out the used magenta toner cartridge from its slot.

6. **Insert New Cartridge:** Align the new TCT magenta toner cartridge with the corresponding slot and slide it in until it clicks firmly into place.
7. **Close Printer Cover:** Close the printer's access panel. The printer will typically perform a self-test or calibration.



Image: A person handling a toner cartridge, illustrating the preparation for installation.

5. Operation and Usage

5.1. Page Yield

This magenta toner cartridge is designed to produce approximately**2,000 pages** at 5% coverage (Letter/A4). Actual page yield may vary based on print content, printer settings, and other environmental factors.



Image: An illustration indicating the average page yield of 2,000 pages for the magenta toner cartridge.

5.2. Print Quality

TCT compatible toner cartridges are manufactured to provide consistent performance and printing results comparable to original cartridges. They utilize high-quality components to ensure clear, vibrant, and professional output for your documents and images.



Image: Individuals examining printed charts and documents, highlighting the quality of print resolution.

6. Maintenance and Storage

6.1. Storage

- Store toner cartridges in their original, unopened packaging in a cool, dry place.
- Keep cartridges away from direct sunlight, extreme temperatures, and high humidity.

6.2. Handling

- Do not expose the toner cartridge's drum surface to light for extended periods, as this can cause damage.
- Avoid touching the green drum surface or the electrical contacts on the cartridge to prevent print quality issues.

7. Troubleshooting Common Issues

7.1. Faded Prints or Streaks

- **Action:** Gently remove the toner cartridge and shake it horizontally 5-6 times to redistribute the toner. Reinsert it firmly.
- **Action:** Check your printer settings to ensure 'Toner Save Mode' is not enabled, which can reduce toner density.
- **Action:** If the issue persists, the cartridge may be low on toner and require replacement.

7.2. 'Toner Low' or 'Replace Toner' Message

- **Action:** This message indicates that the cartridge is nearing the end of its operational life. Continue printing until print quality degrades significantly, then replace the cartridge.

7.3. Cartridge Not Recognized

- **Action:** Remove the cartridge and reinsert it firmly to ensure it is properly seated in its slot.
- **Action:** Power off the printer, wait 30 seconds, then power it back on. This can reset the printer's internal sensors.
- **Action:** Gently clean the electrical contacts on the cartridge and inside the printer with a dry, lint-free cloth.

8. Product Specifications

Feature	Detail
Brand	TCT
Model Number	TCT-DL1320M
Color	Magenta
Page Yield	Up to 2,000 pages (at 5% coverage)
Compatible Printers	Dell 1320, 1320C, 1320CN, 1320DN
Replaces OEM Part Numbers	Dell 310-9064, 1320M, Ku055
Item Weight	7.5 ounces (0.47 Pounds)
Product Dimensions	7.68 x 3.74 x 5.12 inches
UPC	713356556618



Image: A robust toner cartridge, highlighting its design for consistent performance.

9. Warranty and Support

For warranty information or technical support regarding your TCT toner cartridge, please refer to the contact details provided with your purchase or visit the official TCT website for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01MQYSA3V

More documents and user manuals: **https://manuals.plus/**