Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bosch 2608522320

Bosch Professional Quick Release Bit Holder

MODEL: 2608522320

1. Introduction

This manual provides essential information for the safe and effective use of your Bosch Professional Impact Control Quick Release Bit Holder. This universal holder is designed for quick and easy bit changes and provides a strong, secure hold for various screwdriving applications with power tools. Its robust construction ensures durability, especially in impact applications.

2. Safety Information

Always observe general safety precautions when working with power tools and accessories. Failure to follow these instructions may result in electric shock, fire, and/or serious injury.

- **Wear Eye Protection:** Always wear appropriate eye protection when operating power tools.
- **Secure Workpiece:** Ensure the workpiece is stable and securely clamped before beginning work.
- **Use Correct Bit:** Use only screwdriver bits that are compatible with the bit holder and suitable for the task.
- **Inspect Before Use:** Before each use, inspect the bit holder for any signs of damage or wear. Do not use damaged accessories.
- **Keep Hands Clear:** Keep hands and body parts away from rotating parts.
- **Disconnect Power:** Always disconnect the power tool from the power source before changing accessories or performing maintenance.

3. Product Overview

The Bosch Professional Quick Release Bit Holder features a robust design for demanding applications. It is equipped with a quick-change function and a permanent magnet to ensure bits are held firmly and securely.

- **Impact Control:** Designed to withstand high torque and impact forces.
- **Quick Release Function:** Allows for fast and easy bit changes.
- **Permanent Magnet:** Provides a secure grip on screwdriver bits, preventing slippage.
- **1/4-inch Hex Shank:** Compatible with standard cordless screwdrivers and impact wrenches.
- **Pick and Click System:** Designed to integrate with Bosch's modular accessory sets.


BOSCH



Figure 1: Bosch Professional Quick Release Bit Holder in its retail packaging. The packaging highlights "PRO Bit Holder Impact" and "Universal Brand Fit".





Figure 2: Close-up view of the Bosch Professional Quick Release Bit Holder, showing its textured grip and a total length of 60 mm.

4. Setup

To use the bit holder, it must first be securely inserted into a compatible power tool.

1. Ensure your power tool (cordless screwdriver or impact wrench) is turned off and disconnected from its power source (if applicable).
2. Open the chuck of your power tool sufficiently to accept the 1/4-inch hex shank of the bit holder.
3. Insert the hex shank of the Bosch Professional Quick Release Bit Holder into the tool's chuck.
4. Tighten the chuck firmly to secure the bit holder. Ensure it is seated correctly and does not wobble.



Figure 3: The bit holder securely attached to the chuck of a power drill, ready for operation.

5. Operating

The quick-release mechanism allows for efficient bit changes.

5.1. Inserting a Screwdriver Bit

1. Hold the bit holder firmly.
2. Pull the knurled collar of the bit holder forward (away from the power tool).
3. Insert the desired 1/4-inch hex screwdriver bit into the opening.
4. Release the collar. The bit will snap into place and be held by the internal mechanism and the permanent magnet. Gently pull on the bit to ensure it is securely seated.

5.2. Removing a Screwdriver Bit

1. Hold the bit holder firmly.
2. Pull the knurled collar of the bit holder forward (away from the power tool).
3. The bit will be released. Remove it from the holder.
4. Release the collar.



Figure 4: The bit holder with an inserted screwdriver bit actively driving a screw into a metal surface, demonstrating its secure hold during operation.

6. Maintenance

Proper maintenance ensures the longevity and optimal performance of your bit holder.

- **Cleaning:** Periodically wipe the bit holder with a clean, dry cloth to remove dust, debris, and metal shavings. Do not use solvents or harsh chemicals.
- **Inspection:** Regularly inspect the quick-release mechanism and the magnet for any signs of wear or damage. Ensure the collar moves freely.
- **Storage:** Store the bit holder in a dry place, away from direct sunlight and extreme temperatures. Keep it protected from impacts.

7. Troubleshooting

If you encounter issues with your bit holder, consider the following:

- **Bit Not Holding Securely:**
  - Ensure the bit is fully inserted and the collar has snapped back into place.
  - Check if the bit's hex shank is clean and free of debris.
  - Inspect the internal magnet and locking mechanism for damage or obstruction.
- **Difficulty Releasing Bit:**
  - Ensure the collar is pulled fully forward.
  - Check for any debris or corrosion preventing smooth collar movement.
- **Bit Holder Wobbles in Tool Chuck:**
  - Ensure the power tool's chuck is tightened securely around the bit holder's hex shank.
  - Verify the chuck itself is not damaged or worn.

8. Specifications

Brand	Bosch
Model Number	2608522320
Material	Metal
Item Length	60 mm (approximately 2.36 inches)
Drive System	External Hex
Bit Compatibility	1/4-inch Hex
Item Weight	0.02 kg (approximately 0.04 lbs)
GTIN	3165140851107

9. Warranty and Support

For warranty information, technical support, or service inquiries regarding your Bosch Professional product, please refer to the official Bosch Professional website or contact your local Bosch representative.

Official Website: www.bosch-professional.com



Figure 5: Bosch Professional contact details, including the official website.

© Bosch Professional. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01MTA0E7V

More documents and user manuals: **https://manuals.plus/**