Other SQ-109

SQ-109 Arabic Kaaba Design Bluetooth Speaker User Manual

Model: SQ-109 (2724647195148)

Introduction

Thank you for purchasing the SQ-109 Arabic Kaaba Design Bluetooth Speaker. This device is designed to provide high-quality audio playback, primarily featuring Quranic recitations and other Islamic content, along with standard Bluetooth speaker functionality. Its unique design is inspired by the Holy Kaaba. Please read this manual carefully to ensure proper use and maintenance of your speaker.

Safety Information

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from water and other liquids.
- Do not attempt to disassemble or modify the speaker. This will void the warranty.
- Use only the provided charging cable and a compatible power adapter (not always included) for charging.
- Keep out of reach of children.

Package Contents

Please check the box for the following items:

- SQ-109 Arabic Kaaba Design Bluetooth Speaker
- Remote Control
- USB Charging Cable
- User Manual (this document)
- Power Adapter (may vary by region or not be included)



Image: The SQ-109 speaker, its remote control, and a power adapter/charging cable, laid out to show the complete package contents.

Product Overview

Familiarize yourself with the various parts of your SQ-109 speaker.



Image: A detailed view of the SQ-109 speaker, showcasing its black body with gold Kaaba-inspired decorative bands and the speaker grille on top.



Image: An angled view of the SQ-109 speaker, highlighting the textured top surface which serves as the speaker grille, and the intricate gold detailing.

Ports and Controls (Bottom/Rear Panel)



Image: The bottom section of the SQ-109 speaker, displaying the input ports: a slot for a MicroSD card, a Micro USB charging port, and an auxiliary audio input jack.

- **MicroSD Card Slot:** For playing audio files directly from a memory card.
- **Micro USB Port:** For charging the speaker's internal battery.
- **AUX-in Port:** For connecting external audio devices via a 3.5mm audio cable.
- **Power Button:** (Location not explicitly visible in images, typically on the back or bottom) To turn the speaker On/Off.

Remote Control Functions

The remote control provides full functionality for navigating content and controlling playback.

- **Power Button:** Turn the speaker On/Off.
- **Volume +/-:** Adjust volume level.

- **Previous/Next:** Navigate between tracks or chapters.
- **Play/Pause:** Control audio playback.
- **Mode Button:** Switch between Bluetooth, MicroSD, and AUX modes.
- **Number Buttons (0-9):** Direct selection of Surahs or tracks.
- **Language/Reciter Selection:** Buttons for changing language (e.g., Arabic, English) or selecting different reciters/Qaris.
- **Azaan Button:** Play Azaan (call to prayer).
- **MP3 Button:** Switch to MP3 playback mode.
- **Ayat/Surah Buttons:** Specific buttons for navigating by Ayah or Surah.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the Micro USB end of the charging cable to the speaker's Micro USB port and the standard USB end to a USB power adapter (5V/1A recommended) or a computer's USB port. The charging indicator light (if present) will show charging status and turn off or change color when fully charged. A full charge typically takes 2-3 hours.

2. Powering On/Off

Press and hold the Power button on the speaker or the remote control for a few seconds to turn the speaker On or Off. You will hear an audible prompt indicating the power status.

Operating Instructions

1. Bluetooth Mode

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode or you can press the "Mode" button on the remote until you hear "Bluetooth Mode".
2. Enable Bluetooth on your smartphone, tablet, or other Bluetooth-enabled device.
3. Search for "SQ-109" or a similar name in the list of available devices.
4. Select "SQ-109" to pair. Once connected, you will hear a confirmation sound.
5. You can now play audio from your device through the SQ-109 speaker. Use the remote control or your device to adjust volume and control playback.

2. MicroSD Card Playback

1. Insert a MicroSD card (up to 8GB, as per product description) with pre-loaded audio files (e.g., Quranic recitations, MP3s) into the MicroSD card slot on the speaker.
2. The speaker should automatically switch to MicroSD mode. If not, press the "Mode" button on the remote until it enters this mode.
3. Use the remote control to navigate through files, select specific Surahs/Ayats using the number buttons, adjust volume, and control playback.

3. AUX Mode

1. Connect one end of a 3.5mm audio cable (not included) to the AUX-in port on the speaker and the other end to the headphone jack of your external audio device (e.g., MP3 player, laptop).
2. Press the "Mode" button on the remote until the speaker enters AUX mode.
3. Audio from your connected device will now play through the speaker. Control playback and volume primarily from your external device.

4. Special Functions (Using Remote Control)

- **Language Switching:** Use the dedicated language buttons (e.g., Arabic, English) to switch the recitation language if supported by the content.
- **Reciter Selection:** If multiple reciters are available on the MicroSD card, use the corresponding buttons to select your preferred Qari.
- **Azaan Playback:** Press the "Azaan" button to play the call to prayer.
- **Direct Surah/Ayat Selection:** In MicroSD mode, use the number pad to directly input the Surah or Ayah number you wish to listen to.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the speaker. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in constant use.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker for at least 30 minutes.
No sound from speaker.	Volume is too low; Incorrect mode selected; Device not connected properly.	Increase volume; Press "Mode" button to select correct input; Re-pair Bluetooth or re-insert MicroSD/AUX cable.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Device too far; Interference.	Ensure speaker is in Bluetooth mode; Move device closer; Turn off other Bluetooth devices nearby.
Remote control not working.	Battery in remote is dead; Obstruction between remote and speaker.	Replace remote control battery; Ensure clear line of sight to the speaker's IR receiver.
MicroSD card not recognized.	Card inserted incorrectly; Card corrupted; Unsupported format.	Re-insert card correctly; Try a different card; Ensure files are in MP3 format.

Specifications

- **Model:** SQ-109 (2724647195148)
- **Connectivity:** Bluetooth
- **Storage:** Supports MicroSD card (up to 8GB)
- **Audio Input:** AUX (3.5mm)
- **Charging Port:** Micro USB
- **Speaker Type:** Bookshelf (as per product specs)
- **Dimensions:** Approximately 10 x 16.2 x 13.2 cm (3.9 x 6.4 x 5.2 inches)
- **Weight:** Approximately 350 grams (0.77 lbs)
- **Battery:** Rechargeable (Type: Quran, indicates it's a Quran speaker with battery)

Warranty and Support

The SQ-109 speaker comes with a **12-month warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.
For technical support, warranty claims, or further inquiries, please contact the retailer or manufacturer through the contact information provided at the point of purchase. Do not attempt to repair the device yourself.

© 2024 Other. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question