Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ergohuman LE10ERGLO

Ergohuman Eurotech LE10ERGLO Executive Mid Back Leather Swivel Office Chair Instruction Manual

Introduction

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your Ergohuman Eurotech LE10ERGLO Executive Mid Back Leather Swivel Office Chair. Following these guidelines will ensure optimal performance, comfort, and longevity of your chair. Please read all instructions carefully before assembly and use.

Safety Information

To prevent injury or damage to the chair, adhere to the following safety guidelines:

- Always follow the assembly instructions precisely.
- Use the chair only for its intended purpose as an office chair.
- Do not exceed the maximum weight capacity of**275 lbs (125 kg)**.
- Keep hands and feet clear of moving parts during adjustment.
- Ensure all bolts and screws are securely tightened before use and periodically check for looseness.



Image: Front and side views of the Ergohuman chair with detailed dimensions and a clear label for the 275 lbs weight capacity.

Setup and Assembly

Your Ergohuman chair is designed for straightforward assembly. All necessary tools and clear instructions are included in the packaging. Please lay out all components on a clean, soft surface to prevent scratches.

Assembly Steps:

1. Unpack all components and verify against the parts list provided in your package.
2. Attach the casters to the five-star base.
3. Insert the gas lift cylinder into the center hole of the five-star base.
4. Attach the seat mechanism to the underside of the seat cushion using the provided screws.
5. Mount the backrest to the seat mechanism.
6. Attach the armrests to the seat mechanism.
7. Place the assembled seat and backrest onto the gas lift cylinder.

8. Ensure all connections are secure before using the chair.

Refer to the detailed assembly sheet included in your product packaging for specific diagrams and step-by-step guidance.



Image: Front and side views of the Ergohuman chair highlighting various adjustment points and an icon indicating easy assembly with included tools.

Operating Adjustments

The Ergohuman LE10ERGLO chair offers a wide range of adjustments to customize your seating experience for optimal ergonomic support and comfort. Familiarize yourself with these controls:

Chair Adjustments:

- **Seat Height Adjustment:** Use the lever located on the right side under the seat to raise or lower the seat to your desired height. Ensure your feet are flat on the floor or a footrest.
- **Seat Depth Adjustment:** Pull the lever on the left side of the seat to slide the seat forward or backward. Adjust

so there is a 2-3 inch gap between the edge of the seat and the back of your knees.

- **Back Height Adjustment:** Lift the backrest to adjust its height. This supports the natural curve of your spine, particularly the lumbar region.
- **Back Angle Adjustment / Tilt Lock:** Use the lever on the left side to recline the backrest and lock it into your preferred angle.
- **Synchro-Tilt:** The chair features a synchro-tilt mechanism where the backrest reclines at a preset ratio to the seat, promoting an open body angle.
- **Tilt Tension Control:** Rotate the knob under the seat (usually at the front) to increase or decrease the resistance of the chair's tilt. Turn clockwise for more resistance, counter-clockwise for less.
- **Arm Height Adjustment:** Press the button on the side of each armrest to raise or lower the armrests to support your forearms comfortably.
- **Arm Depth Adjustment:** Slide the armrest pads forward or backward to find the optimal position.
- **Swivel Arm:** The armrests can swivel to accommodate various tasks and postures.
- **Dynamic Adjustable Lumbar Support:** The lumbar support automatically adjusts to your back's curve as you recline, providing continuous support.
- **360-Degree Horizontal Rotation:** The chair allows for full 360-degree rotation for ease of movement.




Image: Side view of the Ergohuman chair illustrating back height adjustment, back angle lock, synchro-tilt, dynamic lumbar support, and the patented single lever activation.

Maintenance

Regular maintenance will help preserve the appearance and functionality of your Ergohuman chair.

Cleaning and Care:

- **Leather Care:** Clean the leather upholstery with leather-specific cleaning products. Avoid harsh chemicals or abrasive cleaners.
- **Conditioning:** Condition the leather regularly to prevent drying and cracking.
- **Sunlight Exposure:** Avoid direct sunlight exposure for prolonged periods to prevent fading and damage to the leather.
- **Frame and Base:** Wipe metal and plastic components with a soft, damp cloth.
- **Casters:** Periodically clean casters to remove dust and debris that may hinder smooth movement.

General Maintenance:

- Periodically check all bolts and screws to ensure they are tight. Retighten if necessary.
- Lubricate moving parts (e.g., gas lift, tilt mechanism) with a silicone-based lubricant if squeaking occurs.

Troubleshooting

If you encounter any issues with your Ergohuman chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift may need replacement.
Chair squeaks during movement	Loose connections or lack of lubrication.	Check and tighten all bolts and screws. Apply a silicone-based lubricant to moving parts and joints.
Difficulty reclining or locking tilt	Tilt mechanism or tilt lock lever issue.	Ensure the tilt lock lever is fully disengaged or engaged as desired. Check tilt tension knob for proper adjustment.
Casters do not roll smoothly	Debris in casters or damaged casters.	Clean any hair or debris from the caster wheels. If damaged, casters may need replacement.

If these solutions do not resolve the issue, please contact customer support.

Specifications

- **Model:** LE10ERGLO
- **Brand:** Ergohuman
- **Manufacturer:** Eurotech Seating
- **Material:** Leather (Upholstery), Foam (Fill Material), Metal (Form Factor)
- **Color:** Black
- **Product Dimensions (D x W x H):** 28.74" x 26.57" x 40" (Minimum Height) to 52.36" (Maximum Height)
- **Seat Depth:** 18.11 inches
- **Chair Backrest Width:** 20.47 inches
- **Maximum Weight Recommendation:** 275 Pounds
- **Item Weight:** 64 pounds
- **Back Style:** Solid Back
- **Special Feature:** Multi-Functional Adjustments
- **Furniture Base Movement:** Swivel
- **Certifications:** BIFMA Standards, Greenguard Certified

Warranty

All Eurotech chairs, including the Ergohuman LE10ERGLO, come with a**Limited Lifetime Warranty**. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, please refer to the warranty documentation included with your purchase or visit the official Ergohuman website.

Customer Support

Should you have any questions, require assistance with assembly, or need to address a warranty claim, please contact our customer support team:

- **Email:** For direct assistance, please email the seller or manufacturer as indicated in your purchase documentation.
- **Online:** Visit the official Ergohuman Store for additional resources and contact information:Ergohuman Store
- **Seller:** For purchase-specific inquiries, contact "Sofa In The Box" through your Amazon order details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01NBR66P0

More documents and user manuals: **https://manuals.plus/**