Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T POWER TP-Jz2-KW4

T POWER 8.4V Charger Instruction Manual

For Kokido XTROJET 220, 320, 330 Cordless Robotic Pool Floor Vacuum Cleaners

1. Introduction

This manual provides essential information for the safe and effective use of your T POWER 8.4V AC/DC charger. This charger is specifically designed to power and recharge Kokido XTROJET 220, 320, and 330 cordless robotic pool floor vacuum cleaners. Please read this manual thoroughly before use and retain it for future reference.
Important Note: This charger is **NOT** compatible with Kokido Xtrovac 210 - EV25 models.



Image 1.1: A Kokido XTROJET robotic pool vacuum cleaner, compatible with this charger.

2. Safety Information

To ensure safe operation and prevent damage, observe the following safety precautions:

- Use the charger only with compatible devices as specified in this manual.
- Do not expose the charger to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the charger to severe impact.
- Do not attempt to disassemble or modify the charger. Refer all servicing to qualified personnel.
- Ensure the power outlet voltage matches the charger's input voltage range (AC 100V-240V).
- Unplug the charger from the power outlet when not in use or during electrical storms.
- Keep the charger away from children and pets.



Image 2.1: T POWER charger highlighting built-in safety protections such as over-current, over-temp, over-voltage, and short circuit protection.

3. Package Contents

Verify that all items are present upon opening the package:

- 1 x T POWER 8.4V AC/DC Adapter (Model: TP-Jz2-KW4 / LX084200)

4. Setup

Follow these steps to set up your charger:

1. Ensure the Kokido XTROJET robotic pool cleaner is turned off and dry before connecting the charger.
2. Locate the charging port on your Kokido XTROJET device.
3. Connect the barrel connector of the T POWER charger securely into the charging port of the robotic pool cleaner.
4. Plug the AC power cord of the charger into a standard wall outlet (AC 100V-240V).

5. Operating Instructions

Once connected, the charger will automatically begin charging the robotic pool cleaner's battery. The LED indicator on the charger provides status updates.

LED Indicator Display

The charger features an LED indicator to show its operational status:

- **Green light flashing:** The device is currently charging.
- **Green light solid:** The device is fully charged.
- **Red light flashes fast:** Indicates a defective state.
- **Red light flashes fast & slow:** Indicates a temperature anomaly.



Image 5.1: The T POWER charger displaying its LED indicator and corresponding charging statuses.

Once the green light is solid, indicating a full charge, disconnect the charger from both the wall outlet and the robotic pool cleaner.

6. Maintenance

Proper maintenance ensures the longevity and performance of your charger:

- Keep the charger clean and free from dust and debris. Use a soft, dry cloth for cleaning.
- Store the charger in a cool, dry place when not in use.
- Avoid wrapping the cable too tightly around the charger to prevent wire damage.
- Regularly inspect the cable and connectors for any signs of wear or damage. Discontinue use if damage is observed.

7. Troubleshooting

If you encounter issues with your charger, refer to the following table:

Problem	Possible Cause	Solution
Charger LED not lighting up.	No power from outlet; loose connection; faulty charger.	Check wall outlet with another device; ensure all connections are secure; try a different outlet. If issue persists, charger may be faulty.
Device not charging (Green light flashing).	Device not properly connected; device battery issue.	Ensure the barrel connector is fully inserted into the device's charging port. Verify the device is compatible.
Red light flashing fast.	Defective state.	Disconnect the charger and device. Reconnect after a few minutes. If the red light persists, the charger or device may be defective.
Red light flashing fast & slow.	Temperature anomaly.	Disconnect the charger and device. Allow both to cool down in a well-ventilated area before attempting to charge again.

8. Specifications

- **Brand:** T POWER
- **Model Number:** TP-Jz2-KW4 (Compatible Adapter Models: LX084200, LXO842OO)
- **Input Voltage Range:** AC 100V - 240V
- **Output Voltage:** DC 8.4V
- **Output Amperage:** 2 Amps
- **Output Wattage:** 16.8 Watts
- **Connector Type:** Barrel Connector
- **Special Features:** Fast Charging, Over-Current Protection, Over-Temp Protection, Over-Voltage Protection, Short Circuit Protection
- **Certifications:** CE, RoHS
- **Compatible Devices:** Kokido XTROJET 220, Kokido XTROJET 320, Kokido XTROJET 330 Cordless Robotic Pool Floor Vacuum Cleaners
- **Weight:** Approximately 4 Ounces (113 grams)

9. Warranty and Support

Your T POWER charger comes with a **1-Year Limited Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use.
For warranty claims, technical support, or any inquiries, please contact T-Power customer service through the retailer where the

product was purchased or visit the official T POWER website for contact information.



Image 9.1: T POWER product information detailing 1-year limited warranty and technical support availability.

© 2023 T POWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06X1C2KW4

More documents and user manuals: **https://manuals.plus/**