Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER PT-D210

PKPower AC/DC Adapter for Brother PT-D210 P-Touch Printer

Model: PT-D210 Compatible Power Supply

Introduction

This manual provides essential information for the safe and effective use of your PKPower AC/DC Adapter, designed specifically for the Brother PT-D210 P-Touch Printer. Please read this manual thoroughly before use and retain it for future reference.
The PKPower AC/DC Adapter is engineered to deliver reliable power to your compatible device. It features a wide input voltage range (100-240V, 50-60Hz) for global compatibility and incorporates multiple safety protections, including Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP), ensuring the safety of both the adapter and your connected device. The product is CE, FCC, and RoHS certified.

Setup

1. **Unpack the Adapter:** Carefully remove the PKPower AC/DC Adapter from its packaging. Inspect it for any visible damage.
2. **Locate the Power Port:** Identify the DC input power port on your Brother PT-D210 P-Touch Printer.
3. **Connect to Device:** Insert the DC output plug of the PKPower adapter firmly into the power port of your Brother PT-D210 P-Touch Printer. Ensure a secure connection.
4. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard wall power outlet (100-240V, 50-60Hz).
5. **Verify Power:** Once connected, your Brother PT-D210 P-Touch Printer should receive power. Refer to your printer's manual for specific power indicator lights or startup procedures.



Image: The PKPower AC/DC Adapter with its cable neatly coiled, ready for connection.

Operating Instructions

The PKPower AC/DC Adapter is designed for continuous operation when connected to a compatible device and a power source. No specific operational steps are required for the adapter itself beyond proper connection.

- Ensure the adapter is always connected to a power outlet within the specified voltage range (100-240V).
- Only use the adapter with compatible devices, such as the Brother PT-D210 P-Touch Printer, to prevent damage.
- Disconnect the adapter from the power outlet when not in use for extended periods or during electrical storms.



Image: Side view of the PKPower AC/DC Adapter, highlighting the compact design and standard US plug.

Maintenance

Proper maintenance ensures the longevity and safe operation of your PKPower AC/DC Adapter.

- **Cleaning:** Disconnect the adapter from both the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter's casing and cable for any signs of damage, such as cuts, fraying, or bent prongs. If damage is found, discontinue use immediately and replace the adapter.
- **Environmental Conditions:** Avoid exposing the adapter to moisture, rain, or excessive humidity. Do not operate it in environments with poor ventilation.

Troubleshooting

If you encounter issues with your PKPower AC/DC Adapter, refer to the following troubleshooting steps:

Problem	Possible Cause	Solution
Device not receiving power	Adapter not properly connected	Ensure the adapter's DC plug is fully inserted into the device and the AC prongs are fully inserted into the wall outlet.
Device not receiving power	Wall outlet is not active	Test the wall outlet with another known working device. Check circuit breakers if necessary.
Device not receiving power	Damaged adapter or cable	Inspect the adapter and cable for visible damage. If damaged, discontinue use and replace.
Adapter feels excessively hot	Overload or poor ventilation	Ensure the adapter is used with a compatible device. Provide adequate ventilation around the adapter. Disconnect if overheating persists.

Specifications

Input: 100-240V AC, 50-60Hz

Output: (Specific output voltage/current not provided in source, typically matches device requirements)

Connector Type: Auxiliary (DC Barrel Connector)

Compatible Devices: Brother PT-D210 P-Touch Printer and other compatible models

Color: Black

Safety Certifications: CE, FCC, RoHS

Protection Features: Over Voltage Protection (OVP), Over Current Protection (OCP), Short Circuit Protection (SCP)

Power Source: Corded Electric

Support

For any questions, concerns, or assistance regarding your PKPower AC/DC Adapter, please contact our customer service. Our friendly and reliable customer service team aims to respond to your inquiries within 24 hours.
Please refer to the contact information provided with your purchase or visit the official PKPower website for support details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XC4MZC8

More documents and user manuals: **https://manuals.plus/**