Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC/DC Adapter

PK Power AC/DC Adapter User Manual

For Shinco Portable DVD Players: SDP1720, SDP1720C, SDP1750, SDP1750A

1. Introduction

This manual provides essential instructions for the safe and effective use of your PK Power AC/DC Adapter. This adapter is designed to provide reliable power to compatible Shinco Portable DVD Player models, specifically SDP1720, SDP1720C, SDP1750, and SDP1750A. Please read this manual thoroughly before use and retain it for future reference.

2. Product Overview



Figure 2.1: Overall view of the PK Power AC/DC Adapter, showing the main unit, power prongs, and attached output cable.





Figure 2.2: Top view of the adapter, highlighting the textured casing design.

2.3 Key Features

- **Universal Input:** Operates with input voltage from 100-240V AC, 50-60Hz, suitable for worldwide use.
- **Safety Certifications:** CE, FCC, and RoHS certified, ensuring compliance with international safety and environmental standards.
- **Advanced Protection:** Equipped with Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.

2.4 Package Contents

The package includes the following items:

- 2 x PK Power AC/DC Adapter

Note: The quantity of adapters may vary based on the specific product offering. Please check your packaging.

3. Setup Instructions

Follow these steps to properly connect your AC/DC adapter to your Shinco Portable DVD Player.

1. **Verify Compatibility:** Ensure your Shinco Portable DVD Player model is one of the compatible models: SDP1720, SDP1720C, SDP1750, or SDP1750A.
2. **Connect to Device:** Insert the small connector end of the adapter cable into the DC input jack of your Shinco Portable DVD Player. Ensure a firm connection.
3. **Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard wall power outlet (100-240V AC, 50/60Hz).
4. **Power On:** Once connected, your device should be ready to power on. Refer to your DVD player's manual for specific power-on procedures.





Figure 3.1: Side profile of the adapter, illustrating the standard two-prong plug for wall outlets.

4. Operating Instructions

The PK Power AC/DC Adapter functions as a direct power source and charger for your compatible Shinco Portable DVD Player. No specific operational steps are required for the adapter itself beyond proper connection.

- Once connected to a power source and your device, the adapter will supply power.
- If your device has a rechargeable battery, the adapter will also charge it while providing power.
- Always ensure the adapter is securely plugged into both the wall outlet and your device.

5. Safety Information

To prevent damage to the adapter, your device, or personal injury, please observe the following safety precautions:

- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open, modify, or repair the adapter. Refer servicing to qualified personnel.
- Ensure the adapter is used with compatible devices only. Using it with incompatible devices may cause damage.
- Unplug the adapter from the wall outlet when not in use for extended periods.
- Keep out of reach of children.
- The adapter features **Over Voltage Protection (OVP)**, **Over Current Protection (OCP)**, and **Short Circuit Protection (SCP)** to prevent damage from electrical irregularities. However, these features are not a substitute for careful handling and proper usage.

6. Maintenance and Care

- **Cleaning:** Disconnect the adapter from all power sources and devices before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.

7. Troubleshooting

If you encounter issues with your PK Power AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device not powering on or charging.	Adapter not properly connected. Wall outlet not functioning. Device compatibility issue. Damaged adapter or cable.	Ensure both ends of the adapter are securely plugged in. Test the wall outlet with another device. Confirm your device model is listed as compatible. Inspect the adapter and cable for visible damage. If damaged, discontinue use and contact support.
Adapter feels warm during use.	Normal operation.	A slight warmth is normal during operation. If the adapter becomes excessively hot or emits smoke/odor, unplug immediately and discontinue use.

8. Specifications






Figure 8.1: Detailed view of the adapter's label, displaying input specifications and safety marks (FCC, CE, RoHS).

Feature	Detail
Brand	PKPOWER
Input Voltage	100-240V AC, 50/60Hz
Compatible Devices	Shinco Portable DVD Players (SDP1720, SDP1720C, SDP1750, SDP1750A)
Safety Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Certifications	CE, FCC, RoHS
Color	Black
Included Components	2 x AC Adapter



Figure 8.2: Dimensions of the PK Power AC/DC Adapter, showing approximate measurements for length, width, and height.

9. Warranty and Customer Support

PK Power products are designed for reliability and performance. We stand by the quality of our products.

- **After-Sale Service:** Our customer service team is available to assist you with any questions or concerns. We aim to respond to inquiries within 24 hours.
- For support, please refer to the contact information provided with your purchase or visit the official PKPOWER store on Amazon.

© 2026 PKPOWER. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XC71GNV

More documents and user manuals: **https://manuals.plus/**