Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC/DC Adapter

PKPower AC/DC Adapter Instruction Manual

For PROFORM Elliptical Exerciser Models PFEL59050, PFEL59051, PFEL59050-900, PFEL59051-900

1. Introduction

This manual provides essential instructions for the safe and effective use of your PKPower AC/DC Adapter. This adapter is designed to provide reliable power to compatible PROFORM Elliptical Exerciser models. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: PKPower AC/DC Adapter. This image shows the adapter unit with its attached power cable, coiled neatly, providing a clear view of the product's overall design.

2. Safety Information

Always follow basic safety precautions when using electrical products to reduce the risk of fire, electric shock, and injury to persons.

- Do not expose the adapter to rain or moisture.
- Do not use the adapter if it has been damaged in any way.
- Ensure the adapter is connected to a properly grounded outlet.
- Keep out of reach of children.
- Disconnect the adapter from the power source when not in use.

Proposition 65 Warning:

This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

3. Compatibility

This PKPower AC/DC Adapter is specifically designed for use with the following PROFORM Elliptical Exerciser models:

- PROFORM Elliptical Exerciser 900 Model PFEL59050
- PROFORM Elliptical Exerciser 900 Model PFEL59051
- PROFORM Elliptical Exerciser 900 Model PFEL59050-900
- PROFORM Elliptical Exerciser 900 Model PFEL59051-900

Ensure your device's power requirements match the adapter's output specifications before connecting.

4. Setup Instructions

Follow these steps to properly connect your AC/DC adapter:

1. **Unpack:** Carefully remove the PKPower AC/DC Adapter from its packaging.
2. **Inspect:** Check the adapter and cable for any visible damage. Do not use if damaged.
3. **Connect to Device:** Locate the power input port on your PROFORM Elliptical Exerciser. Insert the adapter's output connector firmly into the device's power input port.
4. **Connect to Power Outlet:** Plug the adapter's AC input prongs into a standard 100-240V AC wall outlet.
5. **Verify Power:** Confirm that your elliptical exerciser receives power, typically indicated by an LED light on the device or its display activating.

5. Operating Instructions

The PKPower AC/DC Adapter is designed for continuous use with compatible devices. Once connected, it provides a stable power supply.

- Ensure the adapter is placed in a well-ventilated area to prevent overheating.
- Avoid pulling the cable forcefully when disconnecting. Always grasp the plug itself.
- Do not attempt to open or modify the adapter.

6. Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter.

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or sprays.
- **Storage:** When not in use for extended periods, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the cable and adapter housing for any signs of wear, cuts, or damage. Replace the adapter if any damage is found.

7. Troubleshooting

If you encounter issues with your PKPower AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not powering on.	Adapter not properly connected. Power outlet not working. Adapter is faulty.	Ensure all connections are secure. Test the outlet with another device. Try a different compatible adapter if available.
Adapter feels hot.	Normal operation (slight warmth). Overload or poor ventilation.	Ensure adequate ventilation around the adapter. If excessively hot, disconnect immediately and contact support.
Intermittent power to device.	Loose connection. Damaged cable.	Check all connections. Inspect the cable for damage. Replace if cable is damaged.

8. Specifications

Key technical specifications for the PKPower AC/DC Adapter:

Feature	Detail
Input Voltage	100-240V AC, 50-60Hz
Output Voltage	12 Volts
Product Dimensions	4 x 2 x 0.5 inches (approximate)
Item Weight	3 ounces
Color	Black
Connector Type	Auxiliary
Certifications	CE, FCC, RoHS



Figure 2: PKPower AC/DC Adapter with dimensions. This image illustrates the physical dimensions of the adapter, showing its length, width, and height in inches.

9. Warranty Information

PKPower products are manufactured to high-quality standards. For specific warranty details, please refer to the product packaging or contact PKPower customer support. Typically, products are covered against defects in materials and workmanship under normal use.

10. Customer Support

If you have any questions, require assistance, or need to report an issue with your PKPower AC/DC Adapter, please contact our customer support team. Our friendly and reliable customer service will respond to you within 24 hours.
For support, please visit the PKPOWER store on Amazon or refer to the contact information provided with your purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XF47JLB

More documents and user manuals: **https://manuals.plus/**