Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC/DC Adapter B06XGQV661

PK Power AC/DC Adapter for Altec Lansing Moondance M302 Clock Radio: User Manual

Introduction

This manual provides essential information for the safe and effective use of your PK Power AC/DC Adapter. This adapter is specifically designed to provide power to the Altec Lansing Moondance M302 Clock Radio.

Safety Information

Your PK Power AC/DC Adapter is designed with safety in mind and meets international standards. Please observe the following safety guidelines:

- **Certifications:** This product is CE, FCC, and RoHS certified, indicating compliance with health, safety, and environmental protection standards.
- **Protection Features:** The adapter incorporates OVP (Over Voltage Output Protection), OCP (Over Current Output Protection), and SCP (Short Circuit Output Protection) to safeguard your device and the adapter itself from electrical damage.
- **Voltage Compatibility:** The adapter supports a wide input voltage range of 100-240 VAC, 50/60Hz, making it suitable for worldwide use.
- **General Safety:**
  - Do not expose the adapter to water or excessive moisture.
  - Avoid dropping or subjecting the adapter to severe impact.
  - Do not attempt to open or modify the adapter.
  - Ensure the adapter is used in a well-ventilated area.
  - Unplug the adapter from the power outlet when not in use for extended periods.

Setup

Follow these steps to set up your PK Power AC/DC Adapter:

1. **Inspect the Adapter:** Before use, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.

2. **Connect to Device:** Locate the power input port on your Altec Lansing Moondance M302 Clock Radio. Carefully insert the adapter's output connector into this port. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the adapter's input prongs into a standard wall power outlet (100-240 VAC, 50/60Hz).
4. **Verify Power:** Once connected, your Altec Lansing Moondance M302 Clock Radio should power on or indicate that it is receiving power.



Image 1: The PK Power AC/DC Adapter, showing the main unit with a US-style plug and the attached DC barrel connector cable.

Operating Instructions

The PK Power AC/DC Adapter is designed for straightforward operation:

- Once properly connected to both the Altec Lansing Moondance M302 Clock Radio and a power outlet, the adapter will continuously supply power to the device.
- There are no user-adjustable settings on the adapter itself. Its function is automatic.
- To disconnect power, simply unplug the adapter from the wall outlet.



Image 2: A view of the PK Power AC/DC Adapter, highlighting the compact design and the neatly coiled power cable.

Maintenance

Proper care ensures the longevity of your adapter:

- **Cleaning:** Always unplug the adapter from the power outlet before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cable excessively. Avoid placing heavy objects on the cable.



Image 3: The PK Power AC/DC Adapter, displaying the side with the product label, which typically includes input/output specifications.

Troubleshooting

If you encounter issues with your adapter, consider the following:

- **Device Not Powering On:**
  - Ensure the adapter is securely plugged into both the Altec Lansing Moondance M302 Clock Radio and a functional wall outlet.
  - Test the wall outlet with another device to confirm it is receiving power.
  - Check the adapter cable for any visible damage. If damaged, discontinue use.
- **Intermittent Power:** Ensure all connections are firm and stable. Avoid placing the adapter or cable in positions where they might be easily disturbed.
- **Adapter Overheating:** While some warmth is normal, excessive heat may indicate an issue. Ensure the adapter is in a well-ventilated area and not covered. If overheating persists, discontinue use.

For issues specific to the Altec Lansing Moondance M302 Clock Radio, please refer to its dedicated user manual.

Specifications

Feature	Detail
Input Voltage	100-240 VAC, 50/60Hz
Certifications	CE, FCC, RoHS
Protection	OVP, OCP, SCP

Connector Type	Auxiliary (DC Barrel Connector)
Color	Black
Power Source	Corded Electric

Warranty and Support

PK Power is committed to customer satisfaction. If you have any questions or require assistance with your adapter:

- **Customer Service:** Our friendly and reliable customer service team aims to respond to inquiries within 24 hours.
- **Return Policy:** This product is typically covered by a 30-day return policy for refunds or replacements. Please refer to your purchase platform for specific details.
- **Contact:** For support, please refer to the contact information provided by your retailer or visit the official PKPOWER store online.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XGQV661

More documents and user manuals: **https://manuals.plus/**