Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC/DC Adapter for Grundig Satellit 750

PK Power AC/DC Adapter User Manual

For Grundig Satellit 750 AM/FM Stereo/Shortwave/Airwave Band Radio

1. Introduction

This manual provides essential instructions for the safe and efficient use of your PK Power AC/DC Adapter. This adapter is designed to provide reliable power to compatible devices, specifically the Grundig Satellit 750 AM/FM Stereo/Shortwave/Airwave Band Radio. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: Front view of the PK Power AC/DC Adapter, showing the main unit with power prongs and attached output cable.

2. Important Safety Information

To ensure safe operation and prevent damage, observe the following precautions:

- Use the adapter only with devices that match its voltage and current specifications.
- Do not expose the adapter to water, moisture, or extreme temperatures.

- Avoid dropping or subjecting the adapter to severe impact.
- Do not attempt to open or modify the adapter. Refer all servicing to qualified personnel.
- Unplug the adapter from the wall outlet when not in use for extended periods.
- Keep out of reach of children.
- Ensure proper ventilation around the adapter during operation.

3. Setup Instructions

Follow these steps to connect your PK Power AC/DC Adapter to your Grundig Satellit 750 radio:

1. **Verify Compatibility:** Ensure your Grundig Satellit 750 radio requires a power input compatible with this adapter's specifications (Input: 100-240V 50-60Hz).
2. **Connect to Device:** Insert the adapter's output connector securely into the DC input jack of your Grundig Satellit 750 radio.
3. **Connect to Power Outlet:** Plug the adapter's prongs into a standard wall power outlet (100-240V AC).
4. **Power On:** Once connected, your radio should receive power. Refer to your radio's manual for specific power-on procedures.



Figure 2: Side view of the PK Power AC/DC Adapter, highlighting the output connector and cable for device connection.

4. Operating Guidelines

The PK Power AC/DC Adapter is designed for continuous operation within its specified limits. No specific operational controls are present on the adapter itself. Its function is to convert AC wall power to DC power for your compatible device.

- Always ensure the adapter is fully plugged into both the wall outlet and the device.
- Avoid placing heavy objects on the adapter or its cable.
- Do not use the adapter if the cable or housing appears damaged.

5. Maintenance and Care

Proper care will extend the life of your AC/DC adapter:

- **Cleaning:** Disconnect the adapter from power and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of wear, cuts, or damage. If damage is observed, discontinue use immediately.

6. Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not powering on.	Adapter not properly connected.	Ensure the adapter is securely plugged into both the wall outlet and the device.
	Wall outlet is not active.	Test the wall outlet with another device to confirm it has power.
	Adapter or cable is damaged.	Inspect the adapter and cable for visible damage. Discontinue use if damaged.
Adapter feels warm during use.	Normal operation.	A slight warmth is normal. If it becomes excessively hot or emits smoke/odor, unplug immediately and discontinue use. Ensure adequate ventilation.

7. Specifications

- **Input:** 100-240V AC, 50-60Hz
- **Output:** Designed for Grundig Satellit 750 AM/FM Stereo/Shortwave/Airwave Band Radio power requirements.
- **Wattage:** 18 watts
- **Connector Type:** Auxiliary
- **Protection Features:** OVP (Over Voltage output Protection), OCP (Over Current output Protection), SCP (Short Circuit output Protection)
- **Certifications:** CE / FCC / RoHS certified
- **Color:** Black

8. Warranty and Support

PK-Power products are manufactured to high standards. For any issues or inquiries, our customer service team is available to assist you.

- **Customer Service:** Our friendly and reliable customer service will respond to you within 24 hours.

- **Returns:** This product is eligible for a refund/replacement within 30 days of purchase. Please refer to your purchase platform for detailed return instructions.

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XKQBPBF

More documents and user manuals: **https://manuals.plus/**