Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC/DC Adapter for Realistic Concertmate 300 Cat No 42-4003

PKPOWER AC/DC Adapter Instruction Manual

For Realistic Concertmate 300 and RadioShack Keyboard Cat No 42-4003

1. Product Overview

This manual provides essential instructions for the safe and effective use of your PKPOWER AC/DC Adapter. This power supply is designed to provide reliable power to compatible devices, specifically the Realistic Concertmate 300 and RadioShack Keyboard Cat No 42-4003.
Please read this manual thoroughly before using the adapter and retain it for future reference.

2. Package Contents

- 1 x PKPOWER AC/DC Adapter

3. Setup and Connection

1. **Verify Compatibility:** Before connecting, ensure your device (e.g., Realistic Concertmate 300 Keyboard) requires the voltage and current supplied by this adapter. Refer to your device's original specifications or manual. This adapter is specifically designed for Realistic Concertmate 300 and RadioShack Keyboard Cat No 42-4003.
2. **Connect to Device:** Insert the adapter's barrel connector firmly into the power input port of your compatible device.
3. **Connect to Power Outlet:** Plug the adapter's AC prongs into a standard 100-240V AC wall outlet.
4. **Power On:** Once connected, your device should receive power. Turn on your device as per its own instructions.



Figure 1: The PKPOWER AC/DC Adapter featuring the standard US plug for wall outlets. This image shows the main body of the adapter with its input prongs.



Figure 2: The PKPOWER AC/DC Adapter showing the output barrel connector, which connects to the compatible electronic device. This view highlights the cable and the device-side connector.

4. Operating Instructions

The PKPOWER AC/DC Adapter operates automatically once connected to a power source and a compatible device. No user intervention is required for its basic function. Ensure the adapter is placed in a well-ventilated area to prevent overheating.

5. Safety Information and Precautions

- Do not expose the adapter to water, moisture, or extreme temperatures.
- Do not disassemble or modify the adapter.
- Avoid dropping or subjecting the adapter to strong impacts.
- Ensure the adapter is used with devices that match its voltage and current specifications.
- Unplug the adapter from the wall outlet when not in use for extended periods.
- This adapter features **OVP (Over Voltage Protection)**, **OCP (Over Current Protection)**, and **SCP (Short Circuit Protection)** to safeguard your devices.
- Keep out of reach of children.

6. Maintenance

- **Cleaning:** Disconnect the adapter from both the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid wrapping the cable too tightly around the adapter body.

7. Troubleshooting

- **No Power to Device:**
  - Ensure the adapter is securely plugged into both the wall outlet and the device.
  - Check if the wall outlet is functional by plugging in another device.
  - Verify that the device's power input port is not damaged.
  - Confirm the adapter is the correct one for your device's power requirements.
- **Adapter Overheating:**
  - Unplug the adapter immediately.
  - Ensure it is not covered or placed in an enclosed space.
  - Verify that the connected device does not exceed the adapter's output current rating.

8. Specifications

Input Voltage	100-240 VAC, 50/60Hz
Output	Matches device requirements (e.g., Realistic Concertmate 300)
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Certifications	CE, FCC, RoHS
Compatible Devices	Realistic Concertmate 300, RadioShack Keyboard Cat No 42-4003
Color	Black

Note: The specific output voltage and current are designed to match the Realistic Concertmate 300 and RadioShack Keyboard Cat No 42-4003. Always verify your device's power requirements.

9. Warranty and Support

PKPOWER products are manufactured to high standards. For any questions, concerns, or technical assistance, please contact our customer service. Our friendly and reliable customer service team aims to respond within 24 hours.
Refer to your purchase documentation for specific warranty terms and contact information.

© 2026 PKPOWER. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XKVH9J8

More documents and user manuals: **https://manuals.plus/**