Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC/DC Adapter for Zebra P120i

PK Power AC/DC Adapter User Manual

For Zebra P120i ID Card Thermal Printer Power Supply

Introduction

This manual provides essential information for the safe and effective use of your PK Power AC/DC Adapter, designed specifically for the Zebra P120i ID Card Thermal Printer. Please read this manual thoroughly before use and retain it for future reference.

Safety Precautions

- Ensure the adapter's input voltage (100-240V) matches your local power supply.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to disassemble or repair the adapter. Refer to qualified personnel for service.
- Disconnect the adapter from the power outlet when not in use for extended periods.
- This adapter is equipped with Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) for enhanced safety.

Package Contents

- 1 x PK Power AC/DC Adapter
- 1 x Power Cord (2-pin)



Image: The PK Power AC/DC Adapter shown with its detachable power cord. The adapter is a black rectangular unit, and the power cord features a standard 2-pin plug for wall outlets and a connector for the adapter.

Setup

1. **Connect the Power Cord:** Insert the 2-pin end of the power cord firmly into the input port of the PK Power AC/DC Adapter.
2. **Connect to Printer:** Locate the power input port on your Zebra P120i ID Card Thermal Printer. Insert the barrel connector end of the adapter's output cable into this port. Ensure a secure connection.
3. **Plug into Wall Outlet:** Insert the wall plug end of the power cord into a standard 100-240V AC electrical outlet.



Image: A close-up view of the PK Power AC/DC Adapter with the power cord connected to its input side. The adapter's output cable with the barrel connector is also visible, ready for connection to the printer.

Operating Instructions

Once the adapter is properly connected to both the power outlet and your Zebra P120i printer, the printer should receive power. Follow the operating instructions provided with your Zebra P120i printer for its specific functions.

- The adapter is designed for continuous operation within its specified voltage and current limits.
- Ensure proper ventilation around the adapter to prevent overheating.

Maintenance

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cables to prevent damage.
- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as frayed wires, cracked casing, or bent connectors. If damage is found, discontinue use immediately.

Troubleshooting

Problem	Possible Cause	Solution
Printer not powering on.	Adapter not properly connected to power outlet or printer.	Ensure all connections are secure. Try a different power outlet.
Adapter feels unusually hot.	Poor ventilation or excessive load.	Ensure adapter is in a well-ventilated area. Disconnect and allow to cool. If problem persists, discontinue use.
Intermittent power to printer.	Loose connection or damaged cable/adapter.	Check all connections. Inspect cables for damage. If damaged, replace the adapter.

If troubleshooting steps do not resolve the issue, please contact customer support.

Specifications

- **Input:** 100-240V AC, 50-60Hz
- **Output:** Matches OEM specifications for Zebra P120i Printer
- **Connector Type:** Barrel Connector
- **Main Power Connector Type:** 2 Pin
- **Compatible Devices:** Zebra P120i ID Card Thermal Printer
- **Special Features:** Over Voltage Protection (OVP), Over Current Protection (OCP), Short Circuit Protection (SCP)
- **Certifications:** CE, FCC, RoHS
- **Power Source:** Corded Electric
- **Mounting Type:** Wall Mount

Warranty and Support

PK-Power products are designed and manufactured to high standards. For any inquiries or assistance, our friendly and reliable customer service team is available to respond within 24 hours.
For specific warranty details, please refer to the information provided at the time of purchase or contact PKPOWER directly through their official channels. Keep your purchase receipt as proof of purchase.

Contact Information:

- Refer to your purchase platform for seller contact details.
- Visit the official PKPOWER store on Amazon: PKPOWER Amazon Store

© 2024 PKPOWER. All rights reserved.
Product Model: AC/DC Adapter for Zebra P120i

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XSJRCXC

More documents and user manuals: **https://manuals.plus/**