Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC/DC Adapter

PK Power AC/DC Adapter for IGIA Vibro Shape MC0138 MCO138 - Instruction Manual

Introduction

This instruction manual provides essential information for the safe and effective use of your PK Power AC/DC Adapter. This adapter is designed to provide reliable power to compatible devices, specifically the IGIA Vibro Shape MC0138 and MCO138 Professional Slimming Massage Belts. Please read this manual thoroughly before use and retain it for future reference.

Safety Information

Always observe the following safety precautions to prevent electric shock, fire, or damage to the adapter or connected devices:

- Ensure the adapter's input voltage (100-240V) matches your local power supply.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open or modify the adapter. There are no user-serviceable parts inside.
- Disconnect the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.
- Use only with compatible devices as specified. Connecting to incompatible devices may cause damage.

This product is CE / FCC / RoHS certified, ensuring it meets safety and environmental standards.

Package Contents

Verify that all items are present in your package:

- 1 x PK Power AC/DC Adapter Unit
- 2 x Power Cords



Image: The PK Power AC/DC Adapter unit shown with its two accompanying power cords. The main adapter block is black and rectangular, connected to a DC output cord, and a separate AC input cord is coiled next to it.

Setup Instructions

1. **Connect the AC Input Cord:** Take one of the provided power cords (the one with the standard wall plug) and connect it securely to the AC input port on the PK Power AC/DC Adapter unit.
2. **Connect to Device:** Take the other power cord (the DC output cord, usually with a barrel connector) and connect its small end to the power input port of your IGIA Vibro Shape MC0138 or MCO138 Professional Slimming Massage Belt. Ensure a firm connection.
3. **Plug into Wall Outlet:** Insert the AC input cord's wall plug into a standard electrical outlet (100-240V, 50-60Hz).



Image: A top-down view of the PK Power AC/DC Adapter. The adapter block is black, and both the AC input cord and DC output cord are

shown neatly coiled, highlighting their connection points to the adapter.

Operating Instructions

Once the adapter is correctly set up and connected to your device and a power outlet:

- The adapter will supply power to your connected device.
- Refer to your IGIA Vibro Shape MC0138/MCO138 manual for specific instructions on operating the massage belt itself.
- To power off, simply unplug the adapter from the wall outlet.

Maintenance

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Wipe the adapter and cords with a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cords to prevent damage.
- **Inspection:** Periodically inspect the adapter and cords for any signs of damage, such as frayed wires, cracked casing, or bent pins. If damage is found, discontinue use immediately and replace the adapter.



Image: A close-up view of the PK Power AC/DC Adapter, focusing on the DC output cord and its connector. The adapter block is visible on the left, and the AC input cord is coiled in the background.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device not powering on.	Adapter not plugged in correctly. Wall outlet not functioning. Device power switch off. Incompatible device.	Ensure all connections are secure. Test the outlet with another device. Check the device's power switch. Verify device compatibility (IGIA Vibro Shape MC0138/MCO138).
Adapter feels unusually hot.	Overload or poor ventilation. Internal fault.	Ensure the adapter is in a well-ventilated area. Disconnect and allow to cool. If overheating persists, discontinue use and contact support.
Visible damage to adapter or cords.	Physical stress or accident.	Discontinue use immediately. Do not attempt to repair. Replace the adapter.

Specifications

- **Input:** 100-240V AC, 50-60Hz
- **Output:** 24V DC
- **Protection Features:** OVP (Over Voltage output Protection), OCP (Over Current output Protection), SCP (Short Circuit output Protection)
- **Certifications:** CE, FCC, RoHS
- **Color:** Black
- **Compatible Devices:** IGIA Vibro Shape MC0138, MCO138 Professional Slimming Massage Belt

Warranty and Support

PK-Power products are designed for reliability and performance. We offer friendly and reliable customer service. If you encounter any issues or have questions regarding your AC/DC adapter, please contact our customer service team. We aim to respond within 24 hours.
For support, please visit the PKPOWER Store on Amazon or refer to your purchase documentation for direct contact information.

© 2023 PKPOWER. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06XWGTXMV

More documents and user manuals: **https://manuals.plus/**