Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER SW-4052

PKPOWER AC/DC Adapter Instruction Manual

Model: SW-4052 | Brand: PKPOWER

1. Introduction

This manual provides instructions for the safe and efficient use of your PKPOWER AC/DC Adapter. This adapter is designed to power Okin Refined SW-4052, Limoss Tranquil Ease lift chairs, and power recliners. Please read this manual thoroughly before installation and operation.

2. Safety Information

- **Electrical Safety:** Ensure the power outlet used is properly grounded and matches the input voltage requirements (100-240V 50-60Hz).
- **Protection Features:** The adapter is equipped with Over Voltage output Protection (OVP), Over Current output Protection (OCP), and Short Circuit output Protection (SCP) to ensure safe operation.
- **Environment:** Do not expose the adapter to water, moisture, or extreme temperatures. Use in a well-ventilated area.
- **Damage:** Do not use the adapter if the cord or plug is damaged. Contact customer service for replacement.
- **Children:** Keep the adapter and its cords out of reach of children.

3. Package Contents

- 1 x PKPOWER AC/DC Adapter



Image of the PKPOWER AC/DC Adapter, showing the main unit, power cord, and output connector.

4. Setup

1. **Connect to Power Outlet:** Plug the AC input cord of the adapter into a standard 100-240V wall outlet. The adapter's indicator light should illuminate, confirming power supply.
2. **Connect to Recliner:** Locate the power input port on your Okin Refined SW-4052 or Limoss Tranquil Ease lift chair/power recliner. Connect the output connector of the PKPOWER AC/DC Adapter to this port. Ensure a secure connection.

▶ **Watch video online**
power recliner power supply

Video demonstrating the connection of a power supply to a recliner, highlighting ease of installation.

5. Operating

Once the adapter is correctly connected to both the power outlet and your recliner, the recliner is ready for use. Operate your lift chair or power recliner using its integrated controls (e.g., hand remote, side panel buttons) as per the furniture's specific instructions.

▶ **Watch video online**
Electric sofa manual controller

Video illustrating the operation of a recliner using a manual controller, powered by a similar adapter.

6. Maintenance

- **Cleaning:** Disconnect the adapter from the power source before cleaning. Use a dry, soft cloth to wipe the surface. Do not use liquid cleaners or sprays.
- **Storage:** When not in use for extended periods, store the adapter in a cool, dry place, away from direct sunlight and moisture.
- **Cable Care:** Avoid bending or crimping the power cords excessively to prevent internal damage.

7. Troubleshooting

- **No Power to Recliner:**
  - Check if the adapter is securely plugged into both the wall outlet and the recliner.
  - Verify that the wall outlet is functional by plugging in another device.
  - Inspect the adapter's cords for any visible damage.
- **Intermittent Power:**
  - Ensure all connections are firm and not loose.
  - Avoid overloading the circuit with other high-power devices.

If issues persist after following these steps, please contact customer support.

8. Specifications

- **Input:** 100-240V 50-60Hz
- **Wattage:** 24 watts
- **Compatibility:** Okin Refined SW-4052 Version No.: JLDP.10.013.000-D, Limoss Tranquil Ease Lift Chair or Power Recline Power Supply Transformer
- **Certifications:** CE / FCC / RoHS certified
- **Protection:** OVP (Over Voltage output Protection), OCP (Over Current output Protection), SCP (Short Circuit output Protection)
- **Color:** Black

9. Warranty and Support

PKPOWER products are tested by the manufacturer to match and/or exceed OEM specifications. We offer a 90-day money-back guarantee. Our friendly and reliable customer service team is available to respond to your inquiries within 24 hours. For support, please refer to the contact information provided with your purchase or on the manufacturer's website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B06ZZR2JFK

More documents and user manuals: **https://manuals.plus/**