Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 9376cc

BRAUN Series 9 9295cc Wet & Dry Men's Electric Shaver

User Manual

1. Introduction

This manual provides comprehensive instructions for the safe and effective use of your BRAUN Series 9 9295cc Wet & Dry Men's Electric Shaver. The Braun Series 9 is designed for efficient and gentle shaving, featuring SyncroSonic technology and a Titanium coated middle trimmer. It incorporates five specialized shaving elements to capture more hair in one stroke, reducing skin irritation. Its SyncroSonic technology adapts to beard density 160 times per minute, providing power where needed. The shaver also includes a HyperLift & Cut trimmer, Direct & Cut trimmer, Protective SkinGuard, and 2x Opti-Foil for a close shave. The 10-D Flexible Shaving System ensures maximum facial adaptability. This model comes with the world's only 5-action alcohol-based Clean & Charge station for automatic cleaning, lubrication, drying, and charging.

2. Safety Information

It is crucial to read and understand all safety warnings and instructions before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Use with caution to avoid cuts or skin irritation.
- Clean and dry the shaver regularly to prevent bacterial growth.
- Do not use near water or while charging the device.
- Keep the appliance dry.
- Do not disassemble the appliance. For repairs, contact an authorized service center.
- Keep out of reach of children.

3. Package Contents

Please check the package for the following items:

- Braun Series 9 Electric Shaver
- Clean & Charge Station
- Cleaning Cartridge (1x)

- Travel Case
- Cleaning Brush
- SmartPlug Power Cord



Figure 3.1: All components included in the BRAUN Series 9 9295cc package.

4. Setup

4.1 Initial Charging

Before first use, fully charge your shaver. Connect the SmartPlug power cord directly to the shaver or to the Clean & Charge Station. A full charge takes approximately one hour and provides up to 50 minutes of cordless shaving time. The display will show the battery status.

4.2 Setting up the Clean & Charge Station

1. Open the Clean & Charge Station by pressing the release button.
2. Insert the cleaning cartridge into the station until it clicks into place.
3. Close the station cover.

4. Connect the SmartPlug power cord to the Clean & Charge Station.



Figure 4.1: Braun Series 9 shaver placed in the Clean & Charge Station.

5. Operating Instructions

5.1 Shaving

The BRAUN Series 9 9295cc can be used for both wet and dry shaving. For optimal results, ensure your skin is clean and dry for dry shaving, or use shaving foam/gel for wet shaving.

- Turn on the shaver by pressing the power button.
- Shave in gentle motions against the direction of hair growth.
- For a closer shave, stretch your skin with your free hand.
- After shaving, turn off the shaver.



Figure 5.1: Front view of the BRAUN Series 9 shaver.

5.2 Using the Precision Trimmer

The integrated precision trimmer can be used for shaping sideburns, mustaches, or for pre-trimming longer hairs before shaving. Slide the trimmer release button upwards to engage the trimmer.

6. Maintenance and Cleaning

Regular cleaning ensures optimal shaving performance and hygiene.

6.1 Manual Cleaning

- After each dry shave, tap the shaver head gently to remove loose hairs.
- For a more thorough manual clean, rinse the shaver head under warm running water while the shaver is switched on. You can use liquid soap if desired.
- Rinse until all residue is gone.
- Turn off the shaver and remove the foil and cutter block. Clean them thoroughly.
- Allow the shaver to air dry completely before reassembling or storing.

6.2 Using the Clean & Charge Station

The Clean & Charge Station automatically cleans, lubricates, dries, and charges your shaver at the push of a button. This is recommended for a hygienic and thorough cleaning process.

1. Ensure the Clean & Charge Station is connected to power and has a cleaning cartridge inserted.
2. Place the shaver head-down into the station, ensuring it clicks into place.
3. Press the start button on the station to initiate the cleaning cycle. The cycle includes cleaning, drying, and charging.
4. The cleaning cartridge should be replaced approximately every 3 months, or when the cleaning indicator light on the station illuminates.

6.3 Replacing Shaving Parts

For continued optimal performance, it is recommended to replace the shaver head (foil and cutter block) every 18 months. Replacement parts are available from authorized Braun retailers.

7. Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 5 minutes, or fully charge it.
Poor shaving performance.	Shaver head is worn or dirty.	Clean the shaver head thoroughly or replace it if worn (recommended every 18 months).
Clean & Charge Station not working.	No power, cleaning cartridge empty, or shaver not correctly inserted.	Ensure power connection, replace cleaning cartridge, and properly seat the shaver.
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Shave gently, do not press too hard. Consider wet shaving with foam/gel. Allow skin to adapt.

8. Specifications

Feature	Detail
Brand	Braun
Model Name	Series 9 + Cleaning Centre
Item Model Number	9376cc

Feature	Detail
Power Source	Battery Powered
Special Feature	Waterproof
Recommended Uses	Beard
Batteries Required	1 Lithium Ion battery
Product Dimensions	4 x 5 x 7 inches; 2.65 Pounds
UPC	069055878552
GTIN	069055878552

9. Warranty and Support

Braun products are manufactured to the highest standards of quality, engineering, and design. Your Braun Series 9 shaver comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.
For product support, replacement parts, or further assistance, please visit the official Braun website or contact Braun customer service. Keep your purchase receipt as proof of purchase for warranty claims.

© 2024 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B071H87W2L

More documents and user manuals: **https://manuals.plus/**