Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRUE VALUE MFG COMPANY PDS38-AER

True Value PDS38-AER 12oz Pink Gloss Enamel Spray Paint User Manual

Model: PDS38-AER

1. Introduction

This manual provides instructions for the safe and effective use of the True Value PDS38-AER 12oz Pink Gloss Enamel Spray Paint. This product is a quick-drying, decorative spray enamel designed for various surfaces, including wood, metal, wicker, masonry, and plastic. It provides a durable, glossy finish.



Image of the True Value PDS38-AER 12oz Pink Gloss Enamel Spray Paint can, featuring a pink cap and label.

2. Safety Information

Always prioritize safety when using spray paint. Failure to follow these warnings may result in injury or property damage.

- **Ventilation:** Use in a well-ventilated area. Avoid breathing vapors. If used indoors, open windows and doors or use a fan.
- **Eye and Skin Protection:** Wear safety glasses with side shields and chemical-resistant gloves to prevent contact with eyes and skin.
- **Flammability:** This product is extremely flammable. Keep away from heat, sparks, open flames, and other

ignition sources. Do not smoke while using.

- **Storage:** Store in a cool, dry place, away from direct sunlight and temperatures above 120°F (49°C).
- **Children and Pets:** Keep out of reach of children and pets.
- **Disposal:** Dispose of empty cans and unused product according to local regulations.

3. Preparation

Proper surface preparation is essential for optimal adhesion and finish quality.

1. **Clean Surface:** Ensure the surface is clean, dry, and free of dust, grease, oil, wax, and loose paint.
2. **Sand (if necessary):** For smooth surfaces or previously painted surfaces, lightly sand with fine-grit sandpaper to create a profile for better adhesion. Wipe away sanding dust.
3. **Masking:** Use painter's tape and drop cloths to protect surrounding areas from overspray.
4. **Temperature and Humidity:** Apply in temperatures between 50°F (10°C) and 90°F (32°C) and relative humidity below 85%. Avoid painting in direct sunlight or on hot surfaces.

4. Setup

Before beginning to spray, ensure the can is properly prepared.

- **Shake Can:** Shake the can vigorously for at least one minute after the mixing ball begins to rattle. Continue to shake occasionally during use.
- **Test Spray:** Test spray on an inconspicuous area or a piece of scrap material to check color and spray pattern.

5. Operating Instructions

Follow these steps for effective application:

1. **Hold Can:** Hold the can upright, 10-12 inches from the surface.
2. **Apply Light Coats:** Apply paint in a steady, back-and-forth motion, slightly overlapping each stroke. Avoid applying heavy coats, which can lead to drips and runs.
3. **Multiple Coats:** For best results, apply several thin coats rather than one thick coat. Allow 5-10 minutes drying time between coats.
4. **Full Cure:** The paint will be dry to the touch in approximately 15-30 minutes, but allow 24 hours for full cure before handling or exposing to heavy use.

6. Maintenance

Proper maintenance ensures the longevity of the product and its usability.

- **Clean Nozzle:** After each use, invert the can and spray for 2-3 seconds until only clear propellant comes out. This prevents the nozzle from clogging.
- **Storage:** Store the can in a cool, dry, well-ventilated area, away from extreme temperatures and direct sunlight. Ensure the cap is securely replaced.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Clogged Nozzle	Paint dried in the nozzle opening.	Remove the nozzle and soak it in mineral spirits or paint thinner. If severely clogged, replace the nozzle. Always clean after use by inverting the can and spraying.
Uneven Spray Pattern	Insufficient shaking, low can temperature, or partially clogged nozzle.	Shake the can vigorously for at least one minute. Warm the can to room temperature. Clean or replace the nozzle.
Drips or Runs	Applying paint too heavily or holding the can too close to the surface.	Apply lighter, more even coats. Maintain a distance of 10-12 inches from the surface.

8. Specifications

Brand: TRUE VALUE MFG COMPANY

Model Name: PDS38-AER

Color: Pink

Finish Type: Gloss

Item Volume: 12 Fluid Ounces

Paint Type: Enamel

Surface Recommendation: Wood, Plastic, Metal

Item Weight: 14.2 ounces

Product Dimensions: 3 x 3 x 8 inches

UPC: 042909100153

9. Warranty and Support

For specific warranty information or technical support regarding your True Value PDS38-AER Pink Gloss Enamel Spray Paint, please contact the manufacturer, TRUE VALUE MFG COMPANY, directly. Refer to the product packaging for contact details or visit their official website.

© 2024 TRUE VALUE MFG COMPANY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B071XWPZQ8

More documents and user manuals: **https://manuals.plus/**