Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ROCK SPACE RAU0567

ROCK SPACE RAU0567 In-Ear Earbuds with Microphone User Manual

Model: RAU0567



Image: Overview of the ROCK SPACE RAU0567 In-Ear Earbuds.

Introduction

Thank you for choosing ROCK SPACE RAU0567 In-Ear Earbuds. This manual provides instructions for proper use, maintenance, and troubleshooting to ensure optimal performance and longevity of your earbuds.

Package Contents

Verify that all items are present in the package:

- ROCK SPACE RAU0567 In-Ear Earbuds
- Extra pairs of silicone ear tips (various sizes)
- Storage bag



Image: Earbuds and accessories, including extra ear tips and a storage bag.

Setup

Selecting Ear Tips

Choose the ear tips that provide the most comfortable and secure fit. A proper seal is essential for optimal sound quality and noise isolation. The earbuds come with medical-grade silicone ear tips in different sizes.



Image: Earbud with extra silicone ear tips for different ear sizes.

Connecting to Device

Insert the 3.5mm audio jack into the headphone port of your smartphone, tablet, MP3 player, or other compatible audio device.

Operating Instructions

The ROCK SPACE RAU0567 earbuds feature an in-line remote control with a microphone, compatible with both iOS and Android operating systems (CTIA international standard interface).



In-line Control

In-line control with integrated Mic supports iPhone and Android (CTIA international standard interface), which control over your calls and music at your fingertips.

Call Control:

Answer/Hang up: short press

Reject: long press

Voice control: long press

Music Control:

Pause/Play: press

Next track: double press

Previous track: triple press

Tips:

1. The control of in-line remote may vary by OS, installed software and areas.
2. The button definition of Android phones is defined by manufacturers, please read the phone manual carefully.

Image: Detailed view of the in-line remote control buttons and microphone.



Image: User holding the in-line remote control.

Call Control

- **Answer/Hang up:** Short press the multifunction button.
- **Reject Call:** Long press the multifunction button.
- **Voice Control:** Long press the multifunction button (activates voice assistant).

Music Control

- **Pause/Play:** Press the multifunction button.
- **Next Track:** Double press the multifunction button.
- **Previous Track:** Triple press the multifunction button.
- **Volume Up:** Press the "Vol+" button.
- **Volume Down:** Press the "Vol-" button.

Note: In-line control functionality may vary depending on the operating system, installed software, and region. For Android phones, button definitions are set by manufacturers; refer to your phone's manual for specific details.

Maintenance

Cleaning

Regularly clean the ear tips with a soft, dry cloth. For deeper cleaning, remove the silicone ear tips and wash them with mild soap and water, then ensure they are completely dry before reattaching. Do not use harsh chemicals or abrasive materials on the earbuds.

Storage

When not in use, store the earbuds in the provided storage bag to protect them from dust, dirt, and tangling. The cable is designed with Kevlar fiber and TPE material for durability and tangle resistance.



Image: Illustration of the durable, tangle-free cable construction.

General Care

- Avoid exposing the earbuds to extreme temperatures, humidity, or direct sunlight.
- Do not pull on the cable to remove the earbuds from your device; always grasp the plug.
- Keep away from sharp objects to prevent damage to the cable or earbud housing.

Troubleshooting

- **No Sound:**
  - Ensure the 3.5mm jack is fully inserted into the device's audio port.
  - Check the volume level on your device.
  - Test with another audio device to rule out device issues.
- **Poor Sound Quality:**
  - Ensure ear tips are properly seated and form a good seal in your ear.
  - Clean ear tips and earbud grilles to remove any debris.
  - Test with another audio source.
- **Microphone Not Working:**
  - Ensure the 3.5mm jack is fully inserted.
  - Check your device's audio settings to ensure the external microphone is selected.
  - Test with another device or application.
- **In-line Remote Not Responding:**
  - Verify compatibility with your device's operating system (iOS/Android CTIA standard).
  - Some functions may be limited or defined differently by specific Android phone manufacturers.

Specifications

Feature	Detail
Model No.	RAU0567
Wearing Style	In-ear
Plug Type	3.5mm Jack
In-line Remote Control	Yes
Driver Diameter	φ10mm
Impedance	32Ω±20%
Frequency Response	20Hz-20kHz
Sensitivity	104dB±3dB
Rated Power	5mW
MIC Directivity	Omnidirectional
MIC Sensitivity	-42±3dB

Materials	Al-alloy, ABS, TPE, Nylon
Cable Length	1200±30mm
Weight	15.3g
Product Dimensions	4.7 x 1.18 x 3.86 inches (packaging)

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official ROCK SPACE website.

© 2023 ROCK SPACE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B071Z6B5V7

More documents and user manuals: **https://manuals.plus/**