Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jimmyjane Ascend 2

JIMMYJANE Ascend 2 Vibrator & Clitoral Stimulator User Manual

Model: Ascend 2

Introduction

The JIMMYJANE Ascend 2 is a rechargeable personal massager designed for sensual pleasure. It features dual powerful motors, multi-speed settings, and a flexible, silky-soft silicone design to provide targeted stimulation. This manual provides essential information for the safe and effective use, care, and maintenance of your Ascend 2.

Safety Information

- **Read all instructions before use.** Keep this manual for future reference.
- **For external use only.**
- **Consult a healthcare professional** if you have any medical conditions or concerns before using this product.
- **Discontinue use immediately** if you experience any discomfort, irritation, or pain.
- **Keep out of reach of children.**
- **Do not use if the product appears damaged.**
- **Use only with water-based lubricants.** Oil-based lubricants may damage the silicone material.

Product Overview

The Ascend 2 features a unique design with two flexible ears, each containing a powerful motor. This allows for versatile positioning and targeted stimulation. The device is made from phthalate-free, latex-free silicone for a silky-soft feel.



Image: The JIMMYJANE Ascend 2 vibrator, showcasing its flexible design and how it can be held for use.




Image: A close-up of the JIMMYJANE Ascend 2 vibrator, demonstrating the pliability of its ears for various positions.

Setup

Charging

Before first use, fully charge your Ascend 2. The device uses a magnetic USB charging cord.

1. Connect the magnetic end of the USB charging cord to the charging port on the Ascend 2.
2. Connect the USB end of the cord to a compatible USB power source (e.g., computer, USB wall adapter).
3. The indicator light on the device will illuminate to show it is charging.
4. Allow approximately **2-3 hours** for a full charge. The indicator light will change or turn off when charging is complete.

Initial Cleaning

Before the first use and after each subsequent use, clean the device thoroughly.

- Wash the device with warm water and a mild, toy-safe soap.
- Rinse thoroughly with clean water.
- Pat dry with a lint-free cloth or allow to air dry completely before storage.

Operating Instructions

The Ascend 2 features intuitive controls for easy operation.




Image: A close-up view of the control panel on the JIMMYJANE Ascend 2 vibrator, showing the power and mode buttons.

Power On/Off

- To turn **ON**: Press and hold the power button (usually the central button) for 2-3 seconds until the device vibrates.
- To turn **OFF**: Press and hold the power button for 2-3 seconds until the device stops vibrating.

Changing Modes and Intensity

The Ascend 2 offers three high-performing vibration modes and three intensity levels.

- While the device is ON, press the**mode button** (often indicated by a wave or pattern icon) to cycle through the different vibration patterns.
- Use the **intensity buttons** (usually '+' and '-' or up/down arrows) to adjust the strength of the vibration within the selected mode.

Travel Lock

The Ascend 2 includes a discretionary travel-lock feature to prevent accidental activation during transport.

- To **activate travel lock**: With the device OFF, press and hold both the power button and the '-' (minus) intensity button simultaneously for 3-5 seconds until the device briefly vibrates or an indicator light flashes.
- To **deactivate travel lock**: Press and hold both the power button and the '+' (plus) intensity button simultaneously for 3-5 seconds until the device briefly vibrates or an indicator light flashes, indicating it is ready for use.

Maintenance

Cleaning

Regular cleaning ensures hygiene and prolongs the life of your device.

- Clean the device before and after each use.
- Wash with warm water and a mild, toy-safe soap.
- Rinse thoroughly and pat dry with a lint-free cloth.
- Do not use harsh chemicals, alcohol, or petroleum-based cleaners, as these can damage the silicone.

Storage

- Store the Ascend 2 in a clean, dry place, away from direct sunlight and extreme temperatures.
- Keep it separate from other toys made of different materials to prevent material degradation.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; Travel lock activated.	Charge the device fully; Deactivate travel lock (refer to Operating Instructions).

Problem	Possible Cause	Solution
Device does not charge.	Charging cable not properly connected; Faulty power source.	Ensure magnetic cable is securely attached; Try a different USB port or power adapter.
Vibrations are weak or inconsistent.	Low battery.	Recharge the device.

Specifications

Feature	Detail
Brand	Jimmyjane
Model	Ascend 2
Material	Silicone (Phthalate-free, Latex-free)
Motors	Dual motors
Vibration Modes	3 modes
Intensity Levels	3 levels
Charging	Magnetic USB charging cord
Water Resistance	Waterproof
Product Care	Hand Wash
Approx. Dimensions	10.24 x 3.98 x 2.52 inches
Approx. Weight	14.89 ounces
Manufacturer	JIMMYJANE, Inc.

Warranty and Support

Specific warranty details for the JIMMYJANE Ascend 2 are not provided in this manual. For information regarding warranty coverage, product support, or to contact customer service, please visit the official JIMMYJANE website or refer to the product packaging.

Official Website: Visit the Jimmyjane Store on Amazon

© 2026 JIMMYJANE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B073FQ6XTD

More documents and user manuals: **https://manuals.plus/**