Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BLOSSOMZ BLZ-39980

BLOSSOMZ Dual Fuel Combination Charcoal/Gas Grill

MODEL: BLZ-39980

Brand: BLOSSOMZ

Introduction

The BLOSSOMZ Dual Fuel Combination Charcoal/Gas Grill, Model BLZ-39980, offers the versatility of both gas and charcoal grilling in one unit. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your grill. Please read all instructions carefully before assembly and use.

Setup

Assembly

While the product is listed as 'Assembly Required: No', some initial setup may be necessary. Ensure all components are present and undamaged upon receipt. Refer to the included diagrams for proper placement of shelves and other accessories.

Connecting the LP Tank

The LP (Liquid Propane) tank is not included with the grill. Connect your standard LP tank to the designated hose and regulator. Ensure all connections are tight and check for leaks using a soapy water solution before first use. The LP tank is designed to be stored securely on the bottom shelf of the grill.

Mobility

The grill is equipped with 2 wheels for easy mobility. Position the grill on a flat, stable surface away from combustible materials.

Operating Instructions

Gas Grill Operation

1. Ensure the LP tank is connected and the gas supply is open.
2. Open the grill lid.
3. Push and turn a control knob to the 'HIGH' position. The integrated ignition system will light the burner.
4. If the burner does not ignite within 5 seconds, turn the knob to 'OFF', wait 5 minutes, and repeat the lighting procedure.
5. Adjust the rubber grip control knobs to achieve your desired cooking temperature. The gas side features 3 stainless steel tube burners, providing a total of 24,000 BTUs.

Charcoal Grill Operation

1. Open the charcoal grill lid.
2. Place charcoal briquettes or lump charcoal into the charcoal tray.
3. Ignite the charcoal using a charcoal starter or appropriate method.
4. Once the charcoal is ready, use the adjustable crank handle on the front to raise or lower the charcoal tray, controlling the heat intensity.
5. Utilize the front door for easy access to add more charcoal during grilling.

Side Burner Operation

The side burner is ideal for sautéing vegetables, boiling water, or preparing sauces while your main dishes grill. To operate, open the side burner lid, push and turn the control knob to 'HIGH' to ignite, and adjust the flame as needed.

Temperature Control & Cooking Surface

Both the gas and charcoal sides are equipped with lid thermometers to monitor internal temperatures. Adjust the top vents on the charcoal side to regulate airflow and heat. The grill offers a total cooking space of 557 sq. inches (262 charcoal, 295 gas) with durable porcelain-enameled cast iron cooking grids. An additional 188 sq. inches of warming rack space (89 charcoal, 99 gas) is available for keeping food warm.

Maintenance

Cleaning Cooking Grids

After each use, once the grill has cooled, clean the porcelain-enameled cast iron cooking grids with a grill brush. For stubborn residue, use warm soapy water.

Grease Management

The grill features a removable grease tray and grease cup located at the back for easy cleaning. Regularly check and empty these components to prevent grease buildup and potential flare-ups.

Ash Removal

For the charcoal side, a removable ash tray is provided for convenient disposal of ashes once completely cooled.

Troubleshooting

- **Assembly Difficulty:** While listed as 'No Assembly Required', some users have reported the assembly process can

be lengthy. Carefully review all instructions and diagrams. Ensure all parts are accounted for before starting.

- **Burners Not Lighting:** Check that the LP tank is properly connected and the gas supply valve is fully open. Ensure the control knob is pushed in before turning to 'HIGH' for ignition.
- **Uneven Heating:** For charcoal grilling, adjust the charcoal tray height and top vents to control heat distribution. For gas grilling, ensure all burners are clean and free of debris.
- **Damaged Parts:** If any parts are bent or damaged upon arrival, contact the manufacturer for replacements before attempting assembly or use.

Specifications

Brand	BLOSSOMZ
Model Name	BLZ-39980
Product Dimensions	64"D x 28"W x 49.75"H
Item Weight	103 Pounds
Fuel Type	Charcoal, Gas
Main Burner Count	3 (Gas Side)
Side Burner Count	1
Heating Power (Gas)	24,000 BTUs (Total for 3 burners)
Cooking Surface Area	557 Square Inches (Total)
Warming Rack Space	188 Square Inches (Total)
Material	Alloy Steel
Finish Type	Painted
Special Feature	Rust Resistant
UPC	647731345613

Product Media

Images



Front view of the BLOSSOMZ Dual Fuel Combination Charcoal/Gas Grill, showcasing both gas and charcoal sections.



Top-down view of the grill with both lids open, revealing the cooking grates and warming racks.



Front view of the grill with both lids closed, highlighting the stainless steel control panel and handles.



Diagram showing the dimensions of the grill: 64 inches deep, 28 inches wide, and 49.75 inches high.

Videos

▶ **Watch video online**

Charcoal & Gas Grill Combo Customer Brief Introduction

Official seller video providing a brief introduction to the Charcoal & Gas Grill Combo, highlighting its features and dual-fuel capabilities.

Warranty and Support

For warranty information, product support, or to order replacement parts, please refer to the contact details provided in your product packaging or visit the official BLOSSOMZ website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B073Q37CQV

More documents and user manuals: **https://manuals.plus/**