Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER SDVD7002, SDVD7002B

PKPOWER AC Adapter User Manual

For Sylvania SDVD7002 and SDVD7002B Portable DVD Players

1. Introduction

This manual provides essential instructions for the safe and effective use of your PKPOWER AC Adapter. This adapter is designed to provide power to compatible Sylvania portable DVD players, specifically models SDVD7002 and SDVD7002B. Please read this manual thoroughly before use and retain it for future reference.

2. Product Overview

The PKPOWER AC Adapter is a reliable power supply unit designed for specific portable electronic devices. It converts standard AC wall power into the DC power required by your device, ensuring stable and consistent operation.



Figure 2.1: PKPOWER AC Adapter and integrated power cord.

Key Features:

- **Input:** 100-240V AC, 50-60Hz (Universal compatibility for various regions).
- **Output:** Designed to match the power requirements of Sylvania SDVD7002 and SDVD7002B.
- **Safety Certifications:** CE, FCC, RoHS certified.
- **Protection Features:** Over Voltage Protection (OVP), Over Current Protection (OCP), Short Circuit Protection (SCP).

3. Setup Instructions

Follow these steps to properly connect and use your AC adapter:

1. **Verify Compatibility:** Ensure your device is a Sylvania SDVD7002 or SDVD7002B portable DVD player. Using this adapter with incompatible devices may cause damage.
2. **Connect to Device:** Locate the DC input port on your Sylvania portable DVD player. Carefully insert the adapter's output connector into this port. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the AC adapter's prongs into a standard wall power outlet (100-240V AC).
4. **Power On Device:** Once connected, you can power on your portable DVD player. The adapter will supply the necessary power for operation and charging (if applicable).

Important: Always ensure the adapter is securely connected to both the device and the power outlet before use.

4. Operating Instructions

Once the PKPOWER AC Adapter is connected as described in the Setup section, it will automatically provide power to your Sylvania portable DVD player. No further user interaction is required for the adapter's operation.

- The adapter is designed for continuous use within its specified operating parameters.
- If your portable DVD player has a charging function, the adapter will facilitate battery charging while connected and the device is powered off or in standby mode.

5. Maintenance

To ensure the longevity and proper functioning of your PKPOWER AC Adapter, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires, bent prongs, or cracks in the casing. If damage is observed, discontinue use immediately and replace the adapter.

Caution: Do not attempt to open or repair the adapter. This may void the warranty and poses a safety risk.

6. Troubleshooting

If you encounter issues with your PKPOWER AC Adapter, consider the following troubleshooting steps:

- **No Power to Device:**
  - Ensure the adapter is firmly plugged into a working wall outlet. Test the outlet with another device.
  - Verify the adapter's connector is securely inserted into the portable DVD player's DC input port.
  - Check the adapter cable for any visible damage.
- **Device Not Charging:**
  - Confirm the portable DVD player's charging indicator (if present) is active.
  - Ensure the device is powered off or in standby mode, as some devices charge slower or not at all when in active use.
  - The issue might be with the device's battery or charging circuit, not the adapter.

- **Adapter Overheating:**
  - A slight warmth is normal during operation. However, if the adapter becomes excessively hot to the touch, disconnect it immediately.
  - Ensure the adapter is not covered or placed in an area with poor ventilation.
  - Verify that the adapter is being used with a compatible device and not overloaded.

If these steps do not resolve the issue, please contact customer support.

7. Specifications





Figure 7.1: Adapter label with technical specifications.

Specification	Detail
Brand	PKPOWER
Input Voltage	100-240V AC
Input Frequency	50/60Hz
Output Voltage	Matches Sylvania SDVD7002/SDVD7002B requirements
Connector Type	Auxiliary (specific to compatible devices)
Compatible Devices	Sylvania SDVD7002, Sylvania SDVD7002B Portable DVD Players
Safety Certifications	CE, FCC, RoHS
Protection Features	OVP, OCP, SCP
Color	Black



Figure 7.2: Approximate dimensions of the PKPOWER AC Adapter.

8. Warranty and Support

PKPOWER products are manufactured to high standards. For any inquiries or assistance, our customer service team is available to help. We aim to respond to all customer service requests within 24 hours.
For support, please refer to the contact information provided with your purchase or visit the official PKPOWER website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B073Z54VFB

More documents and user manuals: **https://manuals.plus/**