Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PaperPlanet ABZKIT

Paper Planet Thermal Paper Instruction Manual

For Clover Mini POS Systems (Models C200, C300, C301, C302, C305)

1. Introduction

This manual provides essential information for the proper use and maintenance of Paper Planet Thermal Paper. Our thermal paper is specifically designed to deliver clean, smudge-free printing for your business needs. It is compatible with various Clover Mini and Clover Mobile Point of Sale (POS) systems.
Each roll is manufactured to high standards, ensuring reliable performance and features a low-paper warning mark to prevent unexpected runouts.



Image: Packaging for Paper Planet thermal paper, highlighting compatibility with Clover Mini.

2. Compatibility

Paper Planet Thermal Paper (Model ABZKIT) is guaranteed to fit and function correctly with the following Clover Mini and Clover Mobile POS system models:

- Clover Mini C200
- Clover Mini C300
- Clover Mini C301
- Clover Mini C302
- Clover Mini C305



Image: A Clover Mini POS system, demonstrating the type of device this paper is compatible with.

3. Setup Instructions

3.1 Loading Thermal Paper into Clover Mini

Follow these steps to correctly load a new roll of Paper Planet Thermal Paper into your Clover Mini POS system:

1. **Open the Printer Door:** Locate the printer compartment on your Clover Mini device and open its door.
2. **Remove Previous Core:** If a roll was previously installed, remove any remaining paper and the empty core.
3. **Place New Roll:** Insert the new Paper Planet thermal paper roll into the compartment. Ensure the paper feeds over itself and towards the top of the device. The leading edge of the paper should come out of the top slot.
4. **Close Printer Door:** Close the printer door securely.
5. **Tear Off Excess:** Gently tear off any excess paper extending from the printer slot.

For a visual guide, please refer to the video below:

▶ **Watch video online**
Thermal Paper for Clover Mini

Video: Demonstrates the process of loading thermal paper into a Clover Mini device.



Image: A thermal paper roll featuring the pink warning stripe, indicating low paper levels.

4. Operation

4.1 General Usage

Once loaded, the Paper Planet Thermal Paper is ready for use with your Clover Mini system. The heat-sensitive coating ensures that your receipts are printed clearly and without smudges, providing a professional appearance for every transaction.

Pay attention to the **pink warning mark** near the end of each roll. This visual cue indicates that the paper supply is running low, allowing staff to replace the roll proactively and avoid interruptions during sales.



Image: Illustrates the heat-sensitive and bright white qualities of the thermal paper.

5. Maintenance and Storage

To ensure the longevity and quality of your Paper Planet Thermal Paper, please adhere to the following storage guidelines:

- Store paper rolls in a **cool, dark place**.
- Avoid direct exposure to **sunlight or excessive heat**, as this can prematurely activate the thermal coating and fade prints.
- Prevent contact with **oil, plastics, chemicals, and fat**, which can degrade the paper quality and print clarity.

6. Troubleshooting

Here are some common issues and their potential solutions:

- **Faded or Unclear Prints:**
  - Check if the paper roll is loaded correctly with the thermal side facing the print head.
  - Ensure the paper has been stored properly (cool, dark place, away from chemicals).
  - Clean the printer's thermal print head according to your Clover Mini's maintenance instructions.
- **Paper Jams:**
  - Verify that the paper roll is the correct size (2.25 inches / 57mm) and fits loosely in the compartment.
  - Remove any torn or crumpled paper from the printer path.
  - Ensure the printer door is fully closed.
- **Paper Not Feeding:**
  - Confirm the paper roll is not empty. Look for the pink warning mark.
  - Ensure the leading edge of the paper is properly inserted into the feed mechanism.

7. Product Specifications

Feature	Detail
Brand	PaperPlanet
Item Model Number	ABZKIT
Material Type	Paper
Color	White
Number of Items	8 Rolls (for this specific product variant)
Sheet Size	2.25 inches (57mm)
Brightness Rating	100
Paper Weight	20
Paper Finish	Smooth
Item Weight	1.54 pounds (approx. 0.7 kg)
Package Dimensions	6.89 x 5.59 x 2.48 inches

8. Warranty Information

Specific warranty details for Paper Planet Thermal Paper are not provided in the product information. For any warranty-related inquiries, please contact Paper Planet customer support directly.

9. Customer Support

For further assistance, questions, or to explore other Paper Planet products, please visit the official Paper Planet Store on Amazon:

Visit the Paper Planet Store

© 2025 Paper Planet. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0746T6XD4

More documents and user manuals: **https://manuals.plus/**