Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER ATV1900AC, ATV585, ATV585-B, ATV586, ATV320

PK Power AC Adapter User Manual

For Mygica ATV1900AC, ATV585, ATV585-B, ATV586, ATV320 Enjoy TV Box

Introduction

This manual provides essential instructions for the safe and effective use of your PK Power AC Adapter. Please read this manual thoroughly before using the product and retain it for future reference. This adapter is designed to provide reliable power to compatible Mygica ATV series TV boxes.

Product Overview

The PK Power AC Adapter is a replacement power supply unit (PSU) designed for specific Mygica ATV series TV boxes. It features a compact design and is built to meet or exceed OEM specifications, ensuring compatibility and reliable performance.



Image 1: Front view of the PK Power AC Adapter, showing the two-prong US-style plug and the DC barrel connector.

Key features include:

- **Wide Input Voltage:** Supports 100-240V AC, 50-60Hz, making it suitable for international travel with appropriate plug adapters.
- **Safety Certifications:** CE, FCC, and RoHS certified, indicating compliance with health, safety, and environmental protection standards.
- **Advanced Protection:** Equipped with Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.



Image 2: Side view of the PK Power AC Adapter, illustrating the compact design and the attached power cable.

Setup Instructions

1. **Verify Compatibility:** Ensure your Mygica TV Box model is listed as compatible with this adapter (e.g., ATV1900AC, ATV585, ATV585-B, ATV586, ATV320).
2. **Connect to Device:** Insert the DC barrel connector of the AC adapter firmly into the power input port of your Mygica TV Box.
3. **Connect to Power Outlet:** Plug the two-prong AC plug of the adapter into a standard wall power outlet (100-240V AC).
4. **Power On:** Once connected, your Mygica TV Box should receive power. Refer to your TV Box's manual for specific power-on procedures.

Important: Always ensure the adapter is securely connected to both the device and the power outlet before use.

Operating Instructions

The PK Power AC Adapter operates automatically once connected. It converts the alternating current (AC) from your wall outlet into the direct current (DC) required by your Mygica TV Box.

- No user intervention is required for the adapter's operation after proper setup.
- The adapter is designed for continuous use within its specified operating parameters.
- If you need to disconnect power, always unplug the adapter from the wall outlet first, then disconnect from

the device.

Maintenance

To ensure the longevity and proper functioning of your AC adapter, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the cable and connectors for any signs of damage, such as fraying, cuts, or bent pins. If damage is observed, discontinue use immediately.

Troubleshooting

If you encounter issues with your PK Power AC Adapter, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Device not powering on.	• Adapter not properly plugged into wall outlet. • Adapter not properly connected to the device. • Wall outlet is not functioning. • Adapter or device malfunction.	• Ensure the adapter is fully inserted into the wall outlet. • Ensure the DC connector is firmly seated in the device's power port. • Test the wall outlet with another known working appliance. • Try a different compatible adapter if available. If the issue persists, the device may be faulty.
Adapter feels unusually hot.	• Overload or poor ventilation. • Internal fault.	• Ensure the adapter is not covered and has adequate airflow. • Disconnect immediately and discontinue use. Contact support.
Visible damage to cable or connector.	Physical wear and tear.	Discontinue use immediately to prevent electrical hazards. Replace the adapter.

Specifications

Brand	PKPOWER
Model Compatibility	Mygica ATV1900AC, ATV585, ATV585-B, ATV586, ATV320 Enjoy TV Box
Input Voltage	100-240V AC
Input Frequency	50-60Hz
Connector Type	Auxiliary (DC Barrel)
Main Power Connector Type	2 Pin (US Standard)
Color	Black

Certifications	CE, FCC, RoHS
Special Feature	Travel-friendly design

Safety Information

Please observe the following safety precautions to prevent injury or damage to the product and connected devices:

- Do not expose the adapter to water, moisture, or extreme temperatures.
- Do not disassemble or attempt to repair the adapter. Refer all servicing to qualified personnel.
- Ensure the adapter is used with devices that match its voltage and current specifications.
- Avoid placing the adapter in areas with poor ventilation, as this can lead to overheating.
- Keep out of reach of children.
- Unplug the adapter during lightning storms or when unused for long periods.

Warning: This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

Warranty and Support

PK-Power products are designed for reliability and performance. For any inquiries or assistance, our customer service team is available to help.

- **Customer Service:** Our friendly and reliable customer service will respond to you within 24 hours.
- For support, please refer to the contact information provided with your purchase or visit the official PKPOWER website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074DQL49P

More documents and user manuals: **https://manuals.plus/**