Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CubicFun 771DS0978

CubicFun 3D Puzzle UK Tower Bridge Instruction Manual

This manual provides detailed instructions for the assembly, usage, and maintenance of your CubicFun 3D Puzzle UK Tower Bridge. Please read carefully before beginning assembly.

1. Product Overview

The CubicFun 3D Puzzle UK Tower Bridge is a detailed architectural model designed for assembly. It consists of 120 pieces made from EPS foam, offering a challenging yet rewarding building experience for individuals aged 10 and above. Once completed, the model serves as a unique decorative piece.



This image shows the assembled CubicFun 3D Puzzle of the UK Tower Bridge alongside its instruction booklet. The puzzle features intricate details of the bridge's architecture, including its towers, suspension cables, and roadway, all set on a blue base representing water. The instruction booklet, titled 'Londres London', is visible to the left.



A close-up view of the assembled CubicFun 3D Tower Bridge puzzle, showcasing its detailed architectural replication. The bridge stands prominently against a blurred background, emphasizing its design and scale.

2. Components

Your CubicFun 3D Puzzle package should contain the following:

- 120 x EPS Foam Puzzle Pieces
- 1 x Instruction Booklet (with illustrated steps)



This image illustrates the ease of assembly with a diagram showing numbered puzzle pieces and an open instruction booklet. It highlights that the puzzle consists of 120 pieces, is suitable for ages 10+, and takes approximately 2+ hours to complete.

3. Setup and Assembly

Follow these steps to assemble your CubicFun 3D Puzzle:

1. **Unpack Components:** Carefully remove all puzzle sheets and the instruction booklet from the packaging.
2. **Familiarize Yourself:** Review the instruction booklet thoroughly. Identify the different sheets and the numbering system for the pieces.
3. **Punch Out Pieces:** Gently punch out the puzzle pieces from their foam sheets. Be careful not to bend or tear the tabs.
4. **Follow Numbered Steps:** The instruction booklet provides a step-by-step guide with illustrations. Assemble the pieces according to the numbered sequence. Pay close attention to the orientation and connection

points.

5. **Connect Carefully:** When connecting pieces, ensure the tabs align correctly with the slots. Avoid forcing pieces, as this may damage them. If a piece doesn't fit, re-check the numbering and orientation.
6. **Complete Sections:** Assemble the model section by section as indicated in the instructions. This often involves building the base, then the towers, and finally connecting elements like the roadway and suspension cables.
7. **Final Touches:** Once all pieces are connected, gently press down on the assembled model to ensure all connections are secure.

Tip: Planning the assembly carefully and understanding how parts fit together can prevent bending of the paper tabs. Refer to the detailed diagrams in the booklet for guidance.



An image depicting an adult and a child collaboratively assembling the CubicFun 3D Tower Bridge puzzle. They are focused on connecting pieces, highlighting the engaging and educational aspect of the activity.

4. Usage

The assembled CubicFun 3D Puzzle UK Tower Bridge is intended for display purposes. It can be placed on a desk, shelf, or any flat surface as a decorative item. It is not designed for active play or repeated disassembly and reassembly, as this may weaken the connections and damage the pieces.



The completed CubicFun 3D Tower Bridge puzzle displayed as a decorative item on a coffee table, alongside a cup of coffee and books. This illustrates its use as a unique centerpiece for home or office.

5. Maintenance

To ensure the longevity and appearance of your 3D puzzle:

- **Cleaning:** Dust the model regularly with a soft, dry cloth or a soft brush. Avoid using wet cloths or cleaning

agents, as they may damage the EPS foam material or the printed surface.

- **Storage:** Keep the assembled model in a dry environment, away from direct sunlight and extreme temperatures, which can cause fading or warping.
- **Handling:** Handle the model with care, especially when moving it, to prevent accidental damage to delicate parts.

6. Troubleshooting

Here are some common issues and their solutions:

- **Pieces Don't Fit:** Double-check the piece number and the corresponding slot in the instruction booklet. Ensure the orientation is correct. Do not force pieces.
- **Tabs Bending:** If tabs bend during assembly, gently straighten them. Ensure you are aligning them precisely before applying pressure. Planning the assembly sequence can help prevent this.
- **Missing Pieces:** While rare, if you believe a piece is missing, carefully re-check all sheets and the packaging. If still missing, contact CubicFun customer support (see Section 8).
- **Model Instability:** Ensure all connections are fully engaged. Gently press down on the entire model to secure any loose joints.

7. Specifications

Feature	Detail
Brand	CubicFun
Model Number	771DS0978
Product Dimensions (L x W x H)	21.5 x 17.5 x 0.25 cm (packaging); Assembled: 79.5 x 17.5 x 21.5 cm
Weight	558 grams
Recommended Age	10 years and up (120 months)
Educational Value	Problem-solving ability
Number of Pieces	120
Assembly Time (Approx.)	2+ hours
Material	EPS Foam
Color	Multicolor
Number of Players	1 or 2



This image displays the key dimensions of the assembled CubicFun 3D Tower Bridge puzzle, indicating its length (79.5 cm / 31.3 inches), width (17.5 cm / 6.89 inches), and height (21.5 cm / 8.46 inches).

8. Warranty and Support

CubicFun is committed to providing high-quality products. For any questions, concerns, or support regarding your 3D puzzle, please refer to the contact information provided on the product packaging or the official CubicFun website. While specific warranty details are not provided in this manual, standard consumer rights apply. Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074NWSRBR

More documents and user manuals: **https://manuals.plus/**