Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire EFIC115

Frigidaire EFIC115 Extra Large Ice Maker User Manual

Model: EFIC115 | Brand: Frigidaire

Introduction

This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your Frigidaire EFIC115 Extra Large Ice Maker. Please read this manual thoroughly before using the appliance and retain it for future reference.

The Frigidaire EFIC115 is a countertop ice maker designed to produce up to 48 pounds of bullet-shaped ice per day. It features a 5-liter water reservoir, a transparent viewing window, and indicator lights for water levels and ice fullness. The unit offers three ice cube size options and includes an external drain for excess water, a removable ice tray, and an ice shovel.

Important Safety Information

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Ensure the appliance is connected to a properly grounded power outlet.
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use the appliance for other than its intended use.
- This ice maker is designed to produce ice, not store it. The unit does not keep ice frozen once it's made. To prevent melting, transfer the ice to your freezer promptly after it is produced.

What's in the Box

Upon unpacking, please ensure all items listed below are present and in good condition:

- Frigidaire EFIC115 Ice Maker Unit
- Ice Shovel
- Removable Ice Basket



Image: The Frigidaire EFIC115 Ice Maker, shown with a full ice basket and the accompanying ice shovel. The unit is stainless steel with a black lid and control panel.

Product Overview and Features

The Frigidaire EFIC115 Ice Maker is designed for convenience and efficiency. Key features include:

- **Extra Large Capacity:** Produces up to 48 pounds of ice in 24 hours.
- **Fast Ice Production:** Makes ice in less than 7 minutes, with options for three different ice cube sizes (Small, Medium, Large).
- **5-Liter Water Reservoir:** Large capacity for extended operation.

- **Transparent Viewing Window:** Allows monitoring of ice production without opening the lid.
- **Intuitive Digital LED Control Panel:** Features indicator lights for "Add Water" and "Ice Full" notifications, and buttons for power and ice size selection.
- **Removable Ice Basket:** Holds up to 2.6 pounds of ice.
- **External Drain Plug:** For easy water drainage and cleaning.



Image: Front view of the Frigidaire EFIC115 Ice Maker, highlighting its large countertop design and stainless steel finish.



Image: The Frigidaire EFIC115 Ice Maker with its lid open, showing the stylish viewing window, the drain plug for easy cleaning, and the large 2.6 lbs ice basket with an ice scoop.



Image: A close-up of the intuitive digital LED control panel on the Frigidaire EFIC115 Ice Maker. It displays indicators for "Ice Full" and "Add Water," along with buttons to select ice cube sizes (S, M, L) and power.

Setup Instructions

1. **Unpack the Appliance:** Carefully remove all packaging materials and check for any damage. Ensure all accessories (ice shovel, ice basket) are present.
2. **Clean the Appliance:** Before first use, clean the interior and exterior of the ice maker as described in the "Maintenance" section.
3. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit (at least 4 inches of space on all sides).
4. **Allow to Rest:** After transportation, allow the ice maker to stand upright for at least 1 hour before plugging it in. This allows the refrigerant to settle.
5. **Connect Power:** Plug the ice maker into a grounded electrical outlet.

Operating Instructions

1. **Add Water:** Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
2. **Power On:** Press the "Power" button on the control panel to turn on the ice maker. The power indicator light will illuminate.
3. **Select Ice Size:** Press the "Select" button to choose your desired ice cube size: Small (S), Medium (M), or Large (L). The corresponding indicator light will illuminate. For the first cycle, it is recommended to select a larger size.
4. **Ice Production:** The ice maker will begin the ice-making cycle. The first batch of ice may take slightly longer (approximately 7-11 minutes depending on selected size and ambient temperature). Subsequent cycles will be faster.
5. **Monitor Ice Level:** The "Ice Full" indicator light will illuminate when the ice basket is full. The ice maker will automatically pause production. Remove ice from the basket to resume production.
6. **Add Water Indicator:** If the "Add Water" indicator light illuminates, the water reservoir is low. Add more water to continue ice production.
7. **Storing Ice:** This appliance is designed to produce ice, not to store it. For best results, transfer freshly made ice to a freezer for long-term storage.
8. **Power Off:** Press the "Power" button to turn off the ice maker when not in use or when the desired amount of ice has been produced.



Image: A hand using the provided ice scoop to retrieve bullet-shaped ice from the Frigidaire EFIC115 Ice Maker's basket. The control panel is visible, indicating the unit is in operation.

Care and Maintenance

Cleaning the Ice Maker

1. **Before Cleaning:** Always unplug the appliance from the power outlet before cleaning.
2. **Drain Water:** Locate the drain plug at the bottom or side of the unit. Place a basin underneath and remove the plug to drain all water from the reservoir. Once drained, replace the plug securely.
3. **Clean Interior:** Remove the ice basket. Clean the interior of the ice maker, including the water reservoir and ice-making components, with a soft cloth dampened with a mild detergent solution. Rinse thoroughly with clean water.
4. **Clean Exterior:** Wipe the exterior of the ice maker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
5. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling and storing or using the appliance.

Storage

If the ice maker will not be used for an extended period, drain all water, clean the unit thoroughly, and allow it to dry completely. Store the appliance in a cool, dry place.

Troubleshooting Guide

Before contacting customer service, please refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
Ice maker does not turn on.	No power supply.	Check if the power cord is securely plugged into a grounded outlet. Check the circuit breaker.
"Add Water" indicator light is on.	Water reservoir is empty or low.	Fill the water reservoir with potable water up to the MAX fill line.
"Ice Full" indicator light is on.	Ice basket is full.	Remove ice from the basket. The ice maker will resume production automatically.
Ice production is slow or ice cubes are small/misshapen.	Ambient temperature is too high; water temperature is too high; unit needs cleaning.	Ensure the unit is in a cool environment. Use cold water. Clean the ice maker as per maintenance instructions.
Water leaks from the unit.	Drain plug is not securely closed; internal component issue.	Ensure the drain plug is firmly in place. If leaking persists, contact customer support.

Specifications

- **Model Number:** EFIC115
- **Brand:** Frigidaire
- **Product Dimensions (D x W x H):** 14.96" x 17.3" x 16.96"
- **Weight:** Approximately 35.26 Pounds
- **Ice Production Capacity:** Up to 48 lbs per 24 hours
- **Water Reservoir Capacity:** 5 Liters (approx. 4.7 Quarts)
- **Ice Basket Capacity:** Up to 2.6 lbs
- **Wattage:** 130 watts
- **Manufacturer:** CURTIS INTERNATIONAL LTD



Frigidaire is a pending or registered trademark of Electrolux Home Products and used under license from Electrolux Home Products, Inc.

Image: Diagram showing the dimensions of the Frigidaire EFIC115 Ice Maker: 14.96 inches deep, 17.13 inches wide, and 16.97 inches high. Note: The product specifications state 17.3"W and 16.96"H.

Warranty and Customer Support

For warranty information or technical assistance, please contact the manufacturer, CURTIS INTERNATIONAL LTD, or refer to the warranty card included with your product. Keep your purchase receipt as proof of purchase for warranty claims.

For additional support, you may visit the official Frigidaire website or contact their customer service department.

© 2023 Frigidaire. All rights reserved. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075CPXP1H

More documents and user manuals: **https://manuals.plus/**