Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic CN-RA04D

Panasonic Car Navigation Strada CN-RA04D User Manual

Model: CN-RA04D | Brand: Panasonic

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your Panasonic Car Navigation Strada CN-RA04D system. Please read this manual thoroughly before using the product to ensure safe and efficient operation. Keep this manual in a safe place for future reference.

2. Setup

2.1. Unpacking and Component Check

Carefully unpack all components and verify that all items listed in the packaging contents are present. The main unit, GPS antenna (4m cable), and necessary mounting hardware should be included.

2.2. Installation

The CN-RA04D is designed for dashboard mounting and has a standard 180mm mounting size. Professional installation is recommended to ensure correct wiring and secure mounting. Connect the GPS antenna to the designated port on the main unit and position it in a location with a clear view of the sky for optimal signal reception. Ensure all power and speaker cables are connected according to the vehicle's wiring diagram and the product's installation guide.

2.3. Initial Power-On and Basic Settings

After installation, turn on your vehicle's ignition. The unit will power on. Follow the on-screen prompts to complete initial setup, including language selection, time zone, and basic navigation preferences. Refer to the detailed installation manual for specific wiring instructions and safety precautions.

3. Operating Instructions

3.1. Screen Operation

The unit features a 7V type wide pressure-sensitive touch panel. Operate the system by gently pressing the desired icons or menu options on the screen. Avoid using sharp objects that could damage the display.

3.2. Navigation Features

The CN-RA04D provides detailed map guidance with a clear, real-time display. Key features include:

- **Route Guidance:** Follow on-screen directions and voice prompts for optimal routes.
- **VICS WIDE:** Receive real-time traffic information and weather updates to avoid congestion.
- **Wrong-Way Driving Alert:** The system issues alerts if it detects the vehicle is traveling in the wrong direction on certain roads.
- **Lane Guidance:** Visual cues assist in selecting the correct lane for turns and exits.



This image displays the advanced navigation features of the CN-RA04D. It shows how the system provides estimated travel times for different turns at an intersection (e.g., 60 seconds for a right turn, 5 seconds for straight, 10 seconds for a left turn). Additionally, it illustrates lane guidance with color-coded traffic conditions for specific intersection lanes, helping drivers navigate complex junctions more effectively.

3.3. Media Playback

The unit supports various media formats:

- **SD Card:** Insert an SD card (up to 16GB) into the designated slot for music or video playback.
- **CD/DVD:** Insert audio CDs or video DVDs into the disc slot.
- **USB:** Connect USB devices for media playback.
- **Bluetooth:** Pair your smartphone or other Bluetooth-enabled devices for audio streaming and hands-free calling.

3.4. Map Updates

The system comes with August 2017 map data and includes one free map update within three years of purchase. Map updates can be performed using NaviCon smartphone linking. Refer to the Panasonic website or the full instruction manual for detailed procedures on how to download and install map updates.



This diagram illustrates the sophisticated signal processing within the CN-RA04D. It features four tuners (Tuner 1-4) that cover nearly all directions around the vehicle, constantly capturing radio waves. These signals undergo Fast Fourier Transform (FFT) processing and are then synthesized. The system automatically corrects data degradation. A high-quality decode circuit, the 'PEAKS Processor,' reproduces high-definition images, ensuring stable reception and superior audio-visual performance.

4. Maintenance

4.1. Cleaning the Screen

To clean the touch screen, gently wipe it with a soft, dry cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaner. Avoid abrasive materials or harsh chemicals, which can damage the screen surface.

4.2. General Care

Keep the unit free from dust and extreme temperatures. Ensure proper ventilation around the unit to prevent overheating. Do not attempt to disassemble or repair the unit yourself, as this will void the warranty and may cause damage.

5. Troubleshooting

If you encounter issues with your CN-RA04D, refer to the following common troubleshooting tips. For more detailed solutions, consult the comprehensive user manual or contact customer support.

5.1. No Power

- Check all power connections and fuses.
- Ensure the vehicle's ignition is on.

5.2. No GPS Signal

- Ensure the GPS antenna has a clear view of the sky and is not obstructed.
- Verify the GPS antenna cable is securely connected.

5.3. Touch Screen Unresponsive

- Perform a soft reset (refer to the full manual for instructions).
- Ensure the screen is clean and free from debris.

5.4. Audio Problems

- Check speaker connections.
- Adjust volume settings.
- Ensure the correct audio source is selected.

6. Specifications

Feature	Specification
Model Name	CN-RA04D
Screen Size	7V Type Wide
Screen Resolution	WVGA (1,152,000 pixels: vertical 480 × horizontal 800 × 3)
Screen Operation	Pressure-sensitive touch panel

Memory	SD16G
Map Data Version	August 2017
Map Update	1 free update within 3 years
Smartphone Link	NaviCon
Connectivity	Bluetooth
Special Features	VICS/VICS WIDE, Hands-free
Product Dimensions (W×H×D)	177 mm × 82 mm × 157 mm (excluding protrusions)
Mounting Depth	165 mm
Weight	Approx. 2.5 kg
Mounting Type	Dashboard Mount
Included Components	GPS Antenna (4m)

7. Warranty and Support

Your Panasonic Car Navigation Strada CN-RA04D comes with a standard manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions. For technical assistance, service, or further inquiries, please contact Panasonic customer support. Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075CRX5C2

More documents and user manuals: **https://manuals.plus/**