Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC Adapter for HP DeskJet D2460 D4260 D1460 D2430 D2445

PK Power AC Adapter User Manual

For HP DeskJet D2460, D4260, D1460, D2430, D2445 Printers

1. Introduction

This manual provides essential information for the safe and effective use of your PK Power AC Adapter. Please read these instructions carefully before using the product to ensure proper functionality and to prevent damage to the adapter or your connected devices. This adapter is specifically designed for use with HP DeskJet D2460, D4260, D1460, D2430, and D2445 series printers.

2. Safety Information

To prevent electric shock, fire, or damage to the product, please observe the following safety precautions:

- Ensure the adapter is connected to a power outlet with the correct voltage (100-240V).
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open or repair the adapter. Refer all servicing to qualified personnel.
- Disconnect the adapter from the power outlet when not in use for extended periods.
- The adapter features OVP (Over Voltage output Protection), OCP (Over Current output Protection), and SCP (Short Circuit output Protection) for enhanced safety.

3. Product Overview

The PK Power AC Adapter is a corded electric power supply designed to provide stable power to compatible HP DeskJet printers. It consists of a main adapter unit, an AC input power cord, and a DC output cable with a barrel connector.



This image displays the PK Power AC Adapter unit, featuring its main rectangular body, the attached AC input power cord with a two-prong plug, and the DC output cable with a barrel connector. The cables are neatly coiled.



This image provides an alternative view of the PK Power AC Adapter, highlighting the connection points for both the AC power input and the DC output to the printer. The adapter's compact design is visible.

4. Setup Instructions

1. **Unpack the Adapter:** Carefully remove the PK Power AC Adapter from its packaging.
2. **Connect to Printer:** Locate the power input port on your HP DeskJet printer (D2460, D4260, D1460, D2430, or D2445). Insert the barrel connector of the adapter's DC output cable firmly into this port.
3. **Connect to Power Outlet:** Plug the AC input power cord into a standard wall outlet (100-240V).
4. **Verify Connection:** Ensure all connections are secure. The printer should now receive power.

5. Operating Instructions

Once properly connected, the PK Power AC Adapter operates automatically. It provides continuous power to your HP DeskJet printer. Simply turn on your printer as you normally would. No additional configuration is required for the adapter itself.

6. Maintenance

To ensure the longevity and optimal performance of your AC adapter:

- **Cleaning:** Use a soft, dry cloth to clean the adapter. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cables to prevent damage.
- **Inspection:** Periodically inspect the cables and connectors for any signs of wear, fraying, or damage. If damage is observed, discontinue use and replace the adapter.

7. Troubleshooting

If you encounter issues with your PK Power AC Adapter, consider the following:

- **No Power to Printer:**
  - Ensure the AC power cord is securely plugged into both the wall outlet and the adapter.
  - Verify the barrel connector is fully inserted into the printer's power port.
  - Test the wall outlet with another device to confirm it is functional.
  - Check for any visible damage to the adapter or cables.
- **Intermittent Power:**
  - Ensure all connections are stable and not loose.
  - Avoid bending or stressing the cables at the connection points.

If problems persist after attempting these steps, please contact customer support.

8. Specifications

Input Voltage	100-240V AC, 50-60Hz
Output Connector Type	Barrel Connector
Compatible Devices	HP DeskJet D2460, D4260, D1460, D2430, D2445 Printers
Safety Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Certifications	CE, FCC, RoHS
Power Source	Corded Electric

9. Warranty and Support

PK Power products are designed for reliability and performance. For any questions, concerns, or technical assistance, our friendly and reliable customer service team is available to help. Please allow up to 24 hours for a response to inquiries.

For support, please visit the PKPOWER Store on Amazon or refer to your purchase documentation for direct contact information.

© 2023 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075SSCL3F

More documents and user manuals: **https://manuals.plus/**