Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Serta 43807A

Serta Bryce Executive Office Chair User Manual

Model: 43807A | Brand: Serta

Introduction

This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your Serta Bryce Executive Office Chair. Designed for comfort and support, this chair features patented AIR Lumbar Technology and quality construction to enhance your seating experience.
For detailed assembly instructions, please refer to the officialInstallation Manual (PDF).

Assembly

The Serta Bryce Executive Office Chair is designed for straightforward assembly. It is recommended to follow the step-by-step instructions provided in the official installation manual to ensure proper setup and functionality.
Key assembly steps typically involve attaching the casters to the chair base, connecting the gas lift cylinder, and securing the seat and backrest components. All necessary tools are generally included or not required for basic assembly.



Image: Overview of chair components and an estimated assembly time of 30 minutes, indicating no extra tools are needed.

Features and Operation

Your Serta Bryce Executive Office Chair is equipped with several features designed for ergonomic support and comfort during extended use.

AIR Lumbar Technology

The patented AIR Lumbar Technology provides dynamic and continuous lower back support. This system pivots with your body's movements, helping to maintain proper lumbar posture in various seated positions.



Image: A detailed view of the Serta AIR Lumbar Support, highlighting its flexible design that adapts to body movement for continuous support.

Ergonomic Design and Cushioning

The chair features a contoured backrest, layered body pillows, a well-padded headrest, and molded armrests. These elements work in conjunction with the lumbar technology to provide comprehensive support for your shoulders and hips.



Image: The deep cushioned headrest provides ergonomic support when sitting upright and comfort when reclining.



Image: The armrests are designed with thick foam and a sculpted shape to reduce pressure on forearms and elbows during extended use.



Image: The seat features extra thick 3-inch foam for generous fill, providing ultimate comfort and relaxation.

Air Circulation

The backrest is constructed with perforated bonded leather and mesh surrounds. This design promotes air circulation, helping to keep you cooler and more comfortable, especially during long periods of sitting.

Adjustable Recline and Height

The chair offers an easy recline function, allowing you to lean back up to 122 degrees. Convenient side-seat controls enable you to raise or lower the seat height by 3.75 inches to find your optimal sitting position.



Image: The chair easily reclines up to 122 degrees, offering more recline than the industry standard.



Image: This diagram illustrates the chair's adjustable height range and the mechanical spring tension knob for controlling recline ease.

Durable Construction and Mobility

The chair is built with a heavy-duty nylon base capable of supporting up to 275 lbs. It features multi-surface silent dual caster wheels that spin 360 degrees, allowing for smooth movement across various floor types.



Image: The chair features a durable nylon base designed to support up to 250 pounds.



Image: Close-up of the 2-inch silent 360-degree spin dual casters, designed for smooth rolling on all floor types.

Quality and Certification

Serta chairs utilize non-recycled, non-toxic foams and exceed minimum industry testing standards. This product is certified by the American Chiropractors Association (ACA), ensuring quality and ergonomic design.



Image: This graphic illustrates the use of non-toxic, non-recycled foam in Serta chairs for maximum comfort, breathability, and safety, contrasting it with potentially toxic recycled foam found in some other brands.



Image: The chair is built with a heavy-duty Class IV gas lift, rated to 275 lbs, and meets ANSI/BIFMA X5.1 standards, as indicated by the SGS test report.

Product Overview Video

Your browser does not support the video tag.

Video: A product summary video showcasing the key features and design of the Serta Bryce Executive Office Chair.

Maintenance

To ensure the longevity and optimal performance of your Serta Bryce Executive Office Chair, follow these maintenance guidelines:

- **Cleaning:** Spot clean the bonded leather and mesh surfaces as needed. Use a mild soap and water solution with a soft cloth. Avoid harsh chemicals or abrasive cleaners that could damage the material.

- **Moving Parts:** Periodically check and tighten any loose screws or bolts. Lubricate moving parts, such as the casters and recline mechanism, with a silicone-based lubricant if they begin to squeak or become stiff.
- **Casters:** Keep the caster wheels clean from debris (hair, dust, etc.) to ensure smooth rolling.
- **General Care:** Avoid exposing the chair to direct sunlight or extreme temperatures, which can cause the material to crack or fade over time.

Troubleshooting

If you encounter issues with your Serta Bryce Executive Office Chair, consider the following common troubleshooting steps:

Problem	Possible Cause	Solution
Chair squeaks or groans	Loose connections, lack of lubrication in moving parts.	Tighten all assembly bolts. Apply silicone lubricant to the recline mechanism and gas lift connections.
Seat height does not adjust or resets	Gas lift malfunction, control lever issue.	Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement. Contact customer support.
Chair feels unstable or wobbly	Loose bolts, uneven floor, damaged base/casters.	Verify all bolts are securely tightened. Ensure the chair is on a flat, even surface. Inspect the base and casters for any damage.
Casters do not roll smoothly	Debris in casters, damaged casters.	Remove any hair or debris from the caster wheels. If damaged, casters can often be replaced.

Specifications

Attribute	Detail
Brand	Serta
Model Name	Bryce
Item Model Number	43807A
Color	Black
Product Dimensions	30.25"D x 25.75"W x 45.75"H
Maximum Weight Recommendation	275 Pounds
Material (Fill)	Foam
Finish Type	Faux Leather

Attribute	Detail
Special Feature	Adjustable Height, AIR Lumbar Technology
UPC	887909059755
Country of Origin	China



Image: Comprehensive product dimensions including width, depth, height, seat depth, seat height, and arm height.

Warranty and Support

Serta provides USA Customer Support for their products. For specific warranty information, including terms, conditions, and how to file a claim, please refer to the official Serta website or contact their customer service directly.
It is recommended to retain your proof of purchase for any warranty-related inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07645VL18

More documents and user manuals: **https://manuals.plus/**