SLIDE SW200BK

SLIDE Smartwatch User Manual

Model: SW200BK

1. Introduction

Thank you for choosing the SLIDE Smartwatch (Model SW200BK). This device is designed to seamlessly integrate with your iOS and Android smartphones, offering a range of features including communication, fitness tracking, and media playback. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your smartwatch.

2. What's in the Box

- SLIDE Smartwatch (SW200BK)
- USB Charging Cable
- User Manual (this document)

3. Product Overview

Familiarize yourself with the components of your SLIDE Smartwatch.



Figure 3.1: Front view of the SLIDE Smartwatch, displaying the digital clock (11:38 PM, 05-25-2016 Wednesday) and icons for Phone (Menu) and Tools. The watch features a rectangular black casing and a textured black wristband.



Figure 3.2: Angled view of the SLIDE Smartwatch, highlighting the screen with time and app icons, and a visible side button on the right side of the watch face. The watch's black strap and metallic-looking body are also visible.

- **Display:** 1.54-inch touch screen for interactive use.
- **Power Button:** Located on the side, used for powering on/off and screen wake/sleep.
- **Charging Port:** Typically located on the side or back for connecting the USB charging cable.
- **SIM Card Slot:** Allows for independent cellular connectivity (Nano SIM).
- **Micro SD Card Slot:** For expandable storage of media and files.

4. Setup

4.1. Charging the Smartwatch

Before first use, fully charge your SLIDE Smartwatch. Connect the USB charging cable to the watch's charging port and the other end to a USB power adapter or computer USB port. The charging indicator will show the charging status on the screen.

4.2. Inserting SIM and Micro SD Cards (Optional)

The SLIDE Smartwatch supports a Nano SIM card for cellular functions and a Micro SD card for additional storage. Locate the SIM/SD card slot, usually under a removable back cover or a side flap. Carefully insert the cards as indicated by the diagrams near the slots. Ensure they are properly seated.

4.3. Powering On/Off

- **To Power On:** Press and hold the Power button until the screen lights up.
- **To Power Off:** Press and hold the Power button, then select 'Power Off' on the screen.

4.4. Pairing with Your Smartphone

To unlock the full potential of your SLIDE Smartwatch, pair it with your iOS or Android smartphone via Bluetooth.

1. Ensure Bluetooth is enabled on both your smartwatch and your smartphone.
2. On your smartwatch, navigate to the Bluetooth settings and enable visibility.
3. On your smartphone, search for available Bluetooth devices. Select 'SW200BK' or a similar name from the list.
4. Confirm the pairing code on both devices if prompted.
5. Once paired, your phone's contacts should automatically download to the smartwatch. Keep your smartphone near the smartwatch for optimal connectivity.

5. Operating Instructions

5.1. Basic Navigation

- **Touchscreen:** Swipe left/right to navigate between screens, tap to select icons or options.
- **Power Button:** Press once to wake/sleep the screen.

5.2. Making and Receiving Calls

With a SIM card inserted or connected via Bluetooth to your phone, you can make and receive calls directly from your smartwatch.

- **Dialer:** Tap the 'Phone' or 'Dialer' icon to enter a number or select from contacts.
- **Answering Calls:** Swipe or tap the 'Answer' icon when an incoming call is displayed.

5.3. Messaging

Access your messages through the 'Messages' icon. You can read incoming SMS and compose new ones using the on-screen keyboard.

5.4. Internet and Applications

The smartwatch supports basic internet browsing and social media applications like Facebook and Instagram. Access these through their respective icons on the main menu.

5.5. Media Playback

If you have a Micro SD card with music or videos, you can play them directly on the smartwatch using the built-in media player. For better audio experience, consider pairing with a wireless speaker.

5.6. Sleep Monitor

The SLIDE Smartwatch includes a sleep monitoring feature. Wear the watch while sleeping to track your sleep patterns. Access sleep data through the 'Sleep Monitor' application on the watch.

6. Maintenance

- **Cleaning:** Wipe the watch screen and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:** To prolong battery life, avoid extreme temperatures. Charge the watch regularly and avoid letting the battery completely drain for extended periods.
- **Storage:** When not in use for a long time, store the smartwatch in a cool, dry place.

7. Troubleshooting

- **Watch Not Charging:** Ensure the charging cable is securely connected to both the watch and the power source. Try a different USB port or power adapter. Check for any debris in the charging port.
- **Low Call Volume:** The smartwatch's internal speaker volume can be low. It is highly recommended to pair your smartwatch with a wireless speaker or Bluetooth headset for clearer audio during calls and media playback.
- **Connectivity Issues (Bluetooth/Internet):** Ensure your smartphone is within Bluetooth range of the smartwatch. If using a SIM card, verify that it is a compatible Nano SIM (e.g., Cricket SIM) as some carriers like AT&T and T-Mobile SIM cards may not work for internet on this device. Restart both devices.
- **Screen Not Responding:** Try restarting the smartwatch by holding the power button. If unresponsive, allow the battery to fully drain and then recharge it.
- **Phone Mirroring Watch Actions:** It is normal for your mobile phone to mirror actions performed on the smartwatch when connected via Bluetooth. This indicates a successful connection and data synchronization.

8. Specifications

Feature	Detail
Model Name	SW200BK
Brand	SLIDE
Screen Size	1.54 Inches (Visible screen diagonal: 2" / 4 cm)
Operating System	Android, iOS compatible
Connectivity Technology	Bluetooth
Special Feature	Sleep Monitor

Battery	1 Lithium Ion battery (included)
Item Weight	4.3 Ounces
Product Dimensions	5.91 x 2.76 x 2.36 inches

9. Warranty and Support

Your SLIDE Smartwatch is covered by a limited manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or contact SLIDE customer support. For technical assistance or further inquiries, please visit the official SLIDE website or contact their customer service department.

© 2024 SLIDE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question