Dupad story Q9

Dupad Story Q9 Mini Wireless Keyboard User Manual

Model: Q9

Introduction

Thank you for purchasing the Dupad Story Q9 Mini Wireless Keyboard. This compact and versatile device combines a full QWERTY keyboard, a multi-touch touchpad, and colorful backlighting, making it ideal for controlling various smart devices. This manual provides detailed instructions on setup, operation, maintenance, and troubleshooting to ensure optimal performance.



Figure 1: Dupad Story Q9 Mini Wireless Keyboard. This image shows the full layout of the keyboard with its integrated touchpad and media control buttons.

Package Contents

Please check the package for the following items:

- 1 x Dupad Story Q9 Mini Wireless Keyboard
- 1 x USB Charging Cable
- 1 x USB Receiver Dongle
- 1 x User Manual



Figure 2: Contents of the Dupad Story Q9 package, including the keyboard, USB cable, USB receiver, and user manual.

Setup Guide

1. Charging the Keyboard

Before first use, fully charge the keyboard.

1. Locate the micro USB charging port on the keyboard.
2. Connect the provided USB charging cable to the keyboard and the other end to a USB power source (e.g., computer USB port, USB wall adapter).
3. The indicator light will show charging status (refer to the "Indicator Lights" section for details). Once fully charged, the light will change or turn off.

2. Connecting to Your Device (Plug and Play)

The Q9 keyboard uses a 2.4GHz wireless connection via a USB receiver.

1. Take out the USB receiver dongle, usually located in a compartment within the keyboard itself.
2. Plug the USB receiver into an available USB port on your target device (e.g., Smart TV, Android TV Box, PC,

Projector).

3. The device should automatically recognize the keyboard and install necessary drivers. No additional software installation is typically required.
4. Turn on the keyboard using the power switch (if present). The keyboard is now ready for use.



Figure 3: The Q9 keyboard is compatible with multiple devices including Android TV Boxes, Smart TVs, PCs, and Projectors. It offers plug-and-play functionality.

Operating Instructions

Keyboard Functions

The Q9 features a full QWERTY layout with additional function keys and multimedia controls.

- **Standard Keys:** All standard alphanumeric and symbol keys are present.

- **Function Keys (F1-F12):** These keys may have secondary functions when pressed in combination with the **Fn** key. Refer to the key legends for specific functions (e.g., F1-F3 for media controls, F5-F8 for special characters).
- **Multimedia Control Keys:** Dedicated buttons for volume up/down, mute, play/pause, next/previous track.
- **Navigation Keys:** Arrow keys, Home, End, Page Up, Page Down for easy navigation.

Touchpad Functions

The integrated touchpad supports multi-finger gestures for enhanced control.

- **Single Finger Tap:** Left-click.
- **Two Finger Tap:** Right-click.
- **Two Finger Scroll:** Scroll up or down.
- **DPI Adjustment:** The touchpad's sensitivity (DPI) can be adjusted to better match different screen sizes. Look for a dedicated DPI button or a combination key (e.g., Fn + spacebar or similar, refer to keyboard markings).



Figure 4: The compact design of the Q9 keyboard allows for easy handling and navigation, making it convenient for controlling media and smart devices.

Backlight Control

The Q9 features a 7-color adjustable backlight for use in low-light conditions.

- **Turning On/Off Backlight:** Press the **RGB** key (or similar designated key) to cycle through backlight modes or turn it off.
- **Changing Colors:** The backlight colors (red, orange, yellow, green, blue, indigo, violet) switch randomly or can be adjusted by touching the touchpad while the backlight is active.



Figure 5: The Q9 keyboard features 7 different backlight colors, which can be adjusted by touching the touchpad, enhancing visibility in dark environments.



Figure 6: Close-up view highlighting key features such as the indicator light, multi-touch touchpad, full QWERTY keyboard layout, and the vibrant 7-color backlight.

Maintenance

Cleaning

- Use a soft, dry cloth to wipe the surface of the keyboard.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- Do not use harsh chemicals, abrasive cleaners, or solvents.

Battery Care

- Recharge the keyboard when the low battery indicator appears.
- Avoid fully discharging the battery frequently to prolong its lifespan.
- If storing the keyboard for an extended period, charge it to about 50% and store in a cool, dry place. Recharge every

few months to prevent deep discharge.

Storage

When not in use, store the keyboard in a clean, dry environment away from direct sunlight, extreme temperatures, and humidity.

Troubleshooting

Problem	Possible Cause	Solution
Keyboard not responding	Low battery USB receiver not connected Out of range Interference	Charge the keyboard. Ensure USB receiver is firmly plugged into the device. Move closer to the device (up to 15 meters range). Move away from other 2.4GHz devices.
Touchpad not working correctly	Incorrect settings Dirty touchpad surface	Adjust DPI settings. Ensure no foreign objects are on the touchpad. Clean the touchpad surface.
Backlight not working	Backlight turned off Low battery	Press the RGB key to turn on/cycle backlight. Charge the keyboard.
Keys not responding	Software issue on host device Physical damage	Restart the host device. Test on another device if possible. Contact customer support if physical damage is suspected.

Specifications

Feature	Detail
Model	Q9
Connectivity	2.4 GHz Wireless (RF)
Operating System Compatibility	Android, PC, Smart TV, HTPC, IPTV, Raspberry Pi, Xbox 360, PS3/PS4
Keyboard Layout	QWERTY
Touchpad Features	Multi-touch, DPI adjustable
Backlight	7 Colors (Red, Orange, Yellow, Green, Blue, Indigo, Violet)
Battery Type	Rechargeable Lithium Ion (BL-4C type)
Charging Interface	Micro USB
Product Dimensions (LxWxH)	14.5 x 11 x 2 cm (5.7 x 4.3 x 0.8 inches)

Feature	Detail
Weight	130 g (0.29 lbs)
Material	Plastic
Wireless Range	Up to 15 meters



Figure 7: Dimensions of the Dupad Story Q9 keyboard, showing its compact size for portability and ease of use.

Warranty and Support

Specific warranty information for the Dupad Story Q9 Mini Wireless Keyboard is not provided in this manual. Please refer

to the product packaging or the retailer's website for warranty details.
For technical support or further assistance, please contact Dupad Story customer service through the contact information provided with your purchase or on the official Dupad Story website.

© 2024 Dupad Story. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question