Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hama MC-200 (00182603)

Hama MC-200 3-Button Optical Mouse User Manual

Model: MC-200 (00182603)

Introduction Safety Information Package Contents Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the Hama MC-200 3-Button Optical Mouse. This manual provides essential information for the proper setup, operation, and maintenance of your new mouse. The Hama MC-200 is a reliable, wired optical mouse designed for precise control and comfortable use.
Key features include:

- Optical 3-button design for exact sensing and precise control.
- Silent main buttons for undisturbed and relaxed working.
- Rubberized surface for improved grip and comfort.
- Symmetrical shape suitable for both left-handed and right-handed users.
- Plug and Play USB connectivity.



Figure 1: Top view of the Hama MC-200 Optical Mouse.

2. Safety Information

Please read the following safety instructions carefully before using your device:

- Do not open the device. Incorrect assembly can lead to electric shock or malfunction.
- Keep the device away from moisture, direct sunlight, and extreme temperatures.
- Use the device only for its intended purpose.
- Do not drop the device or expose it to strong vibrations.
- Dispose of packaging material immediately according to locally applicable regulations.

3. Package Contents

Verify that all items are present and in good condition:

- 1 x Hama MC-200 3-Button Optical Mouse
- 1 x User Manual (this document)

Figure 2: Hama MC-200 Optical Mouse retail packaging.

4. Setup

The Hama MC-200 Optical Mouse is a Plug and Play device, requiring no additional driver installation for basic functionality.

1. **Unpack the Mouse:** Carefully remove the mouse from its packaging.
2. **Connect to Computer:** Insert the USB connector of the mouse into an available USB port on your computer.
3. **System Recognition:** Your operating system will automatically detect and install the necessary drivers. This process may take a few moments.
4. **Ready for Use:** Once the installation is complete, the mouse is ready for immediate use.

System Requirements:

- Operating System: Windows 10/8/7/Vista, MAC OS 10.10 or later.
- Available USB port.

5. Operating Instructions

The Hama MC-200 mouse features a standard 3-button layout with a scroll wheel, designed for intuitive navigation.

- **Left Button:** Primary click function for selecting items, opening files, and executing commands. The silent click design minimizes noise.
- **Right Button:** Secondary click function, typically used to open context menus or access additional options. Also features silent click.
- **Scroll Wheel:**
    - **Scrolling:** Roll the wheel up or down to navigate through documents and web pages.
    - **Middle Click:** Pressing the scroll wheel acts as a third button, often used for opening links in new tabs or other customizable functions.
- **Optical Tracking:** The optical sensor provides precise and smooth cursor movement on various surfaces. For optimal performance, use on a clean, non-reflective mouse pad or surface.
- **Ambidextrous Design:** The perfectly symmetrical shape ensures comfortable use for both left-handed and right-handed individuals.

6. Maintenance

To ensure the longevity and optimal performance of your Hama MC-200 mouse, follow these simple maintenance guidelines:

- **Cleaning:**
    - Disconnect the mouse from your computer before cleaning.
    - Use a soft, slightly damp, lint-free cloth to wipe the surface of the mouse.
    - Do not use harsh cleaning agents, solvents, or abrasive materials, as these can damage the surface.

    - For the optical sensor, use a dry cotton swab to gently remove any dust or debris.
- **Storage:** When not in use for extended periods, store the mouse in a clean, dry environment away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharp bends or kinks in the USB cable to prevent internal damage.

7. Troubleshooting

If you encounter issues with your Hama MC-200 mouse, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mouse not responding / Cursor not moving.	• Loose USB connection. • Faulty USB port. • Operating system issue.	• Ensure the USB cable is securely plugged into the computer. • Try plugging the mouse into a different USB port. • Restart your computer.
Cursor movement is erratic or jumpy.	• Dirty optical sensor. • Unsuitable surface.	• Clean the optical sensor on the underside of the mouse with a dry cotton swab. • Use the mouse on a clean, non-reflective mouse pad or surface.
Buttons or scroll wheel not working.	• Software conflict. • Hardware malfunction.	• Restart your computer. • Test the mouse on another computer to rule out a hardware issue. • If the problem persists, contact Hama customer support.

8. Specifications

Brand	Hama
Series	MC-200
Model Number	00182603
Hardware Platform	PC / Mac
Operating System Compatibility	Windows 10/8/7/Vista, MAC OS 10.10 or later
Item Weight	3.04 ounces (approx. 86 grams)
Product Dimensions (LxWxH)	4.49 x 1.46 x 2.52 inches (approx. 11.4 x 3.7 x 6.4 cm)
Color	White
Power Source	Wired (USB)
Connectivity Technology	USB
Special Feature	Soundless (Silent Clicks)

Movement Detection Technology	Optical

9. Warranty and Support

Hama products are covered by a manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the official Hama website.
If you experience any issues or require technical assistance, please contact Hama customer support:

- **Website:** www.hama.com (Check for regional support contacts)
- **Contact Information:** Refer to the Hama website or product packaging for specific contact details in your region.

Please have your product model number (MC-200 / 00182603) and purchase date ready when contacting support.

© 2026 Hama GmbH & Co KG. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B078T62G9K

More documents and user manuals: **https://manuals.plus/**