Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER PR560, PR580, PR590, PR3175, PR3180, PR3575, PR4000, PR4250, PR5060

PK Power AC Adapter Instruction Manual

For Cobra MicroTalk Two-Way Radios: PR560, PR580, PR590, PR3175, PR3180, PR3575, PR4000, PR4250, PR5060

Introduction

This manual provides instructions for the safe and effective use of your PK Power AC Adapter. This adapter is designed to provide power and charge compatible Cobra MicroTalk two-way radios, including models PR560, PR580, PR590, PR3175, PR3180, PR3575, PR4000, PR4250, and PR5060. Please read this manual thoroughly before use and retain it for future reference.

Setup

1. **Unpack the Adapter:** Carefully remove the AC adapter from its packaging. Inspect the adapter and its cable for any signs of damage. Do not use if damaged.
2. **Identify the Charging Port:** Locate the power input or charging port on your Cobra MicroTalk two-way radio. Refer to your radio's specific user manual if you are unsure.
3. **Connect the Adapter to the Radio:** Insert the small connector end of the AC adapter cable firmly into the power input port of your Cobra MicroTalk two-way radio. Ensure a secure connection.
4. **Connect to Power Outlet:** Plug the AC adapter's two-prong plug into a standard 100-240V AC wall outlet.
5. **Verify Power:** Once connected, your radio should indicate that it is receiving power or charging. This may be shown by an LED indicator on the radio or on the adapter itself, depending on the radio model.



Figure 1: The PK Power AC Adapter with its cable coiled, ready for connection. This image shows the main body of the adapter and the output cable with its connector.

Operating Instructions

The PK Power AC Adapter is designed for straightforward operation:

- **Powering the Radio:** When connected to a power outlet and your radio, the adapter will supply continuous power to the radio, allowing it to operate without battery power (if supported by the radio model) or while charging its internal battery.
- **Charging the Battery:** If your Cobra MicroTalk radio has a rechargeable battery, the adapter will automatically begin charging it once connected and plugged into a power source. The charging time will vary depending on the radio model and battery capacity. Refer to your radio's manual for specific charging indicators and times.
- **Disconnection:** To disconnect, first unplug the adapter from the wall outlet, then gently remove the connector from your radio's power port. Avoid pulling the cable forcefully.



Figure 2: Side view of the PK Power AC Adapter, highlighting the two-prong plug designed for standard wall outlets. This image provides a clear view of the input side of the adapter.

Maintenance

To ensure the longevity and safe operation of your AC adapter, follow these maintenance guidelines:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the adapter. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid extreme temperatures and humidity.
- **Cable Care:** Do not bend, twist, or crimp the cable excessively. Avoid placing heavy objects on the cable.
- **Inspection:** Periodically inspect the adapter and cable for any signs of wear, cuts, or damage. If damage is observed, discontinue use immediately and replace the adapter.

Troubleshooting

If you encounter issues with your PK Power AC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Radio not powering on/charging	• Adapter not fully plugged into outlet. • Adapter not fully connected to radio. • Outlet is not functional. • Adapter or cable is damaged. • Radio battery is completely depleted or faulty.	• Ensure the adapter is securely plugged into a live wall outlet. • Verify the adapter's connector is firmly seated in the radio's power port. • Test the outlet with another device. • Inspect the adapter and cable for visible damage. If damaged, replace. • Try charging for an extended period or test with a known good battery/radio.

Problem	Possible Cause	Solution
Adapter feels hot during use	• Normal operation (slight warmth). • Overload or internal fault.	• A slight warmth is normal. • If the adapter is excessively hot to touch, unplug it immediately. Discontinue use and contact support.

Specifications

Brand: PKPOWER

Input: 100-240V AC, 50-60Hz

Output Wattage: 18 watts

Connector Type: Auxiliary

Color: Black

Special Feature: Travel

Power Source: Corded Electric

Main Power Connector Type: 2 Pin (US Standard)

Certifications: CE, FCC, RoHS

Compatibility: Cobra MicroTalk Two-Way Radios (PR560, PR580, PR590, PR3175, PR3180, PR3575, PR4000, PR4250, PR5060)

Warranty Information

This PK Power AC Adapter comes with a**1-year manufacturer warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or external causes such as power surges. For warranty claims, please retain your proof of purchase.
Additionally, a **30-day return/replacement policy** may apply depending on the retailer's terms of sale.

Customer Support

For technical assistance, warranty claims, or general inquiries regarding your PK Power AC Adapter, please contact PK-Power customer service. Our friendly and reliable customer service team aims to respond within 24 hours.
You can often find support information or contact details through the official PKPOWER store or the retailer from whom you purchased the product.

Online Store: Visit the PKPOWER Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B078YKFG59

More documents and user manuals: **https://manuals.plus/**