Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DELUX OM06G+M105GX

DELUX OM06G+M105GX Wireless Keyboard and Mouse Combo User Manual

Model: OM06G+M105GX

1. Introduction

Thank you for choosing the DELUX OM06G+M105GX Wireless Keyboard and Mouse Combo. This product is designed to provide a comfortable and efficient computing experience with its ergonomic design and reliable 2.4GHz wireless connectivity. This manual will guide you through the setup, operation, and maintenance of your new device.



Image 1.1: The DELUX OM06G+M105GX Wireless Keyboard and Mouse Combo.

2. Package Contents

Please check the package carefully to ensure all items are present:

- 1 x DELUX Wireless Keyboard (French Layout) with 11 Multimedia Keys
- 1 x DELUX Wireless Optical Mouse
- 1 x USB Nano Receiver
- 2 x AAA Batteries (for Keyboard)
- 2 x AA Batteries (for Mouse)
- 1 x User Manual (this document)



Image 2.1: The retail packaging of the DELUX OM06G+M105GX combo, showing the keyboard and mouse inside.

3. Setup Guide

3.1. Installing Batteries

1. **For the Keyboard:** Locate the battery compartment on the underside of the keyboard. Open the cover and insert two AAA batteries, ensuring correct polarity (+/-). Close the cover.
2. **For the Mouse:** Locate the battery compartment on the underside of the mouse. Open the cover and insert two AA batteries, ensuring correct polarity (+/-). Close the cover.
3. The keyboard features a battery wear indicator. Replace batteries when the indicator light signals low power.

3.2. Connecting the USB Nano Receiver

1. Locate the USB Nano Receiver, typically stored within the mouse's battery compartment for safekeeping during transport.
2. Plug the USB Nano Receiver into an available USB port on your computer.
3. Your computer should automatically detect and install the necessary drivers. This process may take a few moments.
4. Once the drivers are installed, the keyboard and mouse are ready for use. No additional pairing is required as they are pre-paired with the receiver.

4. Operating Instructions

4.1. Keyboard Usage

- **Standard Typing:** Use the keyboard as a standard French layout keyboard for all typing tasks.
- **Multimedia Keys:** The keyboard is equipped with 11 dedicated multimedia keys for quick access to functions like volume control, media playback, and web browsing. These keys are typically located along the top row of the keyboard. Refer to the key legends for specific functions.
- **Ergonomic Design:** The keyboard features a contoured ergonomic profile designed for comfortable typing over extended periods.

4.2. Mouse Usage

- **Basic Operation:** The mouse functions as a standard optical mouse with left-click, right-click, and scroll wheel.
- **DPI Resolution:** The mouse operates at a resolution of 1000 DPI, providing precise and smooth cursor control for general computing tasks.
- **Wireless Range:** The 2.4GHz wireless connectivity offers a reliable connection up to 10 meters (approximately 33 feet) from the USB receiver.

5. Maintenance and Care

To ensure the longevity and optimal performance of your DELUX wireless combo, follow these maintenance guidelines:

- **Cleaning:**
  - Disconnect the USB receiver from your computer before cleaning.
  - Use a soft, dry, lint-free cloth to wipe down the surfaces of the keyboard and mouse.
  - For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaning solution. Avoid excessive moisture.
  - Do not spray cleaning solutions directly onto the devices.
  - Use compressed air to remove dust and debris from between the keyboard keys.
- **Battery Replacement:** Replace batteries promptly when the low battery indicator on the keyboard illuminates or when

mouse performance degrades. Always use new, good quality batteries of the specified type (AAA for keyboard, AA for mouse).

- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage. Store the USB receiver in the mouse's battery compartment to avoid loss.
- **Environment:** Avoid exposing the devices to extreme temperatures, direct sunlight, high humidity, or dusty environments.

6. Troubleshooting

If you encounter issues with your DELUX wireless combo, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low batteries, receiver not connected, out of range, interference.	1. Replace batteries in both keyboard and mouse. 2. Ensure the USB Nano Receiver is securely plugged into a working USB port. Try a different USB port. 3. Move the keyboard/mouse closer to the receiver (within 10 meters). 4. Avoid placing the receiver near other wireless devices or large metal objects that might cause interference.
Lagging or erratic cursor movement	Dirty optical sensor, uneven surface, interference.	1. Clean the optical sensor on the underside of the mouse with a soft, lint-free cloth. 2. Use the mouse on a clean, flat, non-reflective surface or a mouse pad. 3. Check for sources of wireless interference.
Multimedia keys not working	Software conflict, driver issue.	1. Ensure your operating system is up to date. 2. Restart your computer. 3. Check if any other software is conflicting with keyboard shortcuts.

If the problem persists after trying these solutions, please contact DELUX customer support.

7. Specifications

Feature	Detail
Brand	DELUX
Model Number	OM06G+M105GX
Color	Black
Connectivity Technology	2.4GHz Wireless (USB Nano Receiver)
Wireless Range	Up to 10 meters
Keyboard Layout	French (AZERTY)
Keyboard Keys	104 standard keys + 11 multimedia keys
Keyboard Key Life	Approx. 10 million keystrokes

Feature	Detail
Keyboard Operating Current	1.5V DC / ≤10mA
Mouse Resolution	1000 DPI
Mouse Button Life	Approx. 3 million clicks
Mouse Operating Current	1.5V DC / ≤10mA
Power Source	Keyboard: 2 x AAA batteries; Mouse: 2 x AA batteries
Compatible Operating Systems	Windows XP/7/8.x/10
Device Compatibility	Personal Computer

8. Warranty and Support

8.1. Manufacturer's Warranty

The DELUX OM06G+M105GX Wireless Keyboard and Mouse Combo comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or external causes.
Please retain your proof of purchase for warranty claims.

8.2. Customer Support

For technical assistance, warranty claims, or any other inquiries regarding your DELUX product, please contact DELUX customer support through the retailer where you purchased the product or visit the official DELUX website for contact information.
Online Resources: For additional support and frequently asked questions, please visit the DELUX brand store on Amazon or the official DELUX website.
Visit the DELUX Store on Amazon

© 2023 DELUX. All rights reserved.
Product Model: OM06G+M105GX

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079K38SRQ

More documents and user manuals: **https://manuals.plus/**