Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC/DC Adapter (Compatible with Panasonic SL-S320, SL-S330, SL-S341C, SL-S441C Series)

PKPower AC/DC Adapter Instruction Manual

For Panasonic SL-S320, SL-S330, SL-S341C, SL-S441C Anti-Shock Memory Mash XBS Portable CD Players

1. Introduction

This manual provides essential information for the safe and effective use of your PKPower AC/DC Adapter. This adapter is specifically designed to provide reliable power to compatible Panasonic portable CD players, ensuring optimal performance and longevity of your device. Please read this manual thoroughly before use and retain it for future reference.

2. Product Overview

The PKPower AC/DC Adapter is a compact and efficient power supply unit, engineered to meet the power requirements of various Panasonic portable CD player models. It features robust construction and incorporates multiple safety protections to safeguard your devices.

2.1 Package Contents

- 1 x PKPower AC/DC Adapter

2.2 Key Features

- **Input Voltage:** 100-240V 50-60Hz, suitable for worldwide use.
- **Safety Certifications:** CE, FCC, and RoHS certified for quality and safety.
- **Protection Features:**
  - **OVP** (Over Voltage Output Protection)
  - **OCP** (Over Current Output Protection)
  - **SCP** (Short Circuit Output Protection)

2.3 Product Dimensions

The adapter is designed to be compact and portable. Approximate dimensions are provided below:



Image: PKPower AC/DC Adapter showing approximate dimensions of 2.92 inches in length, 1.58 inches in width, and 1.18 inches in height.

3. Setup

Follow these steps to properly set up your PKPower AC/DC Adapter:

1. **Identify the Power Port:** Locate the DC input jack on your Panasonic portable CD player. This is typically a small, round port.
2. **Connect the Adapter:** Insert the barrel connector of the PKPower AC/DC Adapter firmly into the DC input jack of your CD player. Ensure a snug fit.
3. **Plug into Power Outlet:** Insert the two-prong plug of the adapter into a standard wall power outlet (100-240V).



Image: The PKPower AC/DC Adapter, illustrating its compact design and the barrel connector for device attachment.

4. Operating Instructions

Once the PKPower AC/DC Adapter is correctly connected to your Panasonic portable CD player and a live power outlet, your CD player should receive power. You can now operate your CD player as usual, without relying on battery power.

- Ensure the power outlet is active.
- The adapter provides continuous power, allowing for extended listening sessions.
- Always disconnect the adapter from the power outlet when not in use for prolonged periods.

5. Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter:

- **Cleaning:** Use a soft, dry cloth to clean the adapter. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Handling:** Do not drop, disassemble, or attempt to repair the adapter yourself. This can void the warranty and pose safety risks.
- **Ventilation:** Ensure the adapter has adequate ventilation during use. Do not cover it with cloths or place it in enclosed spaces that could trap heat.

6. Troubleshooting

If you encounter issues with your PKPower AC/DC Adapter, refer to the following common troubleshooting steps:

- **No Power to CD Player:**
  - Verify that the adapter is securely plugged into both the CD player and the wall outlet.
  - Test the wall outlet with another device to ensure it is functioning correctly.
  - Check the adapter's cable for any visible damage or kinks.
- **Intermittent Power:**
  - Ensure all connections are firm and not loose.
  - Avoid bending the cable sharply near the connector or the adapter body.
- **Adapter Feels Hot:**
  - A slight warmth is normal during operation. However, if the adapter feels excessively hot, disconnect it immediately.
  - Ensure it is not covered and has proper ventilation.

If problems persist after following these steps, please contact customer support.

7. Specifications

Detailed technical specifications for the PKPower AC/DC Adapter:

Input Voltage	100-240V AC, 50/60Hz
Output Current	1.5 Amps
Connector Type	Barrel Connector
Protection Features	OVP, OCP, SCP
Certifications	CE, FCC, RoHS
Compatible Devices	Panasonic SL-S320, SL-S330, SLS320, SLS330, SL-S341C, SL-S441C, SLS341C, SLS441C Portable CD Players

8. Warranty and Support

PKPower stands behind the quality of its products. Your purchase is covered by a return policy allowing for refund or replacement within 30 days of purchase.
For any inquiries, technical assistance, or warranty claims, our friendly and reliable customer service team is available to assist you. We aim to respond to all customer service requests within 24 hours.
Please refer to your purchase documentation or the seller's platform for specific return instructions and contact information.

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079R81X68

More documents and user manuals: **https://manuals.plus/**