Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER MI3021BLK

PKPOWER AC/DC Adapter User Manual

For MEMOREX MI3021BLK Mi3021 Docking Station Speaker System

1. Product Overview

This PKPOWER AC/DC Adapter is designed to provide reliable power to your MEMOREX MI3021BLK Mi3021 Docking Station Speaker System. It converts standard AC wall power to the DC power required by your device, ensuring stable operation.



Image 1.1: The PKPOWER AC/DC Adapter, showing the main unit and attached power cord.

2. Safety Information

- **Read all instructions** before using the adapter.
- **Do not expose** the adapter to rain, moisture, or extreme temperatures.
- **Ensure proper ventilation** around the adapter during use.

- **Do not disassemble** or modify the adapter. Refer servicing to qualified personnel.
- **Use only with compatible devices** as specified. Using with incompatible devices may cause damage.
- **Unplug the adapter** from the wall outlet when not in use for extended periods.
- This adapter features *Over Voltage Protection (OVP)*, *Over Current Protection (OCP)*, and *Short Circuit Protection (SCP)* for enhanced safety.

3. Setup

1. **Identify the power input port** on your MEMOREX MI3021BLK Docking Station Speaker System.
2. **Connect the barrel connector** of the PKPOWER AC/DC Adapter firmly into the power input port of your docking station.
3. **Plug the AC plug** of the adapter into a standard wall electrical outlet (100-240V, 50-60Hz).
4. Ensure all connections are secure before powering on your device.



Image 3.1: Close-up of the PKPOWER AC/DC Adapter's barrel connector, ready for connection.

4. Operating Instructions

Once the PKPOWER AC/DC Adapter is correctly connected to both the wall outlet and your MEMOREX MI3021BLK Docking Station, your docking station is ready for operation. Simply power on your docking station as per its own user manual.

- The adapter provides continuous power to the device.
- No additional controls are present on the adapter itself.

5. Maintenance

- **Cleaning:** Disconnect the adapter from the power source and the device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place when not in use. Avoid wrapping the cord too tightly around the adapter.

- **Inspection:** Periodically inspect the power cord and adapter for any signs of damage, such as frayed wires or cracks. If damage is found, discontinue use and replace the adapter.

6. Troubleshooting

No Power to Device

- **Check Connections:** Ensure the adapter's barrel connector is fully inserted into the device's power port and the AC plug is securely in the wall outlet.
- **Verify Outlet:** Test the wall outlet with another device to confirm it is functional.
- **Inspect Adapter:** Look for any visible damage to the adapter or its cable. If damaged, do not use.
- **Device Compatibility:** Confirm that the adapter is the correct model for your MEMOREX MI3021BLK Docking Station.

7. Specifications

Feature	Specification
Input Voltage	100-240V AC, 50-60Hz
Connector Type	Barrel Connector
Compatible Devices	MEMOREX MI3021BLK Mi3021 Docking Station Speaker System, MP3 Players (as applicable)
Safety Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Certifications	CE, FCC, RoHS

8. Warranty and Support

PKPOWER products are tested by the manufacturer to match and/or exceed OEM specifications. For any inquiries or support, our customer service team is available to assist you.

- **Customer Service:** Our friendly and reliable customer service will respond to you within 24 hours. Please refer to your purchase documentation for contact details.

© 2023 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079SXWSZ6

More documents and user manuals: **https://manuals.plus/**