Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Milenco 0499

Milenco HS Yellow Steering Wheel Lock

Instruction Manual

Product Overview

The Milenco HS Yellow Steering Wheel Lock is a high-security anti-theft device designed to deter vehicle theft. It features a robust construction and an innovative design for quick and easy installation.
This steering wheel lock has been rigorously tested and approved to the Sold Secure Gold automotive standard, which is significantly more stringent than previous security standards, involving an extreme 300-second professional attack test.
Key features include a pick-proof, ultra-high security locking mechanism, and steel construction resistant to sawing and freezing. The redesigned locking mechanism ensures easier alignment and fitting.

Safety Information

- **Always ensure the key is fully inserted** into the lock before attempting to lock or unlock the device.
- Do not attempt to drive the vehicle with the steering wheel lock installed.
- Store the keys in a secure location, separate from the vehicle.
- Keep the lock clean and free from debris to ensure smooth operation.

Package Contents

- 1 x Milenco HS Yellow Steering Wheel Lock
- 3 x High Security Keys

Setup and Installation

The Milenco HS Steering Wheel Lock is designed for quick and easy installation. Follow these steps to secure your vehicle:

1. **Prepare the Lock:** Hold the main body of the lock. The yellow bar has a handle on one end and the locking mechanism on the other. The U-shaped bar is adjustable.
2. **Adjust the U-Bar:** Gently pull the U-shaped bar upwards to extend it from the main body. This allows it to fit over the steering wheel.

3. **Position on Steering Wheel:** Place the U-shaped bar over the top of your vehicle's steering wheel. Ensure the main yellow bar rests across the steering wheel.
4. **Engage the Lock:** Push the U-shaped bar downwards until it firmly secures the steering wheel. The lock should be snug against the steering wheel to prevent movement.
5. **Lock the Device:** Insert one of the high-security keys fully into the lock cylinder. Turn the key to engage the locking mechanism. Remove the key.
6. **Verify Security:** Gently attempt to move the steering wheel. The lock should prevent significant rotation, making the vehicle impossible to steer.



Image: Milenco HS Yellow Steering Wheel Lock correctly installed on a BMW steering wheel, demonstrating its position and visual deterrent.



Image: Milenco HS Yellow Steering Wheel Lock installed in a Mercedes vehicle, showing its compatibility with different car models.



Image: Milenco HS Yellow Steering Wheel Lock installed in a Fiat van, illustrating its versatility across various vehicle types.

Operating Instructions

To unlock and remove the Milenco HS Steering Wheel Lock:

1. **Insert Key:** Fully insert one of the high-security keys into the lock cylinder.
2. **Unlock:** Turn the key to the unlock position. The U-shaped bar should release.
3. **Remove Lock:** Lift the U-shaped bar off the steering wheel and remove the entire device.
4. **Store Safely:** Collapse the U-shaped bar back into the main body for compact storage. Store the lock in a safe place within your vehicle, away from the driver's area.

Your browser does not support the video tag.

Video: A demonstration of how to adjust and operate the Milenco HS Yellow Steering Wheel Lock, showing the extension and retraction of the U-bar and the locking mechanism.

Maintenance

- **Cleaning:** Wipe the lock periodically with a soft, damp cloth to remove dust and grime. Avoid harsh chemicals that may damage the finish.
- **Lubrication:** If the locking mechanism becomes stiff, apply a small amount of graphite lubricant or a silicone-based spray to the keyhole. Do not use oil-based lubricants as they can attract dirt.
- **Storage:** When not in use, store the lock in a dry place to prevent corrosion.

Troubleshooting

- **Lock is Stiff:**
  - Ensure the key is fully inserted.
  - Apply graphite lubricant to the keyhole.
- **Lock Does Not Fit Steering Wheel:**
  - Ensure the U-shaped bar is fully extended.
  - Adjust the position of the lock on the steering wheel to find the best fit.
- **Key is Stuck:**
  - Do not force the key. Apply a small amount of lubricant and gently wiggle the key while attempting to turn it.

Specifications

Brand	Milenco
Model Number	0499
GTIN	05060101830499
Lock Type	Key Lock
Material	Alloy Steel
Color	Yellow
Dimensions (L x W x H)	1.5 x 3.8 x 2.9 cm
Weight	2.37 kg
Special Features	Durable, Pick-proof, Saw-resistant, Freeze-resistant
Country of Origin	Germany



Image: Close-up view of the Milenco HS Yellow Steering Wheel Lock, highlighting the "HARDENED STEEL" inscription, indicating its robust material.



Image: Detailed view of the Milenco HS Yellow Steering Wheel Lock's locking mechanism, demonstrating its design for enhanced security.

Warranty

The Milenco HS Yellow Steering Wheel Lock comes with a**2-year warranty** from the date of purchase. This warranty covers manufacturing defects and material faults under normal use. It does not cover damage caused by misuse, accidents, or unauthorized modifications. Please retain your proof of purchase for warranty claims.

Support

For further assistance, technical support, or warranty inquiries, please contact Milenco customer service through their official website or authorized retailers. Ensure you have your product model number (0499) and proof of purchase available when contacting support.

© 2026 Milenco. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

My Milenco HS Yellow Steering Wheel Lock (Model 0499) is totally locked up and won't open even with lubrication; how can I fix this?

If your Milenco HS Yellow Steering Wheel Lock (Model 0499) is seized and will not open, please follow these troubleshooting steps based on the manufacturer's guidelines: Check Key Insertion: Ensure the high-security key is...

Read full answer

Open the live page

https://manuals.plus/asin/B07B8JKJTW

More documents and user manuals: https://manuals.plus/