Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hoggar by Okoru G01ME0029

Hoggar by Okoru Premium Metal Storage Shed 7.25 m² - Model G01ME0029 User Manual

Your guide to safe assembly, operation, and maintenance.

1. Introduction

Thank you for choosing the Hoggar by Okoru Premium Metal Storage Shed. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your new storage shed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.
This shed is designed for outdoor storage of garden tools, equipment, and other items. It features a galvanized steel structure for durability and a 10-year anti-corrosion warranty.

2. Safety Information

- **Foundation:** A stable, level foundation is crucial for the shed's stability and proper door operation. Do not attempt assembly without a suitable foundation.
- **Assembly:** Assembly requires at least two adults. Wear appropriate safety gear, including gloves and eye protection. Metal edges can be sharp.
- **Weather Conditions:** Do not assemble the shed in strong winds or adverse weather conditions.
- **Anchoring:** Securely anchor the shed to its foundation to prevent wind damage.
- **Ventilation:** The shed includes integrated ventilation. Ensure it remains unobstructed.
- **Children and Pets:** Keep children and pets away from the assembly area. Do not allow them to play inside or around the shed unsupervised.
- **Storage:** Do not store flammable liquids, chemicals, or hazardous materials inside the shed unless properly secured and ventilated according to local regulations.

3. Setup and Assembly

The assembly process for this metal shed can be laborious and requires careful attention to detail. It is highly recommended to have at least two people for assembly.

3.1 Site Preparation

1. **Choose a Level Site:** Select a flat, level area for your shed. An uneven surface will lead to difficulties in assembly, door alignment, and overall structural integrity.
2. **Prepare the Foundation:** A stable foundation frame is essential. This could be a concrete slab, a treated timber frame, or a paved area. Ensure the foundation is larger than the shed's base dimensions.
3. **Clear the Area:** Remove any debris, rocks, or vegetation from the chosen site.

3.2 Unpacking and Part Identification

- Carefully unpack all components. Verify that all parts listed in the packing list are present.
- Many metal panels are covered with protective films. Removing these films can be time-consuming. It is recommended to remove them before assembly.
- Separate and organize all screws, bolts, nuts, and other small hardware components.

3.3 Assembly Steps (General Guidelines)

Refer to the detailed assembly manual provided in the product packaging for step-by-step instructions specific to your model. The following are general guidelines:

1. **Base Frame Assembly:** Assemble the base frame of the shed first, ensuring it is square and level.
2. **Wall Panel Installation:** Attach the wall panels to the base frame, following the numerical or alphabetical order indicated in your specific manual. Ensure all screws are tightened securely but do not overtighten until the entire structure is aligned.
3. **Roof Assembly:** Construct the roof frame and attach the roof panels. Pay close attention to sealing and waterproofing instructions. The shed features a skylight for natural light; ensure it is installed correctly.
4. **Door Installation:** Install the double sliding doors. Ensure they slide smoothly and align properly. Adjust as necessary.
5. **Final Tightening and Anchoring:** Once the entire structure is assembled and aligned, go back and securely tighten all fasteners. Anchor the shed to your prepared foundation using appropriate anchoring hardware (not always included).



Image 1: Exterior dimensions of the Hoggar by Okoru metal storage shed. The shed measures 282 cm in length, 257 cm in width, and 222 cm in height. The door opening is 117 cm wide and 162 cm high.



Image 2: Key features of the shed, including two sliding doors for accessibility (162 cm height), a skylight for natural light, and four integrated drains for water collection.

4. Operating Instructions

4.1 Doors

- The shed is equipped with double sliding doors (117 x 162 cm). To open, gently slide the doors along their tracks.
- Ensure the tracks are kept clear of debris to allow smooth operation.
- For security, a padlock (not included) can be used on the door handles.

4.2 Ventilation

- The shed includes integrated ventilation to renew the air inside. Do not block these vents.
- Proper ventilation helps prevent condensation and mildew buildup, protecting stored items.



Image 3: The metal shed with its double sliding doors open, showcasing its spacious interior suitable for garden tools and equipment.



Image 4: A close-up view of the shed's roof, highlighting the integrated skylight designed to allow natural light into the interior and the ventilation system.

5. Maintenance

The Hoggar by Okoru metal shed is designed for low maintenance, primarily due to its galvanized steel construction and anti-corrosion treatment.

- **Cleaning:** Periodically clean the exterior of the shed with mild soap and water to remove dirt and debris. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Door Tracks:** Keep the sliding door tracks clean and free of obstructions (leaves, dirt, ice) to ensure smooth operation. Lubricate tracks with a silicone spray if doors become stiff.
- **Fasteners:** Annually check all screws and bolts for tightness. Retighten any loose fasteners to maintain structural integrity.
- **Drainage:** Ensure the integrated drains are clear and functioning correctly to prevent water accumulation around the shed's base.
- **Rust Prevention:** Although the shed has an anti-corrosion warranty, promptly address any scratches or damage to the galvanized coating with a suitable rust-inhibiting paint to prevent localized corrosion.

6. Troubleshooting

Problem	Possible Cause	Solution
Doors stick or do not slide smoothly	Debris in tracks, uneven foundation, misaligned doors	Clean tracks. Check foundation level and adjust if possible. Re-align doors according to assembly manual.
Water leakage inside shed	Improperly sealed roof/wall panels, damaged seals, blocked drains	Inspect all seams and seals. Apply silicone sealant where necessary. Clear drains.
Shed feels unstable or wobbly	Not properly anchored, loose fasteners, uneven foundation	Ensure shed is securely anchored to a stable foundation. Tighten all fasteners. Verify foundation level.
Condensation inside shed	Blocked ventilation, high humidity, lack of airflow	Ensure vents are clear. Consider adding a dehumidifier if humidity is consistently high.

7. Specifications

Model: G01ME0029

Brand: Hoggar by Okoru

Exterior Dimensions (L x W x H): 282 cm x 257 cm x 222 cm (111 in x 101.2 in x 87.4 in)

Base Area: Approximately 7.25 m² (78 sq ft)

Door Type: Double Sliding Door

Door Opening (W x H): 117 cm x 162 cm (46.1 in x 63.8 in)

Material: Galvanized Steel (0.25 mm panels), Alloy Steel frame

Color: Grey/Beige

Weight: 87 kg (191.8 lbs)

Water Resistance Level: Waterproof

Features: Integrated ventilation, skylight, 4 drains

Assembly Required: Yes



Image 5: The exterior of the Hoggar by Okoru metal shed, featuring the 10-year anti-corrosion warranty emblem on the door.

8. Warranty Information

This Hoggar by Okoru metal storage shed comes with a**10-year anti-corrosion warranty** on its galvanized steel structure. This warranty covers defects in materials and workmanship that result in corrosion under normal use and maintenance.

Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by improper assembly, lack of maintenance, extreme weather conditions, modifications, or misuse.

9. Support

For further assistance, missing parts, or warranty inquiries, please contact Hoggar by Okoru customer service. Refer to the contact information provided in your product packaging or on the manufacturer's official website. When contacting support, please have your model number (G01ME0029) and proof of purchase readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07BH345D3

More documents and user manuals: **https://manuals.plus/**