Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER PBX-61158

PK Power AC Power Cord Cable User Manual

For QFX PBX-61158 Portable Party Speaker

1. Introduction

This manual provides essential information for the safe and effective use of your PK Power AC Power Cord Cable. This cable is designed to provide power to the QFX PBX-61158 Portable Party Speaker. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

Always observe the following safety precautions to prevent electric shock, fire, or damage to the product or connected devices.

- **Do not use if damaged:** Inspect the cable for any signs of damage (frayed wires, exposed conductors, bent pins) before each use. Do not use a damaged cable.
- **Proper voltage:** Ensure the power outlet voltage matches the requirements of your QFX PBX-61158 speaker (typically 100-240V AC).
- **Avoid water:** Keep the power cord away from water, liquids, and damp environments. Do not handle with wet hands.
- **Proper insertion:** Insert the plugs fully into the speaker and wall outlet. A loose connection can cause overheating.
- **Unplug safely:** Always grasp the plug, not the cable, when disconnecting from the wall outlet or speaker.
- **Indoor use only:** This power cord is intended for indoor use in dry locations.

3. Product Overview

The PK Power AC Power Cord Cable is a replacement or spare power cable for compatible devices, specifically the QFX PBX-61158 Portable Party Speaker. It features a standard 2-prong US male plug on one end and a C7 (figure-8) female connector on the other.



Image 1: PK Power AC Power Cord Cable, coiled, showing the 2-prong male plug and the C7 female connector.



Image 2: PK Power AC Power Cord Cable, coiled, showing a closer view of the 2-prong male plug and the C7 female connector.

4. Setup

Follow these steps to connect your QFX PBX-61158 Portable Party Speaker using the PK Power AC Power Cord Cable:

1. **Power Off:** Ensure your QFX PBX-61158 speaker is turned off before connecting the power cord.
2. **Connect to Speaker:** Insert the C7 (figure-8) female connector end of the power cord firmly into the power input port on your QFX PBX-61158 speaker.

3. **Connect to Outlet:** Insert the 2-prong male plug end of the power cord firmly into a standard, grounded AC wall outlet.
4. **Power On:** You may now turn on your QFX PBX-61158 speaker.

5. Operating

Once properly connected, the PK Power AC Power Cord Cable provides continuous power to your QFX PBX-61158 Portable Party Speaker. No further operation of the cable itself is required. The speaker will draw power as needed.

6. Maintenance

Proper care and maintenance will extend the life of your power cord:

- **Cleaning:** Wipe the cable with a dry, soft cloth. Do not use liquid cleaners or immerse in water.
- **Storage:** When not in use, coil the cable loosely. Avoid tight coiling, kinking, or bending at sharp angles, which can damage internal wires.
- **Inspection:** Periodically inspect the cable for any signs of wear, cuts, or damage to the insulation or connectors. Replace the cable if any damage is found.
- **Environment:** Store in a cool, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you encounter issues, refer to the following troubleshooting tips:

- **No power to speaker:**
  - Ensure both ends of the power cord are securely plugged into the speaker and the wall outlet.
  - Check if the wall outlet is functional by plugging in another device.
  - Inspect the power cord for any visible damage. If damaged, discontinue use and replace.
  - Verify the speaker's power switch is in the 'ON' position.
- **Loose connection:** If the cable feels loose, unplug it completely and re-insert it firmly into both the speaker and the wall outlet.

If problems persist after following these steps, please contact customer support.

8. Specifications

Feature	Detail
Input Voltage	100-240V AC
Frequency	50-60Hz
Certifications	CE / FCC / RoHS
Protection Features	OVP (Over Voltage Output Protection), OCP (Over Current Output Protection), SCP (Short Circuit Output Protection)

Connector Type (Male)	US 2-Prong Plug
Connector Type (Female)	C7 (Figure-8)
Connector Gender	Male-to-Female
Total Power Outlets	1 (single connection point)
UPC	716833581783

9. Customer Support

For any questions, concerns, or assistance with your PK Power AC Power Cord Cable, please contact our customer service team. Our friendly and reliable customer service will respond to you within 24 hours. Please refer to your product packaging or purchase documentation for specific contact details.

© 2023 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07BQXM86H

More documents and user manuals: **https://manuals.plus/**