Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER MGS-150D

PKPower AC/DC Adapter User Manual

Model: MGS-150D Compatible Power Supply

1. Introduction

Thank you for choosing the PKPower AC/DC Adapter. This adapter is designed to provide reliable power to your Naipo MGS-150D Shiatsu Neck & Shoulder Massager. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and troubleshooting.



Image 1.1: The PKPower AC/DC Adapter, showing the main adapter unit and its attached power cord.

2. Safety Information

Please read all safety instructions carefully before using the adapter. Failure to follow these instructions may result in electric shock, fire, or damage to the product or connected device.

- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Do not expose to water, rain, or excessive humidity.
- **Voltage Compatibility:** Ensure the input voltage of the adapter (100-240V 50-60Hz) matches your power outlet specifications.

- **Proper Connection:** Always connect the adapter to the device before plugging it into the wall outlet. Disconnect from the wall outlet before disconnecting from the device.
- **Avoid Overloading:** Do not overload the adapter or the power outlet.
- **Protection Features:** The adapter includes OVP (Over Voltage Protection), OCP (Over Current Protection), and SCP (Short Circuit Protection) for enhanced safety.
- **Damage:** Do not use the adapter if the cord or plug is damaged. Do not attempt to open or repair the adapter. Contact customer support if damaged.
- **Children:** Keep out of reach of children.

3. Setup

Setting up your PKPower AC/DC Adapter is straightforward. Follow these steps to ensure proper connection to your Naipo MGS-150D massager.

1. **Inspect the Adapter:** Before connecting, visually inspect the adapter and its cord for any signs of damage.
2. **Connect to Device:** Locate the power input port on your Naipo MGS-150D Shiatsu Neck & Shoulder Massager. Insert the barrel connector of the PKPower adapter firmly into this port.
3. **Plug into Outlet:** Once the adapter is securely connected to the massager, plug the adapter's two-prong plug into a standard 100-240V AC wall outlet.
4. **Verify Connection:** Ensure both connections are snug. The massager should now be ready for operation.



Image 3.1: The PKPower AC/DC Adapter, illustrating its compact size and barrel connector, which plugs into the device.

4. Operating Instructions

The PKPower AC/DC Adapter functions as a power supply for compatible devices. It does not have operational controls

itself.

- **Power Delivery:** Once properly connected to both the Naipo MGS-150D massager and a power outlet, the adapter will supply the necessary power for the massager to operate.
- **Device Control:** All operational functions (e.g., turning on/off, adjusting settings) are controlled directly on the Naipo MGS-150D massager itself, not via the adapter.
- **Disconnection:** To disconnect, first unplug the adapter from the wall outlet, then disconnect the barrel connector from the massager.

5. Maintenance

Proper maintenance ensures the longevity and safe operation of your PKPower AC/DC Adapter.

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cord to prevent damage.
- **Inspection:** Periodically inspect the adapter, cord, and plug for any signs of wear, cuts, or damage. If damage is found, discontinue use immediately.



Image 5.1: A view of the PKPower AC/DC Adapter, showing the robust construction of the main unit and the attached power cable.

6. Troubleshooting

If you encounter issues with your PKPower AC/DC Adapter, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Device not powering on.	Adapter not plugged in; loose connection; faulty outlet; incompatible device.	Ensure adapter is fully plugged into both the device and a working wall outlet. Test the outlet with another device. Verify the adapter is compatible with your specific Naipo MGS-150D model.

Problem	Possible Cause	Solution
Adapter feels hot.	Normal operation (slight warmth); excessive load; poor ventilation.	A slight warmth is normal. If it's excessively hot, unplug immediately. Ensure the adapter is not covered and has adequate ventilation. Verify the connected device is not drawing too much power.
Visible damage to adapter or cord.	Physical stress or accident.	**Discontinue use immediately.** Do not attempt to repair. Contact customer support for assistance.

7. Specifications

Key technical specifications for the PKPower AC/DC Adapter.

- **Input:** 100-240V AC, 50-60Hz
- **Output:** Compatible with Naipo MGS-150D requirements.
- **Connector Type:** Barrel connector
- **Safety Certifications:** CE, FCC, RoHS certified
- **Protection Features:** Over Voltage Protection (OVP), Over Current Protection (OCP), Short Circuit Protection (SCP)
- **Included Components:** 1 AC/DC Adapter





Image 7.1: Side profile of the PKPower AC/DC Adapter, highlighting its compact design.

8. Warranty and Support

PKPower stands behind its products. For any questions or concerns, please refer to the following information.

- **After-Sale Service:** Our friendly and reliable customer service team is available to respond to your inquiries within 24 hours.
- **Contact:** For support, please refer to the contact information provided with your purchase or visit the official PKPower store on Amazon: PKPOWER Amazon Store.

© 2023 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CJLVT56

More documents and user manuals: **https://manuals.plus/**