Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEBO Nebo 6526

NEBO Armor3 Flashlight - Instruction Manual

Model: Nebo 6526

Product Overview

The NEBO Armor3 Flashlight is a robust and versatile lighting tool designed for durability and performance in various conditions. It features multiple light modes, a non-slip rubber coating, and a magnetic base for hands-free operation. Engineered to be impact-resistant and waterproof, the Armor3 is built to withstand demanding environments.

- **4 Light Modes:** Flashlight, Work Light, Red COB Worklight, Red COB Flash.
- **Durable Design:** Non-slip rubber coating, floats, fully dimmable, steel clip, magnetic base.
- **Operation:** Front position ON/OFF button; hold to dim.
- **Resilience:** IPX7 Waterproof and impact resistant (rated for 66 feet drop).
- **Power:** Powered by 3x AAA batteries (included).



Figure 1: Front view of the NEBO Armor3 Flashlight, highlighting its primary light source and the side COB work light.

Initial Setup

Battery Installation

1. Locate the battery compartment cover, typically at the base of the flashlight.
2. Unscrew the two screws securing the battery cover.
3. Insert 3x AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery cover and securely tighten the screws to maintain the waterproof seal.



Figure 2: Side view of the Armor3 flashlight, illustrating the general area for battery access.

Operating Your Armor3 Flashlight

Power Button and Mode Selection

The Armor3 features a single front-positioned ON/OFF button for all functions.

- **Press once:** Activates Flashlight mode (top spot light).
- **Press twice:** Activates Work Light mode (side COB light).
- **Press three times:** Activates Red COB Worklight mode.
- **Press four times:** Activates Red COB Flash mode.
- **To turn off:** Press the button again after cycling through all modes, or hold the button down for 2 seconds in any mode.

Dimmable Feature

While in Flashlight or Work Light mode, hold down the ON/OFF button to activate the dimming function. Release the button at your desired brightness level. The light will remember the last brightness setting for the next time it is turned on in that mode.

Integrated Features

- **Steel Clip:** Use the integrated steel clip for convenient attachment to pockets, belts, or gear.
- **Magnetic Base:** The powerful magnetic base allows for hands-free lighting by attaching the flashlight to metallic surfaces.



Figure 3: Detailed diagram illustrating the various features and components of the Armor3 flashlight.

Official Product Video: Durability Test

▶ **Watch video online**

Video 1: An official NEBO video demonstrating the durability of the Armor3 flashlight through various tests, including waterproof, drop, crush, and impact tests. This video highlights the product's robust construction and resilience.

Care and Maintenance

- **Cleaning:** Wipe the flashlight with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** Remove batteries if the flashlight will not be used for an extended period to prevent leakage and corrosion. Store in a cool, dry place.
- **Waterproof Seal:** Ensure the battery compartment cover is securely fastened before exposing the flashlight to water to maintain its IPX7 waterproof rating.



Figure 4: The Armor3 flashlight submerged in water, showcasing its waterproof design and ability to float.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity. Replace with fresh AAA batteries.
Light is dim or flickers.	Low battery power. Loose battery connection.	Replace batteries. Ensure battery compartment is securely closed.

Problem	Possible Cause	Solution
Water inside battery compartment.	Battery cover not properly sealed.	Immediately remove batteries and dry the compartment. Ensure cover is tightened correctly for future use.

Technical Specifications

Feature	Detail
Brand	NEBO
Model Number	Nebo 6526
Light Source Type	LED
Brightness (Spot Light)	160 Lumens
Brightness (Work Light)	360 Lumens
Power Source	Battery Powered (3x AAA, included)
Water Resistance Level	IPX7 Waterproof (floats)
Impact Resistance	Rated for 20 meters (66 feet)
Material	Plastic, Rubber
Item Weight	7.4 ounces (209 Grams)
Product Dimensions	8 x 4 x 6 inches



Figure 5: Dimensions of the Armor3 flashlight.

Warranty and Support

The NEBO Armor3 Flashlight comes with a**Limited Lifetime Warranty**, ensuring peace of mind regarding its durability and performance. For warranty claims, technical support, or any product-related inquiries, please refer to the official NEBO website or contact their customer service directly.
Official NEBO Website: www.nebo.acgbrands.com

© 2024 NEBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07CYZVT1P

More documents and user manuals: **https://manuals.plus/**