Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire FFBN1721TV

Frigidaire 17.4 Cu. Ft. 4-Door Refrigerator Instruction Manual

Model: FFBN1721TV

Introduction

This manual provides essential information for the safe and efficient operation of your new Frigidaire 17.4 Cu. Ft. 4-Door Refrigerator. Its innovative four-door design allows for superior organization and easy access to both fresh and frozen foods, simplifying meal preparation. Please read this manual thoroughly before installation and use, and keep it for future reference.



Front view of the Frigidaire 17.4 Cu. Ft. 4-Door Refrigerator, showcasing its sleek brushed steel finish and modern design.

Key Features

- **4-Door Design:** Allows for optimal organization and easy access to fresh and frozen foods.
- **TwinTech Dual Evaporators:** Helps preserve the freshness of both refrigerated and frozen foods by maintaining optimal humidity levels.
- **Adjustable Freezer Storage:** Maximize your freezer space with 4 pull-out freezer bins and 2 pull-out freezer drawers for

easy organization.

- **Digital Display Control Panel:** Conveniently adjust refrigerator and freezer settings from the exterior door.
- **2 SpaceWise Adjustable Glass Shelves:** Customize your refrigerator's interior layout for flexible storage.
- **2 Store-More Door Bins:** Gallon-size bins designed to accommodate larger beverage containers.
- **2 Store-More Clear Crisper Drawers:** Dedicated drawers for keeping fruits and vegetables fresh.
- **LED Interior Lighting:** Bright and energy-efficient lighting throughout the refrigerator for better visibility.



The spacious interior of the refrigerator, demonstrating the effective use of adjustable shelves and door bins for various food items.

Setup and Installation Guidelines

Proper installation is crucial for the performance and longevity of your refrigerator. Before delivery and setup, ensure your space meets the necessary dimensions and utility requirements. This video provides helpful tips for measuring your space and understanding hookup requirements.

▶ **Watch video online**
Refrigerator Measuring Guidelines

Official video from Electrolux Home Products detailing how to measure your kitchen space for a new refrigerator, including considerations for width, height, depth, and necessary clearances.

Space Requirements:

- **Width:** Measure at the upper cabinets, countertop, and bottom cabinets (if molding is present). Note the thinnest point.
- **Height:** Measure from the floor to the lowest point on the cabinet above the refrigerator space.
- **Depth:** Refrigerators come in counter depth and standard depth. For counter depth, measure from the back wall to the edge of your counter. For standard depth, measure from the back wall to about 6 inches past your cabinets.
- **Breathing Room:** Leave 0.5 inches on both sides, 1 inch above the unit, and 2 inches at the back to prevent overheating. Always double-check manufacturer specifications.

Utility Hookups:

- **Electrical Outlet:** A standard 110V, 3-prong, grounded electrical outlet is required within 5 feet of the refrigerator.
- **Water Shutoff Valve (for ice and water dispensing models):** Ensure a working water shutoff valve is within 6 feet of the refrigerator and on the same floor. The connection must be corrosion-free and made of metal (excluding copper).



Visual representation of the refrigerator's key dimensions: approximately 70 inches in height and 33 inches in width, designed for smaller spaces.

Operation

Your Frigidaire 4-Door Refrigerator is designed for intuitive use and efficient food storage. Familiarize yourself with its compartments and controls for optimal performance.

▶ **Watch video online**
Frigidaire 17.4 Cu. Ft. 4 Door Refrigerator in Brushed Steel

Official video from Electrolux Home Products showcasing the interior features and organization capabilities of the Frigidaire 17.4 Cu. Ft. 4-Door Refrigerator.

Interior Organization:

- **Refrigerator Compartment:** The upper section features two SpaceWise adjustable glass shelves, allowing you to

customize the height to fit taller items. Two Store-More clear crisper drawers are located at the bottom for fresh produce.

- **Freezer Compartment:** The lower section provides ample storage with four pull-out freezer bins and two pull-out freezer drawers, making it easy to organize and access frozen goods.
- **Door Bins:** The refrigerator doors are equipped with Store-More gallon-size bins, perfect for storing large bottles and containers.

Controls:

The digital display control panel on the exterior of the refrigerator door allows you to easily adjust temperature settings for both the refrigerator and freezer compartments. Refer to the full user manual for detailed instructions on using specific control functions.

Maintenance and Care

Regular cleaning and maintenance will ensure your Frigidaire refrigerator operates efficiently and maintains its appearance.

- **Cleaning Surfaces:** Wipe down exterior and interior surfaces regularly with a soft cloth and mild, non-abrasive cleaner. For stainless steel, use a specialized stainless steel cleaner.
- **Cleaning Drawers and Shelves:** Remove and wash crisper drawers, door bins, and glass shelves with warm, soapy water. Rinse thoroughly and dry before returning them to the refrigerator.
- **Condenser Coils:** Periodically clean the condenser coils (located at the back or bottom of the unit) to ensure efficient cooling. Refer to the full manual for detailed instructions.
- **Frost-Free Feature:** Your refrigerator is designed with a frost-free system, eliminating the need for manual defrosting.

Troubleshooting

Before contacting customer service, try these common troubleshooting steps:

Problem	Possible Cause	Solution
Refrigerator not cooling	Power outage; thermostat set too high; door left ajar; condenser coils dirty.	Check power supply; adjust thermostat; ensure door is closed; clean coils.
Excessive noise	Refrigerator not level; items vibrating inside; normal operating sounds.	Level the refrigerator; rearrange items; some sounds are normal.
Water dispenser not working	Water supply turned off; water filter clogged; dispenser line frozen.	Check water supply valve; replace filter; thaw line if frozen.

For more detailed troubleshooting and solutions, please refer to the complete Instructions for Use (IFU) PDF.

Specifications

Attribute	Detail
Brand	Frigidaire
Model Number	FFBN1721TV
Capacity	17.4 Cubic Feet (11.9 Cu. Ft. Fresh Food, 5.5 Cu. Ft. Freezer)
Dimensions (D x W x H)	25.75" x 32.81" x 70"
Item Weight	240 pounds
Color	Brushed Steel
Installation Type	Freestanding
Form Factor	French Door
Number of Doors	4
Defrost System	Frost Free
Annual Energy Consumption	507 Kilowatt Hours Per Year
Voltage	115 Volts
Shelf Type	Glass
Included Components	Power cord
Certification	CSA

Warranty and Support

For detailed warranty information, product registration, and customer support, please refer to the official documentation included with your appliance or visit the Frigidaire website. The complete Instructions for Use (IFU) PDF contains comprehensive details regarding your product's warranty and how to obtain service.

© 2025 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07FDDQ366

More documents and user manuals: **https://manuals.plus/**