Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-H15

Joyroom JR-H15 Bluetooth Headphones User Manual

Model: JR-H15 | Brand: Joyroom

1. Introduction

Thank you for choosing the Joyroom JR-H15 Bluetooth Headphones. This manual provides detailed instructions on how to set up, operate, and maintain your headphones to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

2. Package Contents

Please check the package contents upon unboxing. If any items are missing or damaged, please contact your retailer.

- Joyroom JR-H15 Bluetooth Headphones
- USB Charging Cable
- User Manual

3. Product Overview

Familiarize yourself with the components of your Joyroom JR-H15 headphones.



Image: Joyroom JR-H15 Bluetooth Headphones shown in their retail packaging, highlighting the black color variant.



Image: Front view of the Joyroom JR-H15 Bluetooth Headphones, displaying the earcups and integrated control buttons on the right earcup.

Headphone Components:

1. **Adjustable Headband:** For comfortable fit.
2. **Earcups:** Padded for comfort, housing the speakers.
3. **Control Buttons:** (Typically on right earcup) Power On/Off, Volume Up/Next Track, Volume Down/Previous Track, Multi-function Button (Play/Pause, Answer/End Call).
4. **Microphone:** Integrated for hands-free calling.
5. **Charging Port:** (e.g., Micro USB or USB-C) For battery charging.
6. **LED Indicator:** Shows power, pairing, and charging status.

4. Setup

4.1 Charging the Headphones

Before first use, fully charge your headphones. A full charge typically takes approximately 2-3 hours.

1. Connect the small end of the USB charging cable to the charging port on the headphones.
2. Connect the larger end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will illuminate (e.g., red) during charging and turn off or change color (e.g., blue) when fully charged.

4.2 Bluetooth Pairing

Pair your headphones with your Bluetooth-enabled device (smartphone, tablet, computer).

1. Ensure the headphones are turned off.
2. Press and hold the Power/Multi-function button for approximately 5-7 seconds until the LED indicator flashes rapidly (e.g., red and blue alternately), indicating pairing mode.
3. On your device, enable Bluetooth and search for available devices.
4. Select "JR-H15" from the list of found devices.
5. Once paired, the LED indicator will flash slowly (e.g., blue) or turn solid blue, and you may hear an audible confirmation.
6. If prompted for a password, enter "0000".

Note: The headphones will automatically attempt to reconnect to the last paired device when powered on.

5. Operating Instructions

5.1 Power On/Off

- **Power On:** Press and hold the Power/Multi-function button for about 3 seconds until the LED indicator flashes (e.g., blue) and you hear a power-on tone.
- **Power Off:** Press and hold the Power/Multi-function button for about 3 seconds until the LED indicator turns off and you hear a power-off tone.

5.2 Music Playback

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.
- **Volume Up:** Short press the Volume Up (+) button.
- **Volume Down:** Short press the Volume Down (-) button.

5.3 Call Management

- **Answer/End Call:** Press the Multi-function button once during an incoming call.
- **Reject Call:** Press and hold the Multi-function button for about 2 seconds during an incoming call.
- **Redial Last Number:** Double-press the Multi-function button.

6. Maintenance

- Clean the headphones regularly with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the headphones to extreme temperatures, humidity, or dust.
- Do not immerse the headphones in water or any other liquids.
- Store the headphones in a cool, dry place when not in use.
- Do not attempt to disassemble or modify the headphones, as this will void the warranty.

7. Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Headphones not in pairing mode; Bluetooth off on device; device too far.	Ensure headphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Move device closer to headphones (within 10 meters). Clear previous pairings on your device and try again.
No sound or low volume.	Volume too low on headphones or device; not properly connected.	Increase volume on both headphones and your device. Ensure headphones are properly paired and connected. Try restarting both devices.
Sound distortion.	Interference; device too far.	Move closer to your device. Avoid strong electromagnetic interference.

8. Specifications

Model	JR-H15
Brand	Joyroom
Connectivity	Bluetooth
Bluetooth Chip	Imported CSR chip
Battery Capacity	95mAh Polymer Battery
Standby Time	Up to 22 hours
Talking Time	Up to 10 hours
Material	Plastic
Special Features	Microphone Included

Package Dimensions	20.8 x 20 x 7.5 cm
Item Weight	334 g

9. Warranty and Support

Joyroom products are manufactured to the highest quality standards. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, warranty claims, or general inquiries, please contact Joyroom customer service through their official website or the contact information provided with your purchase documentation.

© 2024 Joyroom. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GBTD2DW

More documents and user manuals: **https://manuals.plus/**