Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dupad story 8541648516

D8 Mini Wireless Keyboard with Touchpad User Manual

Brand: Dupad story | Model: 8541648516

1. Introduction

This manual provides detailed instructions for the D8 Mini Wireless Keyboard with Touchpad. This compact and versatile device combines a full QWERTY keyboard and a large, sensitive touchpad, designed for convenient control of various smart devices.

Key Features:

- **Game Handle Design:** Features a hand-tilt design and spiral-patterned anti-slip grip on the back for comfortable use.
- **Sensitive Touchpad:** Built-in high-sensitivity intelligent mouse and touchpad function supporting multi-finger gestures. One-finger click acts as the left mouse button, two-finger click as the right mouse button, and two-finger drag for scrolling. Touchpad sensitivity is adjustable.
- **Colorful Backlit:** Integrated backlit keyboard with adjustable 3 levels of brightness and 7 backlight colors for use in low-light conditions.
- **Stable Signal and Wide Compatibility:** Offers a wireless range of up to 10 meters (32.8ft) with stable signal. Plug and play functionality requires no software installation. Compatible with PC, Laptop, Projector, Mac OS, Linux, HTPC, IPTV, Google Android Smart TV Box, and Windows 2000/XP/Vista/7/8/10.

2. What's in the Box

Please check the package contents to ensure all items are present:

- 1 x D8 Mini Wireless Keyboard with Touchpad
- 1 x USB Receiver (stored inside the keyboard's battery compartment)
- 1 x Micro USB Charging Cable
- 1 x User Manual



Image: Package contents of the D8 Mini Wireless Keyboard.

3. Setup Guide

Follow these steps to set up your D8 Mini Wireless Keyboard:

1. **Locate the USB Receiver:** Open the battery compartment cover on the back of the keyboard. The small USB receiver is stored inside for safekeeping.
2. **Insert the USB Receiver:** Plug the USB receiver into an available USB port on your PC, Laptop, Smart TV Box, or other compatible device.
3. **Power On the Keyboard:** Locate the power switch on the back of the keyboard (near the USB receiver storage) and slide it to the "ON" position.
4. **Automatic Connection:** The keyboard should automatically connect to your device. No additional drivers or software are typically required for basic functionality.



Image: Back of the keyboard indicating the USB receiver and power switch.



Image: Compatible devices for the D8 Mini Wireless Keyboard.

4. Operating Instructions

4.1 Basic Keyboard and Touchpad Use

The D8 Mini Wireless Keyboard features a full QWERTY layout for typing and a large touchpad for mouse control.

- **Typing:** Use the QWERTY keys for text input, similar to a standard keyboard.
- **Left Click:** Tap the touchpad once with one finger.
- **Right Click:** Tap the touchpad once with two fingers.
- **Scrolling:** Drag two fingers up or down on the touchpad to scroll.
- **Cursor Speed Adjustment:** Press and hold the **Fn** key, then press the **DPI** key to cycle through touchpad sensitivity levels.



Image: User holding the QWERTY Mini Keyboard.



Image: Demonstrating the large size touchpad.

4.2 Backlight Control

The keyboard features a colorful backlight with adjustable settings:

- **Change Backlight Color:** Press and hold the **Fn** key, then press the **Ctrl** key to cycle through the 7 available backlight colors.
- **Toggle White Backlight:** Press and hold the **Fn** key, then press the **lightbulb icon** key to switch to white backlight mode.
- **Adjust Brightness:** Press and hold the **Fn** key, then press the **sun icon** key to adjust the backlight brightness (3 levels).



Image: Function key combinations for backlight and DPI adjustment.

4.3 Product Demonstration Video

▶ **Watch video online**

Video: A demonstration of the D8 Mini Wireless Keyboard's features, including its design, touchpad functionality, backlight options, and compatibility with smart TV boxes for browsing and app navigation.

5. Maintenance

- **Charging:** When the battery is low, connect the keyboard to a USB power source using the provided Micro USB charging cable. The charging indicator light will illuminate.
- **Cleaning:** Use a soft, dry cloth to clean the surface of the keyboard and touchpad. Avoid using harsh chemicals

or abrasive materials.

- **Storage:** When not in use for extended periods, turn off the keyboard to conserve battery life. Store the USB receiver inside the battery compartment to prevent loss.

6. Troubleshooting

Problem	Possible Cause	Solution
Keyboard not responding	Keyboard is off Low battery USB receiver not properly connected Interference	Ensure the power switch is ON. Charge the keyboard fully. Reconnect the USB receiver to a different USB port. Move closer to the device or away from other wireless devices.
Backlight not working or flickering	Backlight is off Low battery	Press Fn + Ctrl or Fn + lightbulb icon to activate/change backlight. Charge the keyboard fully.
Touchpad not sensitive enough	DPI setting is too low	Press Fn + DPI to increase touchpad sensitivity.

7. Specifications

Feature	Detail
Product Dimensions	6.1 x 4.53 x 1.18 inches
Item Weight	5.6 ounces
Connectivity Technology	2.4G Wireless (USB Receiver)
Wireless Range	Up to 10 meters (32.8ft)
Keyboard Description	Multimedia
Number of Keys	79
Backlighting	RGB (7 colors) with 3 adjustable brightness levels
Power Source	Rechargeable Battery (included)
Charging Port	Micro USB
Compatible Devices	PC, Laptop, Projector, Mac OS, Linux, HTPC, IPTV, Google Android Smart TV Box, Windows 2000/XP/Vista/7/8/10

8. Warranty and Support

The D8 Mini Wireless Keyboard comes with an unconditional 30-day money-back guarantee and lifetime after-sales service. Your satisfaction is our priority.

For any questions, technical support, or warranty claims, please contact Dupad story customer service through the platform where you purchased the product. Please have your order details and product model number ready for faster assistance.

© 2024 Dupad story. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07GPPRYD9

More documents and user manuals: **https://manuals.plus/**