Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun SE911

Braun FaceSpa Pro 911 User Manual

3-in-1 Facial Epilation, Cleansing & Skin Toning Device

1. Introduction

Welcome to the Braun FaceSpa Pro 911 user manual. This device is the world's first 3-in-1 facial epilation, cleansing, and skin toning system designed for comprehensive facial care. It offers precise facial hair removal, deep pore cleansing, and enhanced skin appearance through micro-vibration technology. This manual provides essential information for safe and effective use of your device.



Figure 1: The Braun FaceSpa Pro 911 device shown with its retail packaging, highlighting its multi-functionality for facial hair removal, deep pore cleansing, and skin toning.

2. Important Safety Information

To ensure safe operation and prevent injury, please read all instructions carefully before using the Braun FaceSpa Pro 911.

- Exfoliate before use to remove dead skin cells and reduce the risk of ingrown hairs.
- This device is intended for facial use only.
- Do not use on irritated, sunburned, or broken skin.
- Consult a doctor if you have a skin condition or are taking medication that affects skin.
- Keep the device dry when not in use. Although water-resistant, ensure proper drying after wet use.
- Do not share attachments for hygiene reasons.
- Keep out of reach of children.

3. Package Contents

Verify that all items listed below are included in your package:

- Braun FaceSpa Pro Device
- Epilator Head
- Cleansing Brush Head
- MicroVibration Toning Head
- Bronze Cap
- Stand
- Pouch
- Cleaning Brush
- Power Cord (not pictured)



Figure 2: An illustration detailing the components included with the Braun FaceSpa Pro 911, such as the main device, toning head, cleansing brush head, stand, pouch, epilator head, and cleaning brush. The power cord is also included but not shown in this visual.

4. Product Overview and Components

The Braun FaceSpa Pro 911 is a versatile device with interchangeable heads for various facial treatments.

- **Main Device:** The rechargeable handheld unit that powers all attachments.
- **Epilator Head:** Features 10 micro-openings designed to capture and remove even the finest facial hairs (4x shorter than wax) from the root.
- **Cleansing Brush Head:** A soft brush that cleanses the skin, removing makeup and impurities. It is 6x more effective than manual cleansing for oil-based foundations.
- **MicroVibration Toning Head:** Designed to gently massage the skin, aiding in the better application and absorption of serums and moisturizers for an enhanced skin appearance.



Figure 3: A visual representation of the Braun FaceSpa Pro device and its three primary attachments: the cleansing brush head, the toning head, and the epilator head, illustrating their distinct functions.

5. Charging the Device

The Braun FaceSpa Pro 911 is a rechargeable device. Before first use, fully charge the device.

1. Connect the power cord to the device and plug it into an electrical outlet.
2. The charging indicator light will illuminate to show that the device is charging.
3. A full charge typically takes approximately 1 hour and provides up to 90 minutes of cordless operation.
4. Unplug the device once fully charged.

6. Operating Instructions

The device features dual settings for speed and intensity, allowing for personalized treatments.

6.1. Using the Epilator Head

The epilator head is designed for precise facial hair removal.

1. Ensure your skin is clean and dry. Exfoliate beforehand to prepare the skin.
2. Attach the epilator head to the main device.
3. Turn on the device and select your desired speed setting.
4. Hold the device at a 90-degree angle to your skin and gently glide it against the direction of hair growth.
5. Move the device slowly and steadily. Avoid pressing too hard.
6. The epilator removes hair from the root, resulting in smoother skin for weeks. Hair grows back thinner and finer with consistent use.



Figure 4: An illustrative diagram explaining the mechanism of epilation, where tiny tweezers pull hair from the root without affecting the skin's surface, leading to finer hair regrowth over time.



Figure 5: A visual demonstrating the benefits of using the epilator, such as removing hair 4x shorter than waxing and providing long-lasting smoothness without the need for frequent salon appointments.



Figure 6: An infographic highlighting the key features of the Braun FaceSpa Pro, including its 3-in-1 functionality, micro-vibrating toning head, 10 micro-openings for fine hair removal, 2 speed settings, portability, and its effectiveness in providing weeks of smooth skin.

6.2. Using the Cleansing Brush Head

The cleansing brush head provides deep pore cleansing.

1. Dampen your face and the cleansing brush head with water.
2. Apply your preferred facial cleanser directly to the brush head or your face.
3. Attach the cleansing brush head to the main device.
4. Turn on the device and gently move it in small circles across your face.
5. Cleanse each area for approximately 20 seconds. The device is water-resistant and can be used in the shower.
6. Rinse your face and the brush head thoroughly after use.

6.3. Using the MicroVibration Toning Head

The toning head helps enhance the absorption of skincare products.

1. Apply your favorite serum or cream to your face.
2. Attach the MicroVibration toning head to the main device.
3. Turn on the device and gently glide the toning head over your face, allowing the micro-vibrations to work with your skincare product.
4. Move the device in upward and outward motions.
5. Use for a few minutes as part of your daily skincare routine.

7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your Braun FaceSpa Pro 911.

- **After Each Use:**
  - Remove the attachment head from the device.
  - Rinse the epilator head or cleansing brush head under running water. For the epilator head, use the small cleaning brush provided to remove any trapped hairs.
  - Wipe the main device with a damp cloth. Do not submerge the main device in water.
  - Allow all parts to air dry completely before reassembling or storing.
- **Deep Cleaning (Epilator Head):** Periodically, you may clean the epilator head with alcohol to ensure maximum hygiene.
- **Storage:** Store the device and its attachments in the provided pouch or on the stand in a dry place.

8. Troubleshooting

If you encounter issues with your Braun FaceSpa Pro 911, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided power cord.
Epilator not removing hair effectively.	Incorrect angle or speed; hairs too short/long; head is dirty.	Ensure device is held at 90 degrees and moved slowly against hair growth. Clean the epilator head. Ensure hair is not excessively short.
Skin irritation after epilation.	Skin not prepared; device used too aggressively; sensitive skin.	Exfoliate before use. Use gentle pressure. Apply a soothing lotion after epilation. If irritation persists, discontinue use.
Cleansing brush not effective.	Brush head is worn out or dirty.	Clean the brush head thoroughly. Replace the brush head if it appears worn (replacement heads sold separately).

9. Specifications

Feature	Detail
Model Number	SE911
Brand	Braun

Feature	Detail
Power Source	Battery Powered (Rechargeable Lithium Ion)
Water Resistance Level	Water Resistant
Product Dimensions	2.24 x 6.1 x 8.74 inches
Item Weight	10.72 ounces
Color	White/Bronze
UPC	069055880548

10. Warranty and Support

For warranty information, product registration, or technical support, please refer to the documentation included with your purchase or visit the official Braun website. Keep your proof of purchase for warranty claims.
Visit Braun's Official Website

© 2024 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07HFHY6RH

More documents and user manuals: **https://manuals.plus/**