Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic EW-CRA518-K

Panasonic CoriCoran High Frequency Therapy Equipment

Model: EW-CRA518-K

1. Introduction

Thank you for purchasing the Panasonic CoriCoran High Frequency Therapy Equipment, model EW-CRA518-K. This device is designed to provide high-frequency therapy to help alleviate muscle stiffness and discomfort. Please read this manual thoroughly before use to ensure safe and effective operation. Keep this manual for future reference.

2. Important Safety Information

Always follow basic safety precautions when using electrical products to reduce the risk of fire, electric shock, and injury. This device is intended for personal use as described in this manual. Consult a healthcare professional before use if you have any medical conditions, are pregnant, or have a pacemaker. Do not use on broken skin or open wounds. Keep out of reach of children.

- Do not disassemble, repair, or modify the device.
- Do not use the device near water or in excessively humid environments.
- Ensure the charging unit is connected to a power source within the specified voltage range (AC 100V-240V, 50/60 Hz).
- Stop use immediately if you experience any discomfort or adverse reactions.

3. Package Contents

Verify that all items are present in your package:

- Main Charging Case
- High Frequency Therapy Units (4 pieces)
- Waist Attachment Band
- AC Adapter / Power Cord
- User Manual



Figure 3.1: Main charging case with four individual therapy units. The units are round with a textured, copper-colored surface.



Figure 3.2: Main charging case in its closed position, showing the sleek black and copper design.



Figure 3.3: The included waist attachment band, designed to secure therapy units to the body.

4. Charging the Therapy Units

The individual therapy units are powered by Lithium Metal batteries and require charging before first use and when their power is low.

1. Place the four therapy units into their respective slots within the main charging case. Ensure they are seated correctly.
2. Connect the AC adapter to the charging case and then plug it into a standard electrical outlet (AC 100V-240V, 50/60 Hz).
3. The 'CHARGE' indicator on the case will illuminate, indicating that the units are charging.
4. Charging typically takes several hours. The indicator will change or turn off once charging is complete. Refer to the indicator guide on the charging case for specific status meanings.

5. Operation

The CoriCoran therapy units are designed for targeted application. Each unit emits high-frequency waves to the area it is applied to.

5.1 Attaching the Therapy Units

There are several methods to attach the therapy units, depending on the desired application area and personal preference:

- **Using the Waist Attachment Band:** Insert the therapy units into the designated pockets or loops on the waist band. Secure the band around your waist or other suitable body part to hold the units in place.
- **Using Rubber Rings (not included, but commonly used):** Some users prefer to use small rubber rings to attach the units to clothing, such as a T-shirt, allowing for indirect contact.
- **Using Adhesive Tape (not included):** For direct skin contact and precise placement, medical-grade adhesive tape can be used to secure the units directly to the skin. Ensure skin is clean and dry before applying tape.

5.2 Activating and Using the Units

Once attached, the therapy units typically activate automatically upon contact or when removed from the charging case. The device operates silently and does not produce noticeable sensations during use.

- Place the therapy units on the desired area of the body where you experience stiffness or discomfort. Common areas include the neck, shoulders, back, and joints.
- The recommended usage duration can vary. Many users find relief after 30 minutes to an hour of continuous use. You may use the device for longer periods as needed, but always monitor your comfort.
- The units are designed for continuous operation until their battery depletes or they are returned to the charging case.

6. Maintenance

6.1 Cleaning

- Wipe the therapy units and charging case with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water and a mild, non-abrasive detergent. Ensure no liquid enters the device openings.
- Do not use alcohol, thinners, or abrasive cleaners, as these can damage the surface.

6.2 Storage

- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep the therapy units in the charging case when not in use to protect them and ensure they are charged for next use.

6.3 Battery Care

- The therapy units contain built-in Lithium Metal batteries. Do not attempt to replace them yourself.
- For optimal battery life, avoid fully discharging the units frequently. Recharge them when the low battery indicator appears.

7. Troubleshooting

Problem	Possible Cause	Solution
Therapy unit not working	Low battery	Place the unit in the charging case and ensure it is fully charged.
Charging indicator not lighting up	AC adapter not connected properly or power outlet issue	Check AC adapter connection to the case and wall outlet. Try a different outlet.
Units fall off during use	Improper attachment method or loose clothing	Ensure units are securely attached using the band or appropriate adhesive. Use tighter clothing if attaching indirectly.

8. Specifications

- **Model Number:** EW-CRA518-K
- **Power Source (Therapy Units):** 4 Lithium Metal batteries (built-in, non-replaceable)
- **Charging Input:** AC 100V ~ AC 240V (50/60 Hz)
- **Package Dimensions:** 8.66 x 8.11 x 3.46 inches
- **Weight:** Approximately 1.48 Pounds (including packaging)
- **Type:** High Frequency Therapy Equipment

9. Warranty and Support

Panasonic products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your product or visit the official Panasonic website for your region. For technical support, service, or inquiries, please contact Panasonic customer service.
Panasonic Official Website: www.panasonic.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07HH7MZRH

More documents and user manuals: **https://manuals.plus/**