Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

IKEA 303.037.22

IKEA Sunnersta Rail 303.037.22 Instruction Manual

Model: 303.037.22
Brand: IKEA

Product Overview

The IKEA Sunnersta Rail is a versatile storage solution designed to help organize various items in your kitchen, bathroom, or other areas. Its simple and functional design allows for easy integration into different spaces, providing a practical way to keep frequently used items within reach.
This rail measures approximately 23.6 inches (60 cm) in length and is constructed from durable steel with a polyester powder coating, ensuring longevity and resistance to wear. It features polypropylene plastic end caps for a neat finish. The rail is designed to be mounted to a wall, offering a sturdy base for hanging hooks, containers, and other compatible accessories.

Image: The IKEA Sunnersta Rail, a simple white metal bar designed for wall mounting to provide additional storage.

Setup and Installation

The IKEA Sunnersta Rail is designed for screw-in installation. Proper mounting ensures stability and safety. Please follow these steps carefully.

Tools Required:

- Pencil
- Measuring Tape
- Drill
- Screwdriver (appropriate for your screws)
- Level (recommended for straight installation)
- Wall plugs/anchors (if mounting into drywall or masonry, not included)

Installation Steps:

1. **Choose Location:** Select a suitable wall location for the rail. Consider the height and accessibility for its intended use.

2. **Mark Mounting Points:** The distance between the two mounting points on the rail is approximately 21 inches (53.3 cm). Hold the rail against the wall at the desired height and use a pencil to mark the two screw holes. Use a level to ensure the marks are perfectly horizontal.
3. **Drill Pilot Holes:** Using a drill bit appropriate for your screws and wall material, drill pilot holes at the marked points. If mounting into drywall or masonry, insert suitable wall plugs/anchors (not supplied with the rail) into the drilled holes.
4. **Secure the Rail:** Align the rail's mounting holes with the drilled holes/anchors. Insert screws (not supplied with the rail) through the rail's holes and into the wall. Tighten the screws firmly with a screwdriver until the rail is securely fastened to the wall. Do not overtighten.
5. **Verify Stability:** Gently pull on the rail to ensure it is securely mounted and does not wobble.

Note: Screws and wall plugs/anchors are not included with the rail. Please choose fasteners appropriate for your wall material to ensure a secure installation.

Operating and Usage

The IKEA Sunnersta Rail is designed to be highly adaptable for various organizational needs. Once installed, it serves as a base for hanging compatible accessories.

Typical Applications:

- **Kitchen Organizer:** Hang kitchen utensils, dishcloths, or small containers for spices and herbs.
- **Bathroom Storage:** Ideal for hanging towels, small baskets for toiletries, or brushes.
- **Craft/Hobby Area:** Organize tools, art supplies, or small craft items.
- **Entryway:** Use for keys, small bags, or light jackets.

The rail is compatible with IKEA Sunnersta series hooks and containers, as well as other standard S-hooks or similar hanging accessories. Simply slide the hooks or accessories onto the rail to customize your storage solution.



Image: The IKEA Sunnersta Rail in use, demonstrating its capacity to hold various items like kitchen utensils and small plants in compatible containers.

Maintenance and Care

To ensure the longevity and appearance of your IKEA Sunnersta Rail, follow these simple maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. A mild cleaner can be used if necessary.
- **Drying:** Wipe dry with a clean cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or chemical solvents, as these can damage the polyester powder coating.
- **Regular Inspection:** Periodically check the mounting screws to ensure they remain tight and secure. Retighten if necessary.

Troubleshooting

If you encounter any issues with your IKEA Sunnersta Rail, consider the following common solutions:

- **Rail is Loose/Wobbly:**
    - Ensure the mounting screws are fully tightened.

- Verify that appropriate wall plugs/anchors were used for your wall material. If not, consider replacing them with more suitable ones.
- Check for any damage to the rail's mounting points.

- **Difficulty Mounting Straight:**
  - Always use a spirit level when marking pilot holes to ensure horizontal alignment.
  - Measure carefully before drilling.

- **Scratches/Damage to Finish:**
  - Minor scratches can sometimes be touched up with a white enamel paint, if desired.
  - Avoid dragging sharp objects across the rail.

For issues not covered here, please refer to the support section or contact IKEA customer service.

Product Specifications

Brand	IKEA
Model Number	303.037.22
Color	White
Material	Alloy Steel, Plastic, Polypropylene (PP)
Product Dimensions (L x W x H)	23.6" x 0.9" x 1.25" (60 cm x 2.4 cm x 3.2 cm)
Distance Between Mounting Points	21" (53.3 cm)
Finish Type	Powder Coated
Installation Type	Screw-In
Item Weight	0.55 Pounds (approx. 8.8 ounces)
Manufacturer	IKEA

Warranty and Support

Specific warranty information for the IKEA Sunnersta Rail is not provided within this manual. For details regarding product warranty, returns, or additional support, please refer to the official IKEA website or contact IKEA customer service directly.

You can typically find support information, FAQs, and contact details on the IKEA official website:www.ikea.com

© 2023 IKEA. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07HNYZC88

More documents and user manuals: **https://manuals.plus/**