Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BRUNO BOE047-IV

BRUNO Multi Futon Dryer

MODEL: BOE047-IV

Instruction Manual

1. Introduction

Thank you for purchasing the BRUNO Multi Futon Dryer BOE047-IV. This versatile appliance is designed to dry and warm futons, blankets, and shoes, providing comfort and hygiene. Please read this manual thoroughly before use to ensure safe and proper operation. Keep this manual for future reference.

2. Safety Information

- Always connect the appliance to a grounded power outlet.
- Do not operate the appliance with wet hands.
- Keep the appliance away from water or other liquids.
- Ensure the air inlets and outlets are not blocked during operation.
- Do not use the appliance near flammable materials.
- Unplug the appliance when not in use or before cleaning.
- Do not attempt to repair or disassemble the appliance yourself. Contact qualified service personnel.
- Supervise children to ensure they do not play with the appliance.

3. Package Contents

Verify that all items are present in the package:

- BRUNO Multi Futon Dryer Main Unit
- Two Flexible Hoses
- Two Nozzle Attachments
- Instruction Manual (this document)

4. Setup

1. **Placement:** Place the main unit on a stable, flat surface near the item to be dried or warmed. Ensure there is adequate ventilation around the unit.

2. **Attach Hoses:** Insert the flexible hoses into the designated ports on the top of the main unit. Ensure they are securely attached.
3. **Attach Nozzles:** Attach the nozzle attachments to the ends of the flexible hoses. These nozzles help direct the airflow.
4. **Power Connection:** Plug the power cord into a standard electrical outlet. The power indicator light will illuminate.



Figure 1: BRUNO Multi Futon Dryer with hoses extended, ready for use.

5. Operating Instructions

The control panel features buttons for Temperature, Timer, Mode, On, and Off. The digital display shows the selected time in minutes.



Figure 2: Control panel with Temperature, Timer, Mode, On/Off buttons, and digital display.

1. **Power On:** Press the **ON** button to turn on the appliance. The default settings will appear on the display.
2. **Set Temperature:** Press the **TEMPERATURE** button to cycle through temperature settings:
    - **Blue Light:** Cool air (for cooling or refreshing items).
    - **Yellow Light:** Warm air (for comfort or light drying).
    - **Red Light:** Hot air (for thorough drying or warming).
3. **Set Timer:** Press the **TIMER** button to adjust the operating duration. The time is displayed in minutes (e.g., 15, 30, 60, 90, 120, 180 minutes).
4. **Select Mode:** Press the **MODE** button to choose from various pre-set modes (Comfort, Refresh, Quick, Max). Each mode has a specific temperature and duration optimized for different uses. Refer to Section 6 for details on each mode.
5. **Start Operation:** Once temperature, timer, and mode are set, the unit will begin operation.
6. **Power Off:** Press the **OFF** button to stop operation and turn off the appliance.

6. Modes

The BRUNO Multi Futon Dryer offers several modes for optimized performance:

- **Comfort Mode:** Provides gentle warmth, ideal for pre-warming a bed before sleep.
- **Refresh Mode:** Circulates cool air to refresh items and reduce humidity.
- **Quick Mode:** Delivers rapid heating for quick drying or warming needs.
- **Max Mode:** Utilizes maximum heat and airflow for intensive drying, such as after washing.

7. Boot Drying Function

The flexible hoses and nozzle attachments can be used to dry shoes or boots. Insert one nozzle into each boot. Select an appropriate temperature (warm or hot) and timer setting. Ensure the boots are placed in a well-ventilated area during drying.

8. Maintenance

- **Cleaning:** Unplug the appliance before cleaning. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Filter Cleaning:** Regularly check and clean the air filter located at the back or bottom of the unit to maintain optimal performance.
- **Storage:** When not in use, store the appliance in a cool, dry place, away from direct sunlight and moisture. Ensure hoses are neatly stored to prevent damage.

9. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; power button not pressed.	Check power cord connection; try a different outlet; press the ON button firmly.
No airflow or weak airflow.	Air inlets/outlets blocked; clogged filter; hoses not properly attached.	Ensure clear path for airflow; clean the air filter; reattach hoses securely.
No heat or insufficient heat.	Incorrect temperature setting; unit in cool mode.	Adjust temperature to Warm or Hot; ensure not in Refresh (cool) mode.

If the problem persists after trying these solutions, please contact customer support.

10. Specifications

- **Brand:** BRUNO
- **Model Name:** BOE047-IV
- **Color:** Ivory
- **Material:** Plastic, Stainless Steel
- **Item Weight:** 1.4 Kilograms
- **Form Factor:** Front Load
- **Access Location:** Top Load

11. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official BRUNO website. Keep your proof of purchase for any warranty claims.
For further assistance, you may contact BRUNO customer service through their official channels.

© 2026 BRUNO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07HQFGZGK

More documents and user manuals: **https://manuals.plus/**