Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Artago 1651ART

Artago 1651ART Anti-Theft Motorbike Handlebar Lock Practic Art User Manual

For Honda X-ADV (2017 Onwards)

1. Introduction

This manual provides instructions for the installation, operation, and maintenance of the Artago 1651ART Practic Art Anti-Theft Handlebar Lock. This high-end security device is specifically designed for the Honda X-ADV (2017 onwards) to provide robust anti-theft protection.

2. Product Overview

The Artago 1651ART Practic Art is an integrated handlebar lock system featuring a high-strength armored steel body and a specialized transport bracket. It utilizes the advanced DISC-TECH ART+ lock mechanism for enhanced security.

2.1 Included Components

- Artago Practic Art Handlebar Lock
- Set of Keys
- Dedicated Transport Bracket for Honda X-ADV (2017 Onwards)

2.2 Key Features

- **Integrated Design:** Specifically engineered for the Honda X-ADV (2017 onwards) for seamless integration and minimal interference during transport.
- **High-Strength Construction:** Features an armored steel body for maximum resistance against physical attacks.
- **DISC-TECH ART+ Lock:** Incorporates an advanced anti-pick lock mechanism with a 5mm anti-drill disc. This lock system is also used in Artago's "Bunker Selection" locks, which have undergone testing by independent homologation laboratories for theft resistance.
- **Key Duplication Service:** Keys can be duplicated by code in case of loss.



Figure 1: The Artago 1651ART Handlebar Lock with its dedicated transport bracket.

3. Setup and Installation

The Artago 1651ART lock is designed for easy assembly and integration with your Honda X-ADV. Follow these steps for proper installation.

1. **Prepare the Motorcycle:** Ensure the motorcycle is stable and turned off.
2. **Install the Transport Bracket:** The dedicated bracket is designed to fit specific points on your Honda X-ADV (2017 onwards). Refer to your motorcycle's service manual or a qualified mechanic for precise mounting locations if unsure. Secure the bracket firmly using appropriate tools.
3. **Attach the Lock:** Once the bracket is securely installed, the handlebar lock unit can be attached to it. The design allows for quick attachment and detachment.
4. **Test Fit:** Before regular use, perform a test fit to ensure the lock engages correctly with the handlebar and the bracket holds the lock securely without obstructing controls or movement.



Figure 2: The Artago 1651ART Handlebar Lock in its operational position on a Honda X-ADV.

4. Operating Instructions

Using your Artago 1651ART lock is designed to be quick and practical.

1. **To Lock:**
    - Remove the lock from its transport bracket.
    - Position the lock around the handlebar and a fixed part of the motorcycle (e.g., brake lever, frame) to prevent steering or movement.
    - Insert the key and turn to engage the locking mechanism. Ensure the lock is fully engaged and secure.
2. **To Unlock:**
    - Insert the key into the lock.
    - Turn the key to disengage the locking mechanism.
    - Remove the lock from the handlebar and return it to its transport bracket for storage while riding.



Figure 3: Close-up view of the Artago 1651ART lock head, showing the keyhole and locking mechanism.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Artago 1651ART lock.

- **Cleaning:** Wipe the lock body and bracket with a damp cloth to remove dirt and grime. Avoid harsh chemicals that may damage the finish.
- **Lubrication:** Periodically apply a small amount of graphite lubricant or a specialized lock lubricant into the keyhole and moving parts of the locking mechanism. Do not use oil-based lubricants as they can attract dirt.
- **Inspection:** Regularly inspect the lock and bracket for any signs of wear, damage, or corrosion. Ensure all mounting points are secure.
- **Key Care:** Keep your keys clean and free from debris. Avoid forcing the key if it feels stiff; lubricate the lock instead.

6. Troubleshooting

If you encounter issues with your Artago 1651ART lock, consider the following common solutions:

- **Lock is Stiff or Difficult to Turn:**
  - Apply graphite lubricant to the keyhole and mechanism.
  - Ensure the key is fully inserted and not bent or damaged.
- **Lock Does Not Engage/Disengage:**
  - Verify that the lock is correctly positioned around the handlebar and the motorcycle part.
  - Check for any obstructions preventing the mechanism from fully engaging.
  - Inspect the key for damage.
- **Bracket Feels Loose:**
  - Re-tighten all mounting screws for the transport bracket. Do not overtighten.
  - Inspect the bracket for any signs of damage or deformation.

If problems persist, contact Artago customer support or a qualified technician.

7. Specifications

Attribute	Detail
Brand	Artago
Model Name	1651ART
Lock Type	Key Lock (DISC-TECH ART+)
Special Feature	Anti-theft, Integrated Transport Bracket
Material	Alloy Steel
Item Dimensions (L x W x H)	9.84 x 3.15 x 3.15 inches (25 x 8 x 8 cm)
Item Weight	3.34 pounds (1.51 kg)
Color	Chrome
Manufacturer	Artago Secure
Compatibility	Honda X-ADV (2017 Onwards)

8. Warranty and Support

Artago products are manufactured with high-quality standards. For warranty information, product support, or key duplication services, please refer to the official Artago website or contact their customer service directly. Keep your key code in a safe place for future reference.
Manufacturer: Artago Secure, Valencia, Spain

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JHB7K31

More documents and user manuals: **https://manuals.plus/**