Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iDealBed 3i

iDealBed 3i Custom Adjustable Bed Base User Manual

Model: 3i

1. Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your iDealBed 3i Custom Adjustable Bed Base. Please read this manual thoroughly before use to ensure proper function and safety.

2. Important Safety Information

WARNING:

- Do not load more than 850 pounds on the adjustable bed base.
- Ensure proper assembly to prevent instability.
- Keep children and pets away from moving parts.
- Do not operate the bed base if any part is damaged or malfunctioning. Contact customer support immediately.

3. Package Contents

Verify that all components are present before beginning assembly:

- iDealBed 3i Adjustable Bed Base Frame
- Wireless Remote Control (2 AAA batteries included)
- Multi-option Height Legs (9" to 15" adjustable in half-inch increments)
- Foot Retainer Bar
- Power Cord and Adapter

4. Setup Instructions

The iDealBed 3i features an almost no-assembly design. Follow these steps for quick setup:

1. **Unpack the Base:** Carefully remove the bed base from its packaging.

2. **Unfold the Frame:** If the frame is folded, gently unfold it to its full size.
3. **Attach the Legs:** Screw the multi-option height legs into the designated points on the underside of the frame. Adjust the leg height to your desired level (9" to 15" in half-inch increments).



Image: Multi-Height Leg Kit showing various leg height options.

4. **Install Foot Retainer Bar:** Attach the foot retainer bar at the end of the bed to keep the mattress in place during articulation.
5. **Position the Base:** Place the bed base in your desired location. The Zero Clearance Design allows the adjustable bed to be used without legs if preferred, or placed directly on a platform bed frame.
6. **Plug In:** Connect the power cord to the bed base and then to a power outlet.



Image: The iDealBed 3i Adjustable Bed Base with dimensions (75"L x 54"W x 14"H for Full size).



Image: The iDealBed 3i Adjustable Bed Base shown in a flat position.

5. Operating Instructions

Your iDealBed 3i comes with a luxurious interactive wireless ergonomic remote control for easy adjustment.

5.1 Remote Control Functions



Image: The iDealBed 3i wireless remote control with backlit buttons.

The remote features 8 backlit buttons for visibility and one-touch comfort position responses:

- **HEAD Up/Down:** Adjusts the head section of the bed base up to 75°.
- **FOOT Up/Down:** Adjusts the foot section of the bed base up to 45°.
- **FLAT:** One-touch button to return the bed base to a completely flat position.
- **ZG (Zero Gravity):** One-touch button to move the bed to the Zero Gravity position, which elevates the head and feet to create a feeling of weightlessness, relieving pressure on the back.



Image: The iDealBed 3i Adjustable Bed Base demonstrating the Zero Gravity position.

- **M1 / M2 (Programmable Memory Positions):** Two buttons to save and recall your favorite custom positions. To program a position, adjust the bed to your desired setting, then press and hold the M1 or M2 button until the remote backlight flashes (approximately five seconds).



Image: The iDealBed 3i Adjustable Bed Base illustrating the use of memory settings.

- **Flashlight:** Activates a built-in flashlight for convenience in low-light conditions.



Image: The iDealBed 3i Adjustable Bed Base with both head and foot sections elevated.

6. Maintenance

To ensure the longevity and optimal performance of your iDealBed 3i Adjustable Bed Base, follow these maintenance guidelines:

- **Cleaning:** Wipe the frame with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Motor Care:** The German-engineered Okin motors are designed for smooth and silent operation and require no special maintenance.
- **Power Cord:** Regularly inspect the power cord for any damage. Do not use if damaged.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 850 pounds.
- **Battery Replacement:** Replace the AAA batteries in the remote control as needed.

7. Troubleshooting

If you encounter any issues with your iDealBed 3i, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed does not operate	No power, loose connection, remote not paired	Check power cord connection. Ensure outlet is functional. Re-pair remote control if necessary (refer to remote instructions).
Remote control not responding	Dead batteries, remote out of range, interference	Replace remote batteries. Move closer to the bed base. Remove any potential sources of interference.
Unusual noise during operation	Obstruction, loose components	Check for any objects obstructing the moving parts. Ensure all legs and components are securely fastened.

If the issue persists after attempting these solutions, please contact iDealBed customer support.

8. Specifications

Feature	Detail
Model Number	3i
Size (Full)	75"L x 54"W x 14"H
Material	Alloy Steel
Color	Grey, Charcoal
Special Feature	Adjustable
Included Components	Remote
Compatible Mattress Size	Full
Manufacturer	iDealBed
Assembly Required	Yes (minimal)
Item Weight	90 pounds
Batteries	2 AAA batteries (included)
Max Load Capacity	850 pounds
Head Articulation	Up to 75°
Foot Articulation	Up to 45°

9. Warranty Information

The iDealBed 3i Custom Adjustable Bed Base comes with a**10-Year Industry Leading Manufacturer Warranty**. For specific terms and conditions, please refer to the warranty card included with your product or contact iDealBed customer support.

10. Customer Support

For further assistance, technical support, or warranty claims, please contact iDealBed customer support through the official website or the contact information provided in your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07KK7XTP1

More documents and user manuals: **https://manuals.plus/**