Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Alecto AK-15

Alecto AK-15 Analog Wall Clock with Thermometer and Hygrometer

Model: AK-15 | Brand: Alecto

Introduction

This manual provides comprehensive instructions for the Alecto AK-15 Analog Wall Clock. This clock features a silent quartz movement, an integrated thermometer, and a hygrometer, offering both precise timekeeping and environmental monitoring. Its 30 cm diameter and elegant aluminum finish make it suitable for various indoor settings. Please read this manual carefully before installation and operation to ensure proper use and longevity of your device.

Package Contents

Verify that all items are present in the package:

- 1 x Alecto AK-15 Analog Wall Clock
- 1 x Instruction Manual
- *Note: 3x AA batteries are required and not included.*



Image: Rear view of the Alecto AK-15 clock, highlighting the battery compartment and the quartz movement. This image also shows a graphic representation of the package contents: the analog wall clock and the instruction manual.

Setup

1. Battery Installation

1. Locate the battery compartments on the back of the clock. There are two compartments: one for the clock movement (1x AA battery) and another for the thermometer/hygrometer display (2x AA batteries).
2. Open the battery compartment covers.
3. Insert 3 new AA batteries in total, ensuring correct polarity (+ and -) as indicated inside the compartments.
4. Close the battery compartment covers securely.



Image: Detailed view of the back of the Alecto AK-15 wall clock, showing the two battery compartments and the time adjustment knob.

2. Time Setting

1. After installing the batteries, locate the time adjustment knob on the back of the clock, usually near the clock movement.
2. Rotate the knob to set the correct time.
3. The quartz movement will begin operating silently.

3. Mounting the Clock

1. Choose a suitable indoor location for the clock. Ensure it is not exposed to direct sunlight or extreme temperature fluctuations, which could affect the accuracy of the thermometer and hygrometer.
2. Use a sturdy hook or screw (not included) to mount the clock securely on a wall. The clock features a hanging slot on its back for easy installation.



Image: Front view of the Alecto AK-15 wall clock, displaying the analog time, digital temperature, and humidity readings.

Operation

Reading the Time

The clock displays time using traditional analog hands (hour, minute, second). The silent quartz movement ensures accurate and quiet operation.

Reading Temperature and Humidity

The Alecto AK-15 features two integrated digital displays on its face:

- **Temperature Display:** Shows the ambient room temperature in Celsius.
- **Humidity Display:** Shows the relative air humidity in percentage (%).

These readings are continuously updated to provide current environmental conditions.



Image: A close-up view of the Alecto AK-15 clock face, specifically highlighting the digital hygrometer display showing relative air humidity.

Maintenance

Battery Replacement

When the clock hands stop moving or the digital displays fade, it is time to replace the batteries. Follow the battery installation steps in the Setup section. Always replace all batteries at the same time with new AA batteries for optimal performance.

Cleaning

To clean the clock, wipe it gently with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the finish or internal components. Avoid getting moisture into the clock mechanism or digital displays.

Troubleshooting

Problem	Possible Cause	Solution
Clock hands do not move.	Dead or incorrectly installed AA battery for the clock movement.	Replace the AA battery, ensuring correct polarity.
Digital displays (temperature/humidity) are blank or dim.	Dead or incorrectly installed AA batteries for the digital displays.	Replace the 2x AA batteries, ensuring correct polarity.
Incorrect time displayed.	Time was not set correctly or was accidentally adjusted.	Adjust the time using the knob on the back of the clock.
Inaccurate temperature/humidity readings.	Clock is placed in an area with extreme temperature fluctuations or direct sunlight.	Relocate the clock to a more stable indoor environment. Allow time for readings to stabilize.

Specifications

- **Model:** AK-15
- **Brand:** Alecto
- **Display Type:** Analog (Time), Digital (Temperature, Humidity)
- **Movement Type:** Quartz
- **Power Source:** Battery powered (3x AA batteries required, not included)
- **Dimensions (L x W x H):** 31.8 x 3.81 x 34.2 cm (approximately 30 cm diameter)
- **Weight:** 900 grams
- **Material:** Metal (Aluminum finish)
- **Color:** Silver
- **Usage:** Indoor
- **Special Features:** Silent operation, integrated thermometer, integrated hygrometer



Image: The Alecto AK-15 wall clock shown with its key dimensions: 30 cm diameter and 4.8 cm depth.

Safety Information

- Keep batteries out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the clock will not be used for an extended period.
- Dispose of used batteries responsibly according to local regulations.
- Do not expose the clock to water or high humidity environments (e.g., bathrooms without proper ventilation) as it is designed for indoor use.
- Avoid dropping the clock or subjecting it to strong impacts.

Warranty and Support

The Alecto AK-15 Analog Wall Clock comes with a**2-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty claims, technical support, or further assistance, please contact Alecto customer service through their official website or the retailer where the product was purchased. Please have your proof of purchase and model number (AK-15) ready when contacting support.

© 2024 Alecto. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07L5QNMNN

More documents and user manuals: **https://manuals.plus/**