Secura HB-3227B

Secura Original Stainless Steel Double Wall Electric Water Kettle

Model: HB-3227B | Brand: Secura

Important Safety Information

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not immerse the kettle or power base in water or other liquids.
- Ensure the power supply voltage matches the rating label on the appliance.
- Always place the kettle on a firm, flat, heat-resistant surface.
- Do not operate the kettle if the cord or plug is damaged.
- Keep out of reach of children.
- The exterior of the kettle features a cool-touch design, but caution should still be exercised when handling hot water.

Product Components

The Secura Electric Water Kettle package includes the following items:

- Electric Kettle (1.8 Quart Capacity)
- Power Base with Cord
- User Manual



Figure 1: Main view of the Secura Electric Water Kettle.

Setup Instructions

1. **Unpack the Kettle:** Carefully remove all packaging materials and inspect the kettle and power base for any damage.
2. **Initial Cleaning:** Before first use, fill the kettle with clean water to the MAX line. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Place the Power Base:** Position the power base on a stable, flat, and dry surface near an electrical outlet.
4. **Connect to Power:** Plug the power cord into a grounded electrical outlet.



Figure 2: Kettle dimensions and 1.7L/1.8Qt capacity marking.

Operating Instructions

1. **Fill the Kettle:** Open the lid and fill the kettle with the desired amount of water. Ensure the water level is between the MIN and MAX marks located inside the kettle. The interior is 100% food-grade stainless steel, ensuring no plastic contact with water.
2. **Close the Lid:** Securely close the lid.
3. **Place on Power Base:** Place the kettle firmly onto the power base. The cordless design allows for easy placement and serving.
4. **Turn On:** Press the ON/OFF switch located on the handle downwards. The indicator light will illuminate, indicating that the kettle is heating.
5. **Boiling Process:** The kettle will begin to heat the water. Thanks to its double-wall stainless steel construction, water boils quickly and stays warm longer.
6. **Automatic Shut-Off:** Once the water reaches a rolling boil, the kettle will automatically shut off, and the indicator light will extinguish.
7. **Serve:** Carefully lift the kettle from the power base and pour the hot water. The cool-touch exterior minimizes scalding hazards.



Figure 3: The kettle features a 100% food-grade stainless steel interior, ensuring no plastic touches the water.



Figure 4: Double-wall design provides thermal insulation, keeping the exterior cool to the touch.

Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your kettle.

- **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- **Interior Cleaning (Hand Wash):** The kettle interior should be hand washed. For general cleaning, rinse the interior with warm water after each use.
- **Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. To descale, fill the kettle with a mixture of water and white vinegar (1:1 ratio) or a commercial descaling solution. Boil the mixture, then let it stand for 30 minutes to an hour. Discard the mixture and rinse the kettle thoroughly several times with fresh water.



Figure 5: The wide opening allows for easy access to clean the interior by hand.

Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in; power switch not pressed; kettle not properly seated on base; power outage.	Check power connection; ensure switch is ON; reseat kettle on base; check household power.
Kettle switches off before boiling.	Too much limescale buildup; insufficient water.	Descale the kettle; ensure water level is above MIN mark.
Water tastes metallic or has residue.	New kettle residue; limescale buildup.	Perform initial cleaning steps again; descale the kettle.

Specifications

Brand: Secura

Model Name: HB-3227B

Color: Black Onyx

Capacity: 1.8 Quarts (1.7 Liters)

Material: Stainless Steel Interior, BPA-Free Cool Touch Exterior

Special Feature: Auto Shut-Off, Boil-Dry Protection, Double-Wall Insulation, British Strix Control

Power: 120V, 60Hz, 1500W

Product Dimensions: 6.29"L x 6.29"W x 10.24"H

Item Weight: 2.5 Pounds

Care Instructions: Hand Wash



Figure 6: The kettle incorporates reliable British Strix control for safety features.

Warranty and Support

Secura stands behind its products and service with confidence. If for any reason you are not completely satisfied with your purchase, please contact customer support. We are committed to providing the best customer support and will reply to your questions within 24 hours.

For further assistance or warranty claims, please refer to the contact information provided on the product packaging or the official Secura website.

© 2024 Secura. All rights reserved.